

## A INTRODUCTION

This manual consists of the following 11 sections:

No.	Section	Description
A	INDEX	Index of the contents of this manual.
	INTRODUCTION	Brief explanation of each section.
B	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
C	TROUBLE-SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
H	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
I	INDEX	Index of the system circuits.
	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to use this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
J	GROUND POINTS	Shows ground positions of all the parts described in this manual.
K	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.

This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)

When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Points section). See the System Outline to understand the circuit operation.

When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.


Wiring related to each system is indicated in each system circuit by arrows (from\_\_,to\_\_). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.

# B HOW TO USE THIS MANUAL

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.




## POWER WINDOW



- (A) : System Title
- (B) : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.


Example: ① Indicates Relay Block No. 1.

- (C) : Indicates the connector to be connected to a part (the numeral indicates the pin No.)  
Explanation of pin use.



The pins shown are only for the highest grade, or only include those in the specification.

- (D) : Connector Color Connectors not indicated are milky white in color:
- (E) : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- (F) : Indicates related system.
- (G) : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↘).




The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g. "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g. IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

- (H) : Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.

- (I) : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts .

Example:



- (J) : Indicates the wiring color.  
Wire colors are indicated by an alphabetical code.


B = Black	L = Black	R = Red
BR = Brown	LG = Light Green	V = Violet
G = Green	O = Orange	W = White
GR = Gray	P = Pink	Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.




- (K) : Indicates a wiring Splice Point (Codes are "E" for the Engine Room, "I" for the Instrument Panel, and "B" for the Body).

Example:



The Location of Splice Point I 5 is indicated by the shaded section.


- (L) : Page No.
- (M) : Indicates a shielded cable.



- (N) : Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g. "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

- (O) : Indicates the pin number of the connector.  
The numbering system is different for female and male connectors.



- (P) : When 2 parts both use one connector in common, the parts connector name used in the wire routing section is shown in square brackets [ ].

# B HOW TO USE THIS MANUAL

## Q SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS TO **TERMINAL 3** OF THE POWER WINDOW MASTER SW, **TERMINAL 2** OF THE POWER WINDOW CONTROL RELAY AND **TERMINAL 8** OF THE POWER WINDOW SW THROUGH THE DOOR FUSE.

### 1. DRIVER'S WINDOW "MANUAL UP" OPERATION BY MASTER SW

HOLDING MANUAL SW (DRIVER'S) ON "UP" POSITION LOCATED IN POWER WINDOW MASTER SW, THE CURRENT FLOWS TO **TERMINAL 5** OF THE POWER WINDOW CONTROL RELAY THROUGH **TERMINAL 3** OF THE MASTER SW → **TERMINAL 2** TO OPERATE A POWER WINDOW CONTROL RELAY. THUS THE CURRENT INSIDE THE RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY → **TERMINAL 1** → **TERMINAL 2** OF THE POWER WINDOW MOTOR → **TERMINAL 1** → **TERMINAL 4** OF THE RELAY → **TERMINAL 3** → TO **GROUND**. THE MOTOR TURNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND THE WINDOWS CAN STOP AT WILL POINT.

(FOR THE "MANUAL DOWN" OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOW ARE CHANGED).

### 2. DRIVER'S WINDOW "AUTO DOWN" OPERATION BY MASTER SW

ONCE THE "AUTO DOWN" BUTTON OF THE MASTER SW IS PUSHED, THE CURRENT FLOW **TERMINAL 9** OF THE POWER WINDOW CONTROL RELAY THROUGH **TERMINAL 3** OF THE MASTER SW → **TERMINALS 8 AND 9** TO OPERATE THE RELAY. THUS THE CURRENT INSIDE THE POWER WINDOW CONTROL RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY → **TERMINAL 4** → **TERMINAL 1** OF THE POWER WINDOW MOTOR → **TERMINAL 2** → **TERMINAL 1** OF THE RELAY → **TERMINAL 3** → TO **GROUND**. THE MOTOR CONTINUES THE ROTATION ENABLING TO DESCENT THE WINDOW.

THE WINDOW DESCENDS TO THE END POSITION. THE CURRENT WILL BE CUT OFF TO RELEASE THE AUTO DOWN FUNCTION BASED ON THE INCREASING CURRENT BETWEEN **TERMINAL 2** OF THE RELAY AND **TERMINAL 1** IN RELAY.

### 3. DRIVER'S WINDOW AUTO DOWN RELEASE OPERATION BY MASTER SW

HOLDING THE MANUAL SW (DRIVER'S) ON "UP" POSITION IN OPERATING AUTO DOWN. THE CURRENT FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 2** FLOWS **TERMINAL 5** OF THE RELAY AND RELEASES THE AUTO DOWN FUNCTION IN THE POWER WINDOW CONTROL RELAY. RELEASING THE HAND FROM SW, WINDOW STOPS AND CONTINUING ON TOUCHING SW. THE FUNCTION SWITCHES TO MANUAL UP OPERATION.

### 4. PASSENGER'S WINDOW UP OPERATION (MASTER SW) AND WINDOW LOCK SW OPERATION

HOLDING PASSENGER'S WINDOW SW (MASTER SW) ON "UP", THE CURRENT FLOWS FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 6** TO **TERMINAL 3** OF THE POWER WINDOW SW (PASSENGER'S) → **TERMINAL 4** **TERMINAL** → **2** OF THE MOTOR → **TERMINAL 1** → **TERMINAL 9** OF THE POWER WINDOW SW → **TERMINAL 7** → **TERMINAL 1** OF THE MASTER SW → **TERMINAL 4** TO **GROUND**. THE MOTOR RUNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND WINDOW CAN STOP AT WILL PLACE. SWITCHING THE WINDOW LOCK SW IN "LOCK" POSITION, THE CIRCUIT IS OPENED AND STOPPED THE MOTOR ROTATION.

(FOR THE DOWN OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOWS ARE CHANGED).

## R SERVICE HINTS

### P 2 POWER WINDOW CONTROL RELAY

3-GROUND: ALWAYS CONTINUITY

2-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

5-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE MASTER SW AT **UP** POSITION

8-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE MASTER SW AT **AUTO DOWN** POSITION

9-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE MASTER SW AT **DOWN** OR **AUTO DOWN** POSITION

### P 4 POWER WINDOW MASTER SW

4-GROUND: ALWAYS CONTINUITY

3-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

### WINDOW LOCK SW

OPEN WITH THE WINDOW LOCK SW AT **LOCK** POSITION

## S

: PARTS LOCATION					
CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
P2	21	P4	21	P6	21
P3	21	P5	21		

## T

: RELAY BLOCKS		
CODE	SEE PAGE	RELAY BLOCK (RELAY BLOCK LOCATION)
1	16	R/B NO. 1 (INSTRUMENT PANEL LEFT)

## U

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR		
CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
38	14	J/B NO. 3 AND COWL WIRE (INSTRUMENT PANEL LEFT SIDE)

## V

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS		
CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	26	FRONT DOOR RH WIRE AND COWL WIRE (RIGHT KICK PANEL)
IH1	26	FRONT DOOR LH WIRE AND COWL WIRE (LEFT KICK PANEL)

## W

: GROUND POINTS		
CODE	SEE PAGE	GROUND POINT LOCATION
IC	24	COWL LEFT


## X

: SPLICE POINTS					
CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
15	24	COWL WIRE			

- Ⓚ: Explains the system outline.
- Ⓡ: Indicates values or explain the function for reference during troubleshooting.
- Ⓢ: Indicates the reference page showing the position on the vehicle of the parts in the system circuit.

Example: Part "P 4" (Power Window Master SW) is on page 21 of the manual.

\* The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with the letter.

Example: P 4  


- Ⓣ: Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.

Example: Connector "1" is described on page 16 on this manual and is installed on the left side of the instrument panel.

- Ⓤ: Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.

Example: Connector "3B" connects the Cowl Wire and J/B No. 3. It is described on page 14 of this manual, and is installed on the instrument panel left side.

- Ⓥ: Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).

Example: Connector "ID1" connects the front door RH wire (female) and cowl wire (male). It is described on page 26 of this manual, and is installed on the right side kick panel.


- Ⓦ: Indicates the reference page showing the position of the ground points on the vehicle.

Example: Ground point "IC" is described on page 24 of this manual and is installed on the cowl left side.

- Ⓧ: Indicates the reference page showing the position of the splice points on the vehicle.

Example: Splice point "I 5" is on the Cowl Wire Harness and is described on page 24 of this manual.

#### HINTS:




Junction connector (code: J1 to J19) in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.) Wire harness sharing the same short terminal grouping have the same color.





The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (EA, IB and IC shown below) can also be checked this way.


## J GROUND POINT



\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



# C TROUBLESHOOTING




## VOLTAGE CHECK

- (a) Establish conditions in which voltage is present at the check point.

Example:


- Ⓐ - Ignition SW on
- Ⓑ - Ignition SW and SW 1 on
- Ⓒ - Ignition SW, SW 1 and Relay on (SW2 off)

- (b) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal, and the positive lead to the connector or component terminal. This check can be done with a test light instead of a voltmeter.



## CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check point.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- (c) Use the volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting of the electrical circuit.



## FINDING A SHORT CIRCUIT

- Remove the blown fuse and disconnect all loads of the fuse.
- Connect a test light in place of the fuse.
- Establish conditions in which the test light comes on.

Example:

- Ⓐ - Ignition SW on
  - Ⓑ - Ignition SW and SW 1 on
  - Ⓒ - Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)
- Disconnect and reconnect the connectors while watching the test light.  
The short lies between the connector where the test light stays lit and the connector where the light goes out.
  - Find the exact location of the short by lightly shaking the problem wire along the body.


## CAUTION:

- Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)
- When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).





## DISCONNECTION OF MALE AND FEMALE CONNECTORS

To pull apart the connectors, pull on the connector itself, not the wire harness.

HINT: Check to see what kind of connector you are disconnecting before pulling apart.



# C TROUBLESHOOTING



## HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

### 1. PREPARE THE SPECIAL TOOL

HINT: To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.

### 2. DISCONNECT CONNECTOR

### 3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER

- (a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
- (b) Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

### NOTICE:

**Do not remove the terminal retainer from connector body.**

- Ⓐ For Non-Waterproof Type Connector





HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.

### "Case 1"

Raise the terminal retainer up to the temporary lock position.

### "Case 2"

Open the secondary locking device.



Ⓑ For Waterproof Type Connector

HINT: Terminal retainer color is different according to connector body.

Example:

Terminal Retainer	:Connector Body
Black or White	:Gray
Black or White	:Dark Gray
Gray or White	:Black

“Case 1”

Type where terminal retainer is pulled up to the temporary lock position (Pull Type).


Insert the special tool into the terminal retainer access hole (▲ Mark) and pull the terminal retainer up to the temporary lock position.

HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.


“Case 2”

Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.


# C TROUBLESHOOTING



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




## 4. INSTALL TERMINAL TO CONNECTOR

(a) Insert the terminal.


HINT:

1. Make sure the terminal is positioned correctly.
2. Insert the terminal until the locking lug locks firmly.
3. Insert the terminal with terminal retainer in the temporary lock position.



(b) Push the secondary locking device or terminal retainer into the full lock position.

## 5. CONNECT CONNECTOR



## DISCONNECTION AND CONNECTION OF BOLT TYPE CONNECTORS

For engine control module in this vehicle, connections are used which require a bolt built into the connector to be screwed down to securely connect the connector.

1. Disconnect the connector

After completely loosening the bolt, the two parts of the connector can be separated.

**NOTICE:**

**Do not pull the wire harness when disconnecting the connector.**

2. Connect the connector

**NOTICE:**

**Before connecting the connector, always check that the terminals are not bent or damaged.**

- (a) Match the guide section of the male connector correctly with the female connector, then press them together.

- (b) Tighten the bolt.

Make sure the connectors are completely connected, by tightening the bolt until there is a clearance of less than 1 mm (0.04 in.) between the bottom of male connector and the end of female connector.



## ABBREVIATIONS

The follow abbreviations are used in this manual.






















## ABBREVIATIONS D

















---

ABS	= Anti-Lock Brake System	O/D	= Overdrive
A/C	= Air Conditioning	PPS	= Progressive Power Steering
ACIS	= Acoustic Control Induction System	R/B	= Relay Block
A/T	= Automatic Transmission	RH	= Right-Hand
COMB.	= Combination	SFI	= Sequential Multiport Fuel Injection
ECU.	= Electronic Control Unit	SRS	= Supplemental Restraint System
EGR	= Exhaust Gas Recirculation	SW	= Switch
ESA	= Electronic Spark Advance	TEMP.	= Temperature
EVAP	= Evaporative Emission	TRAC	= Traction Control
J/B	= Junction Block	VSV	= Vacuum Switching Valve
LH	= Left-Hand	w/	= With
M/T	= Manual Transmission	w/o	= Without

\* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.


# E GLOSSARY OF TERMS AND SYMBOLS

 <p><b>BATTERY</b> Stores chemical energy and converts it into electrical energy. Provides DC current for the auto's various electrical circuits.</p>	<p><b>GROUND</b> The point at which wiring attaches to the Body, thereby providing a return path for an electrical circuit; without a ground, current cannot flow.</p> 
 <p><b>CAPACITOR (Condenser)</b> A small holding unit for temporary storage of electrical voltage.</p>	<p><b>HEADLIGHTS</b> Current flow causes a headlight filament to heat up and emit light. A headlight may have either a single (1) filament or a double (2) filament.</p> <p>1. <b>SINGLE FILAMENT</b></p>  <p>2. <b>DOUBLE FILAMENT</b></p> 
 <p><b>CIGARETTE LIGHTER</b> An electric resistance heating element.</p>	
<p><b>CIRCUIT BREAKER</b> Basically a reusable fuse, a circuit breaker will heat and open if too much current flows through it. Some units automatically reset when cool, others must be manually reset.</p> 	<p><b>HORN</b> An electric device which sounds a loud audible signal.</p> 
<p><b>DIODE</b> A semiconductor which allows current flow in only one direction.</p> 	<p><b>IGNITION COIL</b> Convert low-voltage DC current into high-voltage ignition current for firing the spark plugs.</p> 
<p><b>DIODE, ZENER</b> A diode which allows current flow in one direction but blocks reverse flow only up to a specific voltage. Above that potential, it passes the excess voltage. This acts as a simple voltage regulator.</p> 	<p><b>LIGHT</b> Current flow through a filament causes the filament to heat up and emit light.</p> 
<p><b>PHOTODIODE</b> The photodiode is a semiconductor which controls the current flow according to the amount of light.</p> 	<p><b>LED (LIGHT EMITTING DIODE)</b> Upon current flow, these diodes emit light without producing the heat of a comparable light.</p> 
 <p><b>DISTRIBUTOR, IIA</b> Channels high-voltage current from the ignition coil to the individual spark plugs.</p>	<p><b>METER, ANALOG</b> Current flow activates a magnetic coil which causes a needle to move, thereby providing a relative display against a background calibration.</p> 
<p><b>FUSE</b> A thin metal strip which burns through when too much current flows through it, thereby stopping current flow and protecting a circuit from damage.</p>  <p><b>FUSIBLE LINK</b> A heavy-gauge wire placed in high amperage circuits which burns through on overloads, thereby protecting the circuit. The numbers indicate the cross-section surface area of the wires.</p>  <p>(for Medium Current Fuse)</p>  <p>(for High Current Fuse or Fusible Link.)</p>	<p><b>METER, DIGITAL</b> Current flow activates one or many LED's, LCD's, or fluorescent displays, which provide a relative or digital display.</p>  <p><b>MOTOR</b> A power unit which converts electrical energy into mechanical energy, especially rotary motion.</p> 


 <p><b>RELAY</b>          1. <b>NORMALLY CLOSED</b>          2. <b>NORMALLY OPEN</b></p>	 <p><b>SPEAKER</b>          An electromechanical device which creates sound waves from current flow.</p>
 <p><b>RELAY, DOUBLE THROW</b>          A relay which passes current through one set of contacts or the other.</p>	<p><b>SWITCH, MANUAL</b>          Open and closes circuits, thereby stopping (1) or allowing (2) current flow.</p>  <p>1. <b>NORMALLY OPEN</b>          2. <b>NORMALLY CLOSED</b></p>
 <p><b>RESISTOR</b>          An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.</p>	<p><b>SWITCH, DOUBLE THROW</b>          A switch which continuously passes current through one set of contacts or the other.</p> 
 <p><b>RESISTOR, TAPPED</b>          A resistor which supplies two or more different non adjustable resistance values.</p>	<p><b>SWITCH, IGNITION</b>          A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational.</p> 
 <p><b>RESISTOR, VARIABLE or RHEOSTAT</b>          A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.</p>	<p><b>SENSOR (Thermistor)</b>          A resistor which varies its resistance with temperature.</p> 
 <p><b>SENSOR, SPEED</b>          Uses magnetic impulses to open and close a switch to create a signal for activation of other components.  <small>(Reed Switch Type)</small></p>	<p><b>SWITCH, WIPER PARK</b>          Automatically returns wipers to the stop position when the wiper switch is turned off.</p> 
 <p><b>SHORT PIN</b>          Used to provide an unbroken connection within a junction block.</p>	<p><b>TRANSISTOR</b>          A solid state device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base."</p> 
 <p><b>SOLENOID</b>          An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc.</p>	<p><b>WIRES</b>          Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined; crossed wires (2) and a black dot or octagonal (O) mark at the junction as spliced (joined) connections.</p>  <p>(1) <b>NOT CONNECTED</b>          (2) <b>SPLICED</b></p>

# F RELAY LOCATIONS


## [Engine Compartment]




## [Instrument Panel]



[Body]





[Seat]




# F RELAY LOCATIONS

○ : J/B No. 1      Left Kick Panel (See Page 18)






[J/B No. 1 Inner Circuit]



\*1: Power Main Relay  
 \*2: Taillight Relay


# F RELAY LOCATIONS

② : R/B No. 2	<b>Engine Compartment Left (See Page 18)</b>
○ : J/B No. 2	




- \*1: { 50A AM1 (for Medium Current) (USA)  
60A AM1 (for Medium Current) (CANADA)
- \*2: { HEAD (RH) (USA)  
HEAD (RH-LWR) (CANADA)
- \*3: { HEAD (LH) (USA)  
HEAD (LH-LWR) (CANADA)
- \*4: 30A ABS NO. 2 (for Medium Current)
- \*5: 50A MAIN (for Medium Current)

④ : R/B No. 4      Left Kick Panel (See Page 18)




⑤ : R/B No. 5      Engine Compartment Right (See Page 18)



# G ELECTRICAL WIRING ROUTING

## Position of Parts in Engine Compartment

[2JZ-GTE]



- A 1 A/C Ambient Temp Sensor
- A 2 A/C Condensor Fan Motor
- A 3 A/C Triple Pressure SW  
(A/C Dual and Single Pressure SW)
- A 4 A/C Magnetic Clutch and Lock Sensor
- A 5 A/T Fluid Temp. Sensor
- A 6 ABS Actuator
- A 7 ABS Actuator
- A10 ABS Speed Sensor Front LH
- A11 ABS Speed Sensor Front RH

- B 1 Back-Up Light SW (M/T)
- B 2 Brake Fluid Level Warning SW

- C 1 Camshaft Position Sensor No.1
- C 2 Camshaft Position Sensor No.2
- C 3 Crankshaft Position Sensor
- C 4 Cruise Control Actuator

- D 1 Data Link Connector 1
- D 2 Daytime Running Light Relay No.3
- D 3 Daytime Running Light Relay No.3

- E 1 EGR Gas Temp. Sensor
- E 2 Electronically Controlled Transmission Solenoid
- E 3 Engine Coolant Temp. Sensor

- E 4 Engine Coolant Temp. Sender
- E 5 Engine Coolant Temp. SW
- E 6 Engine Hood Courtesy SW
- E 7 Engine Oil Level Sensor


- F 3 Front Fog Light LH
- F 4 Front Fog Light RH
- F 5 Front Side Marker Light LH
- F 6 Front Side Marker Light RH
- F 7 Front Turn Signal Light LH
- F 8 Front Turn Signal Light RH and Parking Light RH
- F 9 Front Wiper Motor

- G 1 Generator
- G 2 Generator

- H 1 Headlight Hi LH
- H 2 Headlight Hi RH
- H 3 Headlight Lo LH
- H 4 Headlight Lo RH
- H 5 Heated Oxygen Sensor (Bank 1 Sensor 1)
- H 8 Horn LH
- H 9 Horn RH

## Position of Parts in Engine Compartment

### [2JZ-GTE]




- |   |  |
|---|--|
| I 1 Idle Air Control Valve  | R 1 Radiator Fan Motor No.1  |
| I 2 Igniter   | R 2 Radiator Fan Relay No.1  |
| I 3 Igniter   | R 3 Radiator Fan Relay No.2  |
| I 6 Ignition Coil No.1  | R20 Radiator Fan Motor No.2  |
| I 7 Ignition Coil No.2  | S 1 SFI Resistor   |
| I 8 Ignition Coil No.3  | S 2 Starter  |
| I 9 Ignition Coil No.4  | S 3 Starter  |
| I10 Ignition Coil No.5  | S 5 Sub Throttle Position Sensor                                       |
| I11 Ignition Coil No.6  | S18 Sub Throttle Valve Motor   |
| I12 Injector No.1   | T 1 Theft Deterrent Horn   |
| I13 Injector No.2   | T 2 Throttle Position Sensor   |
| I14 Injector No.3   | T14 Turbo Pressure Sensor  |
| I15 Injector No.4   | V 2 VSV (EGR)  |
| I16 Injector No.5   | V 3 VSV (EVAP)   |
| I17 Injector No.6   | V 4 VSV (Exhaust Bypass Valve)   |
| K 1 Knock Sensor (on Front Side)  | V 5 VSV (Exhaust Gas Control Valve)                                    |
| K 2 Knock Sensor (on Rear Side)   | V 6 VSV (Fuel Pressure Up)   |
| M 1 Mass Air Flow Meter   | V 7 VSV (Intake Air Control Valve)                                     |
| N 1 Noise Filter  | V 8 VSV (Waste Gate Valve)   |
| O 1 O/D Direct Clutch Speed Sensor  | V10 Vehicle Speed Sensor No.1 (Combination Meter)                      |
| O 2 Oil Pressure SW   | V11 Vehicle Speed Sensor No.2 (Electronically Controlled Transmission) |
| P 1 PPS Solenoid  | W 1 Washer Motor   |
| P 2 Park/Neutral Position SW, Back-Up Light SW and A/T Indicator Light SW (A/T) |  |
| P13 Parking Light LH  |  |

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Engine Compartment

[2JZ-GE]




- A 1 A/C Ambient Temp. Sensor
- A 3 A/C Dual Pressure SW
- A 4 A/C Magnetic Clutch and Lock Sensor
- A 5 A/T Fluid Temp. Sensor
- A 6 ABS Actuator
- A 7 ABS Actuator
- A 8 ABS Relay
- A 9 ABS Relay
- A10 ABS Speed Sensor Front LH
- A11 ABS Speed Sensor Front RH
  
- B 1 Back-Up Light SW (M/T)
- B 2 Brake Fluid Level Warning SW
  
- C 3 Crankshaft Position Sensor
- C 4 Cruise Control Actuator
  
- D 1 Data Link Connector 1
- D 4 Distributor

- E 1 EGR Gas Temp. Sensor
- E 2 Electronically Controlled Transmission Solenoid
- E 3 Engine Coolant Temp. Sensor
- E 4 Engine Coolant Temp. Sender
- E 6 Engine Hood Courtesy SW
- E 7 Engine Oil Level Sensor
  
- F 3 Front Fog Light LH
- F 4 Front Fog Light RH
- F 5 Front Side Marker Light LH
- F 6 Front Side Marker Light RH
- F 7 Front Turn Signal Light LH
- F 8 Front Turn Signal Light RH and Parking Light RH
- F 9 Front Wiper Motor
  
- G 1 Generator
- G 2 Generator



## Position of Parts in Engine Compartment

**[2JZ-GE]**



H 1 Headlight Hi LH  
 H 2 Headlight Hi RH  
 H 3 Headlight Lo LH  
 H 4 Headlight Lo RH  
 H 8 Horn LH  
 H 9 Horn RH

I 1 Idle Air Control Valve  
 I 4 Igniter  
 I 5 Ignition Coil  
 I 12 Injector No.1  
 I 13 Injector No.2  
 I 14 Injector No.3  
 I 15 Injector No.4  
 I 16 Injector No.5  
 I 17 Injector No.6

K 1 Knock Sensor (on Front Side)  
 K 2 Knock Sensor (on Rear Side)

M 1 Mass Air Flow Meter  
 M 2 Main Heated Oxygen Sensor (Bank 1 Sensor 1)  
 M 3 Main Heated Oxygen Sensor (Bank 2 Sensor 1)

N 1 Noise Filter

O 2 Oil Pressure SW

P 1 PPS Solenoid  
 P 2 Park/Neutral Position SW, Back-Up Light SW and  
 A/T Indicator Light SW (A/T)  
 P 3 Power Steering Pressure SW  
 P13 Parking Light LH

S 2 Starter  
 S 3 Starter


T 1 Theft Deterrent Horn  
 T 2 Throttle Position Sensor

V 1 VSV (ACIS)  
 V 2 VSV (EGR)  
 V 3 VSV (EVAP)  
 V 6 VSV (Fuel Pressure Up)  
 V10 Vehicle Speed Sensor No.1 (Combination Meter)  
 V11 Vehicle Speed Sensor No.2 (Electronically  
 Controlled Transmission)

W 1 Washer Motor

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Instrument Panel




- A12 A/C Amplifier
- A13 A/C Amplifier
- A14 A/C Amplifier
- A15 A/C Evaporator Temp. Sensor
- A16 A/C Room Temp. Sensor
- A17 A/C Solar Sensor
- A18 ABS ECU
- A19 ABS ECU
- A20 ABS ECU
- A21 ABS ECU
- A23 ABS Deceleration Sensor
- A24 Air Inlet Control Servo Motor
- A25 Air Mix Control Servo Motor
- A26 Air Vent Mode Control Servo Motor
- A27 Airbag Squib (Steering Wheel Pad)
- A28 Airbag Squib (Front Passenger Airbag Assembly)
- A29 Ashtray Illumination
- A30 Auto Antenna Control Relay
- A34 Airbag Sensor
- B 3 Blower Motor
- B 4 Blower Motor Control Relay

- B 5 Blower Motor Control Relay
- B 6 Buckle SW LH
- B 7 Buckle SW RH
- C 6 Cigarette Lighter
- C 7 Cigarette Lighter Illumination
- C 8 Clock
- C 9 Clutch Start SW
- C10 Combination Meter
- C11 Combination Meter
- C12 Combination Meter
- C13 Combination SW
- C14 Combination SW
- C15 Cruise Control Clutch SW
- C16 Cruise Control ECU
- D 5 Data Link Connector 2
- D 6 Daytime Running Light Relay (Main)
- D 7 Diode (Interior Light)
- D 8 Diode (Idle-Up)
- D17 Data Link Connector 3

\*1: 2JZ-GTE  
\*2: 2JZ-GE

## Position of Parts in Instrument Panel



E 8 Electronically Controlled Transmission Pattern Select SW

E 9 Engine Control Module

E10 Engine Control Module

E11 Engine Coolant Temp. Sensor (A/C System)

F10 Front Tweeter (Speaker) LH

F11 Front Tweeter (Speaker) RH

G 3 Glove Box Light

G 4 Glove Box Light SW

H10 Hazard SW

H11 Heated Oxygen Sensor (Bank 1 Sensor 2)

H12 Heater Control SW

H13 Heater Control SW

I18 Ignition Key Cylinder Light

I19 Ignition SW

I20 Integration Relay

J 1 Junction Connector

J 2 Junction Connector

K 4 Kick Down SW

N 2 Noise Filter

O 5 O/D Main SW and A/T Indicator Illumination

P 4 PPS ECU

P 5 Parking Brake SW

R 4 Radio and Player (w/o Stereo Power Amplifier)

R 5 Radio and Player (w/o Stereo Power Amplifier)

R 6 Radio and Player (w/ Stereo Power Amplifier)

R 7 Remote Control Mirror SW

R 8 Rheostat

S 6 Seat Heater SW

S 7 Shift Lock ECU

S 8 Stereo Power Amplifier

S 9 Stereo Power Amplifier

S10 Stereo Power Amplifier

S11 Stop Light SW

S16 Sub Heated Oxygen Sensor (Bank 1 Sensor 2)

T 5 Telltale Light LH

T 6 Telltale Light RH

T 7 Theft Deterrent and Door Lock Control ECU

T 8 Traction Control SW

T13 Theft Deterrent and Door Lock Control ECU


T15 Throttle ECU

T16 Throttle ECU

U 1 Unlock Warning SW

# G ELECTRICAL WIRING ROUTING

## Position of Parts in Body



A31 ABS Speed Sensor Rear LH  
 A32 ABS Speed Sensor Rear RH  
 A33 Auto Antenna Motor

D10 Door Courtesy SW LH  
 D11 Door Courtesy SW RH  
 D12 Door Key Lock and Unlock SW LH  
 D13 Door Key Lock and Unlock SW RH  
 D14 Door Lock Control SW RH  
 D15 Door Lock Motor and Door Unlock Detection SW LH  
 D16 Door Lock Motor and Door Unlock Detection SW RH

F12 Front Door Speaker LH  
 F13 Front Door Speaker RH  
 F14 Fuel Pump and Sender  
 F15 Fuel Pump ECU

H14 High Mounted Stop Light

L 1 License Plate Light  
 L 2 Light Failure Sensor  
 L 3 Luggage Compartment Key Unlock SW  
 L 4 Luggage Compartment Light  
 L 5 Luggage Compartment Light SW


N 3 Noise Filter

P 6 Personal Light  
 P 7 Power Window Control SW RH  
 P 8 Power Window Master SW and Door Lock Control SW LH  
 P 9 Power Window Motor LH  
 P10 Power Window Motor RH

R 9 Rear Combination Light LH  
 R10 Rear Combination Light RH  
 R11 Rear Side Marker Light LH  
 R12 Rear Side Marker Light RH  
 R13 Rear Speaker LH  
 R14 Rear Speaker RH  
 R15 Rear Wiper Motor and Relay  
 R16 Remote Control Mirror and Mirror Heater LH  
 R17 Remote Control Mirror and Mirror Heater RH  
 R18 Rear Window Defogger (+)  
 R19 Rear Window Defogger (-)

T11 Tension Reducer Solenoid LH  
 T12 Tension Reducer Solenoid RH

W2 Woofer (Speaker)

**Position of Parts in Seat**


P11 Power Seat Control SW (Driver's Seat)  
P12 Power Seat Motor (Driver's Seat Slide Control)  
S12 Seat Heater (Driver's Seat)

S13 Seat Heater (Front Passenger's Seat)  
S14 Seat Heater Relay (Driver's Seat)  
S15 Seat Heater Relay (Front Passenger's Seat)


# G ELECTRICAL WIRING ROUTING

- : Location of Connector Joining Wire Harness and Wire Harness
- ▽ : Location of Ground Points


[2JZ-GTE]



- : Location of Splice Points



## Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO.2)
EA2	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO.2)


# G ELECTRICAL WIRING ROUTING

□ : Location of Connector Joining Wire Harness and Wire Harness  
▽ : Location of Ground Points

[2JZ-GE]




○ : Location of Splice Points






Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO.2)
EA3	

# G ELECTRICAL WIRING ROUTING


**□** : Location of Connector Joining Wire Harness and Wire Harness



**▽** : Location of Ground Points




## Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB2	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IB4	
IB5	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB6	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IC1	FLOOR NO.2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IC2	FLOOR NO.2 WIRE AND COWL WIRE (RIGHT KICK PANEL)
ID1	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE1	INSTRUMENT PANEL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)
IF1	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT RH)
IF3	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)

# G ELECTRICAL WIRING ROUTING


**□ : Location of Connector Joining Wire Harness and Wire Harness**



**○ : Location of Splice Points**




## Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG1	INSTRUMENT PANEL WIRE AND COWL NO.3 WIRE (BEHIND HEATER CONTROL SW)
IH1	
IH2	INSTRUMENT PANEL WIRE AND CONSOLE BOX WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)
IH3	
II1	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	
IJ2	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IK1	COWL NO.4 WIRE AND COWL WIRE (RIGHT KICK PANEL)
IL1	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

# G ELECTRICAL WIRING ROUTING


□ : Location of Connector Joining Wire Harness and Wire Harness  
 ▽ : Location of Ground Points



○ : Location of Splice Points




## Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
BM1	BACK DOOR NO. 1 WIRE AND FLOOR NO.2 WIRE (LEFT SIDE OF PACKAGE TRAY TRIM)
BO1	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE (BACK DOOR UPPER LEFT)
BP1	FUEL GAUGE WIRE AND FLOOR NO.2 WIRE (LUGGAGE ROOM FRONT LH)

## G ELECTRICAL WIRING ROUTING

**□** : Location of Connector Joining Wire Harness and Wire Harness




**○** : Location of Splice Points










## Connector Joining Wire Harness and Wire Harness




CODE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
BQ1	FLOOR NO. 2 WIRE AND SEAT WIRE (UNDER THE FRONT LH SEAT)









- \*1 : CANADA
- \*2 : USA
- \*3 : 2JZ- GTE
- \*4 : 2JZ- GE
- \*5 : W/ STEREO POWER AMPLIFIER
- \*6 : W/O STEREO POWER AMPLIFIER

 : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
J1	29	J2	29		

 : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO. 4 (LEFT KICK PANEL)
5	23	R/B NO. 5 (ENGINE COMPARTMENT RIGHT)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1D	20	FRONT DOOR LH WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1F	20	ROOF WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1G	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H		
1J		
1K		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB5	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IC1	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IK1	38	COWL NO. 4 WIRE AND COWL WIRE (RIGHT KICK PANEL)
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE
BM1	40	BACK DOOR NO. 1 WIRE AND FLOOR NO. 2 WIRE (LEFT SIDE OF PACKAGE TRAY TRIM)
BO1	40	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE
BP1	40	FUEL GAUGE WIRE AND FLOOR NO. 2 WIRE (LUGGAGE ROOM FRONT LH)
BQ1	42	FLOOR NO. 2 WIRE AND SEAT WIRE (UNDER THE FRONT LH SEAT)

 : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
EC	32 (2JZ-GTE)	FRONT SIDE OF INTAKE MANIFOLD
	34 (2JZ-GE)	
ED	32 (2JZ-GTE)	REAR SIDE OF INTAKE MANIFOLD
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL
IF		
IG	36	RIGHT KICK PANEL
IH		
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER
BK	40	RIGHT SIDE OF HIGH MOUNTED STOP LIGHT



**: SPLICE POINTS**


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	I10	38	COWL WIRE
E5			I11		
E7			I14		
E9			I17		
E14	32	ENGINE WIRE	I18	38	COWL WIRE
E18	34	ENGINE ROOM MAIN WIRE	I21	38	INSTRUMENT PANEL WIRE
E19			I23	38	COWL WIRE
E20			I24		
E21			I25	38	INSTRUMENT PANEL WIRE
E24	34	ENGINE WIRE	B1	40	FRONT DOOR LH WIRE
E27			B2	40	FRONT DOOR RH WIRE
E28			B3	40	FLOOR NO. 2 WIRE
I1			B4		
I2	38	COWL WIRE	B5	40	FLOOR NO. 2 WIRE
I3	38	INSTRUMENT PANEL WIRE	B6		
I4	38	COWL WIRE	B7		
I7	38	FLOOR NO. 2 WIRE	B9	42	SEAT WIRE
I8	38	INSTRUMENT PANEL WIRE	B10	40	BACK DOOR NO. 2 WIRE
I9	38	COWL WIRE			

J 1



(HINT : SEE PAGE 7)

J 2





(HINT : SEE PAGE 7)

# H POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.



The next page and following pages show the parts to which each electrical source outputs current.



\* These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: J/B No. 1 (See page 20) ②: R/B No.2 (See page 22)





③: R/B No. 4 (See page 23)

# H POWER SOURCE (Current Flow Chart)

\*1: (CANADA)

\*2: (USA)

Location	*Page Nos. of Related Systems	228	228	228	159 164	159	159	228	208 228	159	159	164	164	228	122	210	210	197	116	220	228	206	206		
	Parts	A/C Condenser Fan Motor	A/C Single Pressure SW	A/C Triple Pressure SW	A/C Magnetic Clutch and Lock Sensor	ABS Actuator	ABS Relay	A/C Amplifier	ABS ECU	Air Inlet Control Servo Motor	Ashtray Illumination	Auto Antenna Control Relay	Auto Antenna Motor	Airbag Sensor Assembly	Back-Up Light SW (M/T)	Brake Fluid Level Warning SW	Blower Motor Control Relay	Buckle SW LH	Buckle SW RH						
	Code or Location	A 2	A 3	A 4	A 6	A 8	A 9	A 12	A 14	A 18	A 19	A 20	A 21	A 24	A 29	A 30	A 33	A 34	B 1	B 2	B 4	B 6	B 7		
CB or Fuse																									
7.5A HTR		●	●					●	●						●										
7.5A IGN																			●						
7.5A OBD-II																									
7.5A RAD NO.2																			●						
7.5A ST																									
7.5A TURN																									
10A ECU-B									●										●						
10A ECU-IG									●				●										●	●	
10A GAUGE					●		●		●	●	●	●	●							●	●				
10A MIR-HTR																									
10A PANEL																			●						
10A TAIL																									
15A CIG									●																
15A SEAT-HTR																			●						
15A STOP										●				●											
20A WIPER																									
30A DEFOG																									
30A DOOR																									
7.5A ALT-S																									
7.5A DOME																									
7.5A DRL																									
7.5A TRAC																									
15A FOG																									
15A HAZ-HORN																									
15A HEAD (LH) *2																									
15A HEAD (LH-LWR) *1																									
15A HEAD (LH-UPR) *1																									
15A HEAD (RH) *2																									
15A HEAD (RH-LWR) *1																									
15A HEAD (RH-UPR) *1																									
20A RAD NO.1																			●	●					
30A EFI NO.1																									
30A EFI NO.2																									
30A FAN		●																		●					
50A HTR																						●			
60A ABS NO.1					●	●	●					●	●	●											

\* These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①:J/B No. 1 (See page 20) ②:R/B No.2 (See page 22) ③:R/B No.4 (See page 23)

186	122	186	60, 64 70, 82 130, 220	140 150 169 174 220	122	70 82 181 228	111	140 150 220	220	94 96	111	94	106	129	111	126	203	174	140 150 174	70, 82 140, 150 159, 164 197	96	96	70 140 169 174 197	96 220	118	70 82	
Cigarette Lighter	Cigarette Lighter Illumination	Clock	Clutch Start SW	Combination Meter	Meter Illumination [Comb. Meter]	Speedometer [Comb. Meter]	Turn Signal Indicator Light [Comb. Meter]	Combination Meter	High Beam Indicator Light [Comb. Meter]	Turn Signal Indicator Light [Comb. Meter]	Dimmer SW [Comb. SW]	Fog Light SW [Comb. SW]	Horn SW [Comb. SW]	Turn Signal SW [Comb. SW]	Front Wiper and Washer SW [Comb. SW]	Rear Wiper and Washer SW [Comb. SW]	Cruise Control Clutch SW	Cruise Control ECU	Data Link Connector 1	Daytime Running Light Relay No.3	Data Link Connector 2	Daytime Running Light Relay (Main)	Diode (Interior Light)	Diode (Idle-Up)			
C 6	C 7	C 8	C 9	C 10			C 11	C 12		C 13			C 14		C 15	C 16	D 1	D 2	D 3	D 5	D 6	D 7	D 8				

④:R/B No. 5 (See page 23)

# H POWER SOURCE (Current Flow Chart)

Location	*Page Nos. of Related Systems		Parts																			
	Code or Location		CB or Fuse																			
	118	118	70 82	140	220	228	220	122	60, 64 70, 82 140, 150	70, 82 140, 150 220, 228	106	106	102	102	111	102 111	126	220	70 82			
			Door Courtesy SW LH	Door Courtesy SW RH	Data Link Connector 3	Electronically Controlled Transmission Solenoid	Engine Coolant Temp. Sender	Engine Coolant Temp. SW	Engine Oil Level Sensor	Electronically Controlled Transmission Pattern Select SW	Engine Control Module	Front Fog Light LH	Front Fog Light RH	Front Side Marker Light LH	Front Side Marker Light RH	Front Turn Signal Light LH	Front Turn Signal Light RH and Parking Light RH	Front Wiper Motor	Fuel Pump and Sender	Fuel Pump ECU		
			D10	D11	D17	E 2	E 4	E 5	E 7	E 8	E 9	E 10	F 3	F 4	F 5	F 6	F 7	F 8	F 9	F 14	F 15	
7.5A	HTR							●				●										
7.5A	IGN											●										
7.5A	OBD-II			●																		
7.5A	RAD NO.2																					
7.5A	ST										●											
7.5A	TURN																●	●				
10A	ECU-B																					
10A	ECU-IG								●												●	
10A	GAUGE						●					●										
10A	MIR-HTR											●										
10A	PANEL									●		●										
10A	TAIL														●	●		●				
15A	CIG																					
15A	SEAT-HTR																					
15A	STOP											●										
20A	WIPER																		●			
30A	DEFOG																					
30A	DOOR																					
7.5A	ALT-S		●	●																		
7.5A	DOME		●	●																		
7.5A	DRL																					
7.5A	TRAC																					
15A	FOG												●	●								
15A	HAZ-HORN																●	●				
15A	HEAD (LH) *2																					
15A	HEAD (LH-LWR) *1																					
15A	HEAD (LH-UPR) *1																					
15A	HEAD (RH) *2																					
15A	HEAD (RH-LWR) *1																					
15A	HEAD (RH-UPR) *1																					
20A	RAD NO.1																					
30A	EFI NO.1					●					●	●										●
30A	EFI NO.2																					●
30A	FAN																					
50A	HTR																					
60A	ABS NO.1																					

\* These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: J/B No. 1 (See page 20) ②: R/B No.2 (See page 22) ③: R/B No. 4 (See page 23)

68 220	122	122	94 96	94 96	94 96	94 96	70	129	129	111 122	70	122 228	114	70 82	118	102	102 114 220	118	118	70, 82 140, 150	82	82	220	122 140 150	60, 64 70, 82 116, 130 140, 150 174, 220	181	
Generator	Glove Box Light	Glove Box Light SW	Headlight Hi LH	Headlight Hi RH	Headlight Lo LH	Headlight Lo RH	Heated Oxygen Sensor (Bank 1 Sensor 1)	Horn LH	Horn RH	Hazard SW	Heated Oxygen Sensor (Bank 1 Sensor 2)	Heater Control SW	High Mounted Stop Light	Idle Air Control Valve	Ignition Key Cylinder Light	License Plate Light	Light Failure Sensor	Luggage Compartment Light	Luggage Compartment Light SW	Mass Air Flow Meter	Main Heated Oxygen Sensor (Bank 1 Sensor 1)	Main Heated Oxygen Sensor (Bank 2 Sensor 1)	Oil Pressure SW	O/D Main SW and A/T Indicator Illumination	Park/Neutral Position SW, Back-Up Light SW and A/T Indicator Light SW (A/T)	PPS ECU	
G 2	G 3	G 4	H 1	H 2	H 3	H 4	H 5	H 8	H 9	H 10	H 11	H 12	H 14	I 1	I 18	L 1	L 2	L 4	L 5	M 1	M 2	M 3	O 2	O 5	P 2	P 4	
●												●															
										●																●	
●											●						●						●		●		●
	●	●									●						●										
		●									●						●										
													●														

④: R/B No. 5 (See page 23)

# H POWER SOURCE (Current Flow Chart)

Location	*Page Nos. of Related Systems																						
	Parts																						
	Code or Location																						
CB or Fuse	Parking Brake SW	Personal Light	Power Window Control SW RH	Power Window Master SW and Door Lock Control SW LH	Power Window Motor LH	Power Window Motor RH	Power Seat Control SW (Driver's Seat)	Power Seat Motor (Driver's Seat Slide Control)	Parking Light LH	Radiator Fan Motor No.1	Radiator Fan Relay No.1	Radiator Fan Relay No.2	Radio and Player (w/o Stereo Power Amplifier)	Radio and Player (w/ Stereo Power Amplifier)	Remote Control Mirror SW	Rheostat	Back-Up Light LH (Rear Comb. Light LH)	Rear Turn Signal Light LH (Rear Comb. Light LH)	Stop Light LH (Rear Comb. Light LH)	Tailight LH (Rear Comb. Light LH)	Back-Up Light RH (Rear Comb. Light RH)	Rear Turn Signal Light RH (Rear Comb. Light RH)	
	P 5	P 6	P 7	P 8	P 9	P10	P11	P12	P13	R 1	R 2	R 3	R 4	R 6	R 7	R 8	R 9				R10		
7.5A HTR											●	●											
7.5A IGN																							
7.5A OBD-II																							
7.5A RAD NO.2													●		●								
7.5A ST																							
7.5A TURN																			●				●
10A ECU-B																							
10A ECU-IG																							
10A GAUGE	●																	●				●	
10A MIR-HTR																							
10A PANEL													●	●		●							
10A TAIL									●											●			
15A CIG																							
15A SEAT-HTR																							
15A STOP																			●				
20A WIPER																							
30A DEFOG																							
30A DOOR			●	●	●	●	●	●															
7.5A ALT-S		●																					
7.5A DOME																							
7.5A DRL																							
7.5A TRAC																							
15A FOG																							
15A HAZ-HORN																			●				●
15A HEAD (LH) *2																							
15A HEAD (LH-LWR) *1																							
15A HEAD (LH-UPR) *1																							
15A HEAD (RH) *2																							
15A HEAD (RH-LWR) *1																							
15A HEAD (RH-UPR) *1																							
20A RAD NO.1													●										
30A EFI NO.1																							
30A EFI NO.2																							
30A FAN										●	●	●											
50A HTR																							
60A ABS NO.1																							

\* These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: J/B No. 1 (See page 20) ②: R/B No. 2 (See page 22) ③: R/B No.4 (See page 23)

114	102	102	102	203	188 208	188 208	228	122 192	184	210 214	70, 82 114, 140 150, 159 164, 174 184	192	192	192	192	82	130	159 164	70 82	169 220	68	118	102 114	194	197	70, 82 122, 140 150, 174 181, 220 228	
Stop Light RH [Rear Comb. Light RH]	Taillight RH [Rear Comb. Light RH]	Rear Side Marker Light LH	Rear Side Marker Light RH	Rear Wiper Motor and Relay	Remote Control Mirror and Mirror Heater LH	Remote Control Mirror and Mirror Heater RH	Radiator Fan Motor No.2	Seat Heater SW	Shift Lock ECU	Stereo Power Amplifier	Stop Light SW	Seat Heater (Driver's Seat)	Seat Heater (Front Passenger's Seat)	Seat Heater Relay (Driver's Seat)	Seat Heater Relay (Front Passenger's Seat)	Sub Heated Oxygen Sensor (Bank 1 Sensor 2)	Theft Deterrent Horn	ABS Warning Light [Telltale Light LH]	Malfunction Indicator Lamp [Telltale Light LH]	Telltale Light LH	Charge Warning Light [Telltale Light RH]	Open Door Warning Light [Telltale Light RH]	Rear Light Warning Light [Telltale Light RH]	Seat Belt Warning Light [Telltale Light RH]	SRS Warning Light [Telltale Light RH]	Telltale Light RH	
R10	R11	R12	R15	R16	R17	R20	S6	S7	S8	S11	S12	S13	S14	S15	S16	T1	T5			T6							
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

④: R/B No. 5 (See page 23)

# H POWER SOURCE (Current Flow Chart)

\*1: (CANADA)

\*2: (USA)

Location	CB or Fuse	*Page Nos. of Related Systems																				
		Theft Deterrent and Door Lock Control ECU	Traction Control SW	Tension Reducer Solenoid LH	Tension Reducer Solenoid RH	Theft Deterrent and Door Lock Control ECU	Throttle ECU	VSV (ACIS)	VSV (EGR)	VSV (EVAP)	VSV (Exhaust Bypass Valve)	VSV (Exhaust Gas Control Valve)	VSV (Fuel Pressure Up)	VSV (Intake Air Control Valve)	VSV (Waste Gate Valve)	Vehicle Speed Sensor No.1 (Combination Meter)	Washer Motor	Diode	Integration Relay	Power Main Relay (Point Side)	Power Main Relay (Coil Side)	
		T 7	T 8	T 11	T 12	T 13	T 15	T 16	V 1	V 2	V 3	V 4	V 5	V 6	V 7	V 8	V 10	W 1	①			
7.5A	HTR																					
7.5A	IGN																					
7.5A	OBD-II																					
7.5A	RAD NO.2																					
7.5A	ST					●																
7.5A	TURN																					
10A	ECU-B																					
10A	ECU-IG	●		●	●																	●
10A	GAUGE																					
10A	MIR-HTR																					
10A	PANEL		●																			
10A	TAIL																					
15A	CIG	●																				
15A	SEAT-HTR																					
15A	STOP																					
20A	WIPER																					
30A	DEFOG																					
30A	DOOR	●																				
7.5A	ALT-S																					
7.5A	DOME					●																
7.5A	DRL																					
7.5A	TRAC																					
15A	FOG																					
15A	HAZ-HORN					●																
15A	HEAD (LH) *2																					
15A	HEAD (LH-LWR) *1																					
15A	HEAD (LH-UPR) *1																					
15A	HEAD (RH) *2																					
15A	HEAD (RH-LWR) *																					
15A	HEAD (RH-UPR) *1																					
20A	RAD NO.1																					
30A	EFI NO.1						●		●	●	●	●	●	●	●	●						
30A	EFI NO.2																					
30A	FAN																					
50A	HTR																					
60A	ABS NO.1																					


\* These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.


[LOCATION] ①: J/B No. 1 (See page 20) ②: R/B No.2 (See page 22) ③: R/B No.4 (See page 23)













# POWER SOURCE

## SERVICE HINTS

### HEADLIGHT RELAY (USA)

2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION

### HEADLIGHT RELAY (CANADA)

2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION

: CLOSED WITH THE ENGINE RUNNING AND THE PARKING BRAKE LEVER RELEASED (PARKING BRAKE SW OFF)

### TAILLIGHT RELAY

5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

### I19 IGNITION SW

2-3 : CLOSED WITH THE IGNITION KEY AT **ACC** OR **ON** POSITION

2-4 : CLOSED WITH THE IGNITION KEY AT **ON** OR **ST** POSITION

7-6 : CLOSED WITH THE IGNITION KEY AT **ON** OR **ST** POSITION

7-8 : CLOSED WITH THE IGNITION KEY AT **ST** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
I19	29				

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO.2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO.4 (LEFT KICK PANEL)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)
2B	22	ENGINE ROOM MAIN WIRE AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)


## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E7	32	ENGINE ROOM MAIN WIRE	E20	34	ENGINE ROOM MAIN WIRE


I19








# STARTING AND IGNITION (2JZ-GTE)









# STARTING AND IGNITION (2JZ-GTE)

## SERVICE HINTS

### I19 IGNITION SW

- 7-8 : CLOSED WITH THE IGNITION SW AT **ST** POSITION
- 7-6 : CLOSED WITH THE IGNITION SW AT **ON** OR **ST** POSITION

### P2 PARK/NEUTRAL POSITION SW (A/T)

- 6-5 : CLOSED WITH THE A/T SHIFT LEVER IN **P** OR **N** POSITION

### C9 CLUTCH START SW (M/T)

- 1-2 : CLOSED WITH THE CLUTCH PEDAL FULLY DEPRESSED

### S2 (A), S3 (B) STARTER

- POINTS CLOSED WITH THE PARK/NEUTRAL POSITION SW ON AND THE IGNITION SW AT **ST** POSITION (A/T)
- POINTS CLOSED WITH THE CLUTCH START SW ON AND THE IGNITION SW AT **ST** POSITION (M/T)

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C1	24	I3	B 25	J2	29
C2	24	I6	25	N1	25 (2JZ-GTE)
C3	24 (2JZ-GTE)	I7	25	P2	25 (2JZ-GTE)
C9	28	I8	25	S2	A 25 (2JZ-GTE)
D1	24 (2JZ-GTE)	I9	25	S3	B 25 (2JZ-GTE)
E9	B 29	I10	25	T13	29
E10	A 29	I11	25		
I2	A 25	I19	29		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 ( ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1J	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
IK		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	32(2JZ-GTE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA2	32	
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB2		
IF2	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EC	32 (2JZ-GTE)	FRONT SIDE OF INTAKE MANIFOLD
ED	32 (2JZ-GTE)	REAR SIDE OF INTAKE MANIFOLD

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E11	32	ENGINE WIRE	I4	38	COWL WIRE
E16			I17		
E17			I20		

C 1 BLACK




C 2 BLACK




C 3 DARK GRAY




C 9



E 9 (B) DARK GRAY




E10 (A) DARK GRAY




I 2 (A) BLACK




I 3 (B) BLACK




I 6, I 7, I 8  
I 9, I 10, I 11 BLACK



I19



J 2




(HINT : SEE PAGE 7)


N 1 GRAY



P 2 GRAY




S 2 (A)




S 3 (B) BLACK



T13 ORANGE





**SERVICE HINTS**

**G2 (A) GENERATOR**

- (A) 3-GROUND : **13.9-15.1** VOLTS WITH THE ENGINE RUNNING AT **2000** RPM AND **25•C (77•F)**  
**13.5-14.3** VOLTS WITH THE ENGINE RUNNING AT **5000** RPM AND **115•C (239•F)**
- (A) 1-GROUND ; **0-4** VOLTS WITH THE IGNITION SW AT **ON** POSITION AND THE ENGINE NOT RUNNING

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
G1	B	G2	A	T6	29
	24 (2JZ-GTE) 26 (2JZ-GE)		24 (2JZ-GTE) 26 (2JZ-GE)		

**○ : RELAY BLOCKS**

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**




CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA2	32	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA3	34	
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

**○ : SPLICE POINTS**

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I14	38	INSTRUMENT PANEL WIRE			





## SYSTEM OUTLINE

THE ENGINE CONTROL SYSTEM UTILIZES A MICROCOMPUTER AND MAINTAINS OVERALL CONTROL OF THE ENGINE, TRANSMISSION ETC. AN OUTLINE OF THE ENGINE CONTROL IS GIVEN HERE.

### 1. INPUT SIGNALS

#### (1) ENGINE COOLANT TEMP. SIGNAL CIRCUIT

THE ENGINE COOLANT TEMP. SENSOR DETECTS THE ENGINE COOLANT TEMP. WHICH IS INPUT INTO **TERMINAL THW** OF THE ENGINE CONTROL MODULE AS A CONTROL SIGNAL.

#### (2) INTAKE AIR TEMP. SIGNAL CIRCUIT

THE INTAKE AIR TEMP. SENSOR IS INSTALLED IN THE MASS AIR FLOW METER AND DETECTS THE INTAKE AIR TEMP. WHICH IS INPUT AS A CONTROL SIGNAL TO **TERMINAL THA** OF THE ENGINE CONTROL MODULE.

#### (3) OXYGEN DENSITY SIGNAL CIRCUIT

THE OXYGEN DENSITY IN THE EXHAUST EMISSION IS DETECTED BY THE HEATED OXYGEN SENSOR SIDE AND INPUT AS A CONTROL SIGNAL TO **TERMINAL OX1, OXS** OF THE ENGINE CONTROL MODULE.

#### (4) RPM SIGNAL CIRCUIT

CRANKSHAFT POSITION IS DETECTED BY THE CRANKSHAFT POSITION SENSOR. CRANKSHAFT POSITION IS INPUT AS A CONTROL SIGNAL TO **TERMINAL NE** OF THE ENGINE CONTROL MODULE.

#### (5) THROTTLE POSITION SIGNAL CIRCUIT

THE THROTTLE POSITION SENSOR DETECTS THE THROTTLE VALVE OPENING ANGLE AS A CONTROL SIGNAL, WHICH IS INPUT INTO **TERMINAL VTA1** OF THE ENGINE CONTROL MODULE. WHEN THE VALVE IS COMPLETELY CLOSED, THE CONTROL SIGNAL IS INPUT INTO **TERMINAL IDL1**.

#### (6) VEHICLE SPEED CIRCUIT

THE VEHICLE SPEED IS DETECTED BY VEHICLE SPEED SENSOR NO. 1 INSTALLED IN THE TRANSMISSION AND THE SIGNAL IS INPUT TO **TERMINAL SP1** OF THE ENGINE CONTROL MODULE VIA THE COMBINATION METER.

#### (7) NEUTRAL POSITION SIGNAL CIRCUIT

THE PARK/NEUTRAL POSITION SW DETECTS WHETHER THE SHIFT POSITION IS IN "N" AND "P" OR NOT, AND THE SIGNAL IS INPUT INTO **TERMINAL NSW** OF THE ENGINE CONTROL MODULE.

#### (8) A/C SW SIGNAL CIRCUIT

THE OPERATING VOLTAGE OF THE A/C MAGNETIC CLUTCH IS DETECTED AND THE SIGNAL IS INPUT INTO **TERMINAL ACMG** OF ENGINE CONTROL MODULE AS A CONTROL SIGNAL.

#### (9) BATTERY SIGNAL CIRCUIT

VOLTAGE IS CONSTANTLY APPLIED TO **TERMINAL BATT** OF THE ENGINE CONTROL MODULE. WITH THE IGNITION SW TURNED ON, THE VOLTAGE FOR ENGINE CONTROL MODULE START-UP POWER SUPPLY IS APPLIED TO **TERMINAL +B** OF THE ENGINE CONTROL MODULE VIA EFI MAIN RELAY.

THE CURRENT FLOWING THROUGH THE **IGN** FUSE FLOWS TO **TERMINAL IGSW** OF THE ENGINE CONTROL MODULE.

#### (10) INTAKE AIR VOLUME SIGNAL CIRCUIT

INTAKE AIR VOLUME IS DETECTED BY THE MASS AIR FLOW METER AND THE SIGNAL IS INPUT TO **TERMINAL VG** OF THE ENGINE CONTROL MODULE AS A CONTROL SIGNAL.

#### (11) STOP LIGHT SW SIGNAL CIRCUIT

THE STOP LIGHT SW IS USED TO DETECT WHETHER THE VEHICLE IS BRAKING OR NOT AND THE SIGNAL IS INPUT INTO **TERMINAL STP** OF THE ENGINE CONTROL MODULE AS A CONTROL SIGNAL.

#### (12) STARTER SIGNAL CIRCUIT

TO CONFIRM WHETHER THE ENGINE IS CRANKING THE VOLTAGE APPLIED TO THE STARTER MOTOR DURING CRANKING IS DETECTED AND THE SIGNAL IS INPUT IN **TERMINAL STA** OF THE ENGINE CONTROL MODULE AS A CONTROL SIGNAL.

#### (13) ENGINE KNOCK SIGNAL CIRCUIT

ENGINE KNOCKING IS DETECTED BY KNOCK SENSOR FRONT AND REAR SIDE AND THE SIGNAL IS INPUT **TERMINALS KNK1** AND **KNK2** AS A CONTROL SIGNAL.

## 2. CONTROL SYSTEM

### \* SEQUENTIAL MULTIPOINT FUEL INJECTION SYSTEM

THE SEQUENTIAL MULTIPOINT FUEL INJECTION SYSTEM MONITORS THE ENGINE CONDITION THROUGH THE SIGNALS INPUT FROM EACH SENSOR (INPUT SIGNALS FROM (1) TO (13) ETC.) TO THE ENGINE CONTROL MODULE. THE BEST FUEL INJECTION TIMING IS DECIDED BASED ON THIS DATA AND THE PROGRAM MEMORIZED BY THE ENGINE CONTROL MODULE, AND THE CONTROL SIGNAL IS OUTPUT TO **TERMINALS #10, #20, #30, #40, #50 AND #60** OF THE ENGINE CONTROL MODULE TO OPERATE THE INJECTOR (INJECT THE FUEL). THE SEQUENTIAL MULTIPOINT FUEL INJECTION SYSTEM PRODUCES CONTROLS OF FUEL INJECTION OPERATION BY THE ENGINE CONTROL MODULE IN RESPONSE TO THE DRIVING CONDITIONS.

### \* ESA SYSTEM

THE ESA SYSTEM MONITORS THE ENGINE CONDITION THROUGH THE SIGNALS INPUT TO THE ENGINE CONTROL MODULE FROM EACH SENSOR (INPUT SIGNALS FROM (1), (2), (4) TO (13) ETC.). THE BEST IGNITION TIMING IS DECIDED ACCORDING TO THIS DATA AND THE MEMORIZED DATA IN THE ENGINE CONTROL MODULE AND THE CONTROL SIGNAL IS OUTPUT TO **TERMINALS IGT1, IGT2, IGT3, IGT4, IGT5 AND IGT6** THESE SIGNALS CONTROL THE IGNITER TO PROVIDE THE BEST IGNITION TIMING FOR THE DRIVING CONDITIONS.

### \* HEATED OXYGEN SENSOR HEATER CONTROL SYSTEM

THE MAIN HEATED OXYGEN SENSOR, SUB HEATED OXYGEN SENSOR HEATER CONTROL SYSTEM TURNS THE HEATER ON WHEN THE INTAKE AIR VOLUME IS LOW (TEMP. OF EXHAUST EMISSIONS IS LOW) AND WARMS UP THE OXYGEN SENSOR TO IMPROVE DETECTION PERFORMANCE OF THE SENSOR. THE ENGINE CONTROL MODULE EVALUATES THE SIGNALS FROM EACH SENSOR (INPUT SIGNALS FROM (1), (2), (4), (9) TO (11) ETC.), AND OUTPUTS CURRENT TO **TERMINALS HT1, HTS** TO CONTROL THE HEATER

### \* IDLE AIR CONTROL SYSTEM

THE IDLE AIR CONTROL SYSTEM (STEP MOTOR TYPE) INCREASES THE ENGINE SPEED AND PROVIDES IDLING STABILITY FOR FAST IDLE-UP WHEN THE ENGINE IS COLD, AND WHEN THE IDLE SPEED HAS DROPPED DUE TO ELECTRICAL LOAD AND SO ON. THE ENGINE CONTROL MODULE EVALUATES THE SIGNALS FROM EACH SENSOR (INPUT SIGNALS FROM (1), (4), (5), (8), (9), (11) ETC.), OUTPUTS CURRENT TO **TERMINALS ISC1, ISC2, ISC3 AND ISC4** TO CONTROL THE IDLE AIR CONTROL VALVE.

### \* EGR CONTROL SYSTEM

THE EGR CONTROL SYSTEM DETECTS THE SIGNAL FROM EACH SENSOR (INPUT SIGNALS FROM (1), (4), (9), (10) ETC.), AND OUTPUTS CURRENT TO **TERMINAL EGR** TO CONTROL THE EGR VALVE.

### \* FUEL PUMP CONTROL SYSTEM

THE ENGINE CONTROL MODULE OUTPUTS CURRENT TO **TERMINAL FPC** AND CONTROLS THE FUEL PUMP ECU AND FUEL PUMP DRIVE SPEED IN RESPONSE TO THE DRIVING CONDITIONS

## 3. DIAGNOSIS SYSTEM


WITH THE DIAGNOSIS SYSTEM, WHEN THERE IS A MALFUNCTION IN THE ENGINE CONTROL MODULE SIGNAL SYSTEM, THE MALFUNCTIONING SYSTEM IS RECORDED IN THE MEMORY. THE MALFUNCTIONING SYSTEM CAN BE FOUND BY READING THE CODE DISPLAYED BY THE MALFUNCTION INDICATOR LAMP.


## 4. FAIL-SAFE SYSTEM

WHEN A MALFUNCTION HAS OCCURRED IN ANY SYSTEM, IF THERE IS A POSSIBILITY OF ENGINE TROUBLE BEING CAUSED BY CONTINUED CONTROL BASED ON THE SIGNALS FROM THAT SYSTEM, THE FAIL-SAFE SYSTEM EITHER CONTROLS THE SYSTEM BY USING DATA (STANDARD VALUES) RECORDED IN THE ENGINE CONTROL MODULE MEMORY OR ELSE STOPS THE ENGINE.



# ENGINE CONTROL (2JZ-GTE)












# ENGINE CONTROL (2JZ-GTE)








# ENGINE CONTROL (2JZ-GTE)



FROM POWER SOURCE SYSTEM (SEE PAGE 56)





# ENGINE CONTROL (2JZ-GTE)

## SERVICE HINTS

### EFI MAIN RELAY

②3- ②5 : CLOSED WITH THE IGNITION SW AT **ON** POSITION

### EFI NO. 2 RELAY

②3- ②5 : CLOSED WITH THE IGNITION SW AT **ON** POSITION

### E3 ENGINE COOLANT TEMP. SENSOR

- 1-2 : **10-20** K $\Omega$  (**-20** °C, **-4** °F)
- 4-7** K $\Omega$  (**0** °C, **32** °F)
- 2-3** K $\Omega$  (**20** °C, **68** °F)
- 0.9-1.3** K $\Omega$  (**40** °C, **104** °F)
- 0.4-0.7** K $\Omega$  (**60** °C, **140** °F)
- 0.2-0.4** K $\Omega$  (**80** °C, **176** °F)

### I1 IDLE AIR CONTROL VALVE

- 1, 3-2 : APPROX. **10-30**  $\Omega$
- 4, 6-5 : APPROX. **10-30**  $\Omega$

### I12, I13, I14, I15, I16, I17 INJECTOR

- 1-2 : APPROX. **13.8**  $\Omega$

### T2 THROTTLE POSITION SENSOR

- 1-4 : APPROX. **4-9** K $\Omega$
- 1-3 : **3.3-10.0** K $\Omega$  WITH THROTTLE VALVE FULLY **OPENED** POSITION
- 0.2-0.8** K $\Omega$  WITH CLEARANCE BETWEEN LEVER AND STOP SCREW **0** MM (**0** IN.)
- 1-2 : **0-2.3** K $\Omega$  WITH CLEARANCE BETWEEN LEVER AND STOP SCREW **0.45** MM (**0.0177** IN.)
- INFINITY WITH CLEARANCE BETWEEN LEVER AND STOP SCREW **0.55** MM (**0.0216** IN.)

### E9 (B), E10 (A) ENGINE CONTROL MODULE

(VOLTAGE AT ENGINE CONTROL MODULE WIRING CONNECTORS)

- BATT-E1 : ALWAYS **9-14** VOLTS
- IGSW-E1 : **9-14** VOLTS WITH THE IGNITION SW ON
- M-REL-E : **9-14** VOLTS WITH THE IGNITION SW ON
- +B-E1 : **9-14** VOLTS WITH THE IGNITION SW ON
- IDL1-E2 : **9-14** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN
- 0-1.5** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED
- VTA1-E2 : **0.3-0.8** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED
- 3.2-4.9** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE OPEN
- THA-E2 : **0.5-3.4** VOLTS WITH THE IGNITION SW ON AND THE INTAKE AIR TEMP. **20** °C (**68** °F)
- THW-E2 : **0.2-1.0** VOLTS WITH THE IGNITION SW ON AND THE COOLANT TEMP. **80** °C (**176** °F)
- STA-E1 : **6-14** VOLTS WITH THE ENGINE CRANKING
- W-E1 : **9-14** VOLTS WITH ENGINE IDLING
- IGF-E1 : PULSE GENERATION (ENGINE IDLING)
- NSW-E1 : **0-3** VOLTS WITH THE IGNITION SW ON AND THE SHIFT LEVER **P** OR **N** POSITION
- 9-14** VOLTS WITH THE IGNITION SW ON AND THE SHIFT LEVER EXCEPT **P** OR **N** POSITION
- SP1 : PULSE GENERATION
- TE1-E1 : **9-14** VOLTS WITH THE IGNITION SW ON
- A/C-E1 : **0-1.5** VOLTS WITH THE IGNITION SW ON AND THE A/C OFF
- 7.5-14** VOLTS WITH THE IGNITION SW ON AND THE A/C ON
- ELS-E1 : **9-14** VOLTS WITH THE TAILLIGHT ON, DEFOGGER ON
- 0-1.5** VOLTS WITH THE TAILLIGHT OFF, DEFOGGER OFF
- STP-E1 : **7.5-14** VOLTS WITH THE STOP LIGHT SW ON (BRAKE PEDAL DEPRESSED)
- 0-1.5** VOLTS WITH THE STOP LIGHT SW OFF
- ISC1, ISC2, ISC3, ISC4-E1 : PULSE GENERATION (ENGINE IDLING)
- #10, #20, #30, #40, #50, #60-E01, E02 : PULSE GENERATION (ENGINE IDLING)

(RESISTANCE OF ENGINE CONTROL MODULE WIRING CONNECTORS)

- IDL1-E2 : INFINITY WITH THE THROTTLE VALVE OPEN
- 0-2.3** K $\Omega$  WITH THE THROTTLE VALVE FULLY CLOSED
- VTA1-E2 : **3.3** K $\Omega$ - **10.0** K $\Omega$  WITH THE THROTTLE VALVE FULLY OPEN
- 200**  $\Omega$  - **800**  $\Omega$  WITH THE THROTTLE VALVE FULLY CLOSED
- VCC-E2 : **4** K $\Omega$  - **9** K $\Omega$
- THA-E2 : **2** K $\Omega$  - **3** K $\Omega$  WITH THE INTAKE AIR TEMP. **20** °C (**68** °F)
- THW-E2 : **200**  $\Omega$  - **400**  $\Omega$  WITH THE COOLANT TEMP. **80** °C (**176** °F)
- ISC1, ISC2, ISC3, ISC4- +B : **10-30**  $\Omega$
- #10, #20, #30, #40, #50, #60- +B : **13.2-14.2**  $\Omega$

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A5	24 (2JZ-GTE)	H5	24	S1	25
C1	24	H11	29	S5	25
C2	24	I1	25 (2JZ-GTE)	S11	29
C3	24 (2JZ-GTE)	I2	B 25	T2	25 (2JZ-GTE)
C9	28	I3	A 25	T5	29
C10	A 28	I12	25 (2JZ-GTE)	T6	29
C12	B 28	I13	25 (2JZ-GTE)	T14	25
D1	24 (2JZ-GTE)	I14	25 (2JZ-GTE)	T15	29
D5	28	I15	25 (2JZ-GTE)	V2	25 (2JZ-GTE)
D8	28	I16	25 (2JZ-GTE)	V3	25 (2JZ-GTE)
D17	28	I17	25 (2JZ-GTE)	V4	25
E1	24 (2JZ-GTE)	I19	29	V5	25
E3	24 (2JZ-GTE)	J2	29	V6	25 (2JZ-GTE)
E9	B 29	K1	25 (2JZ-GTE)	V7	25
E10	A 29	K2	25 (2JZ-GTE)	V8	25
F14	30	M1	25	V10	25 (2JZ-GTE)
F15	30	P2	25 (2JZ-GTE)		

**○ : RELAY BLOCKS**

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	32 (2JZ-GTE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA2	32	
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC1	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IC2		
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		
BP1	40	FUEL GAUGE WIRE AND FLOOR NO. 2 WIRE (LUGGAGE ROOM FRONT LH)

**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
ED	32 (2JZ-GTE)	REAR SIDE OF INTAKE MANIFOLD
IE	36	LEFT KICK PANEL
IF		
IG	36	RIGHT KICK PANEL
BI	40	LEFT QUARTER PILLAR


**○ : SPLICE POINTS**

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E7	32	ENGINE ROOM MAIN WIRE	I2	38	COWL WIRE
E10	32	ENGINE WIRE	I4	38	INSTRUMENT PANEL WIRE
E11			I5	38	INSTRUMENT PANEL WIRE
E12			I8	38	INSTRUMENT PANEL WIRE
E13			I11	38	COWL WIRE
E14			I14	38	INSTRUMENT PANEL WIRE
E16			I17	38	ENGINE WIRE
E17			I20	38	COWL WIRE



# ENGINE CONTROL (2JZ-GTE)

A 5 GRAY



C 1 BLACK




C 2 BLACK




C 3 DARK GRAY




C 9




C10 (A) BLUE




C12 (B)




D 1 BLACK




D 5 DARK GRAY




D 8 ORANGE



D17




E 1 DARK GRAY




E 3 DARK GRAY




E 9 (B) DARK GRAY




E10 (A) DARK GRAY



F14 DARK GRAY



F15 BLACK




H 5 DARK GRAY



H11 GRAY




I 1 BLACK



I 2 (B) BLACK



I 3 (A) BLACK




I12, I14, I16 DARK GRAY




I13, I15, I17 BROWN



I19



J2




(HINT : SEE PAGE 7)


K 1, K 2 DARK GRAY




M 1 BLACK




P 2 GRAY




S 1 DARK GRAY




S 5 BLACK




S 11 BLUE




T 2 BLACK




T 5




T 6




T 14 BLACK




T 15




V 2 BLACK




V 3 BROWN




V 4 BLUE




V 5 BLACK




V 6 BLUE



V 7 BLACK



V 8 BLUE



V 10 BLACK








# HEADLIGHT (USA)

\*1 : 2JZ-GTE  
\*2 : 2JZ-GE



**SERVICE HINTS**

**HEADLIGHT RELAY**

2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION

**C13 LIGHT CONTROL SW [COMB. SW]**

13-11 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION

**C13 LIGHT CONTROL SW [COMB. SW]**

14-9 : CLOSED WITH THE DIMMER SW AT **FLASH** POSITION  
 12-9 : CLOSED WITH THE DIMMER SW AT **HIGH** OR **FLASH** POSITION

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C12	28	H2	24 (2JZ-GTE)	H4	24 (2JZ-GTE)
C13	28		27 (2JZ-GE)		27 (2JZ-GE)
H1	24 (2JZ-GTE)	H3	24 (2JZ-GTE)	I20	29
	27 (2JZ-GE)		27 (2JZ-GE)		

**○ : RELAY BLOCKS**

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO.2 (ENGINE COMPARTMENT LEFT)

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1J	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB2		
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)

**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL


**○ : SPLICE POINTS**


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	E21	34	ENGINE ROOM MAIN WIRE
E9			I2	38	COWL WIRE
E18	34				






# HEADLIGHT (CANADA)







# HEADLIGHT (CANADA)



## SYSTEM OUTLINE

VOLTAGE IS ALWAYS APPLIED FROM THE **MAIN** FUSE, THROUGH THE HEADLIGHT RELAY (COIL SIDE) TO **TERMINAL 5** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN), **TERMINAL 6** OF THE INTEGRATION RELAY, **TERMINAL 14** OF THE DIMMER SW, DIMMER RELAY (DAYTIME RUNNING LIGHT RELAY NO. 2) (COIL SIDE), TO **TERMINAL 17** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). WHEN THE IGNITION SW IS TURNED ON, VOLTAGE FROM THE **GAUGE** FUSE IS APPLIED TO **TERMINAL 2** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN).

### 1. DAYTIME RUNNING LIGHT OPERATION

WHEN THE ENGINE STARTS, VOLTAGE FROM **TERMINAL 'L'** OF THE GENERATOR IS APPLIED TO **TERMINAL 11** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). IF THE PARKING BRAKE LEVER IS PULLED UP (PARKING BRAKE SW ON) AT THIS TIME, THE DAYTIME RUNNING LIGHT SYSTEM DOES NOT OPERATE. WHEN THE PARKING BRAKE IS RELEASED (PARKING BRAKE SW OFF), A SIGNAL IS OUTPUT FROM **TERMINAL 1** OF THE PARKING BRAKE SW TO **TERMINAL 8** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN). THIS ACTIVATES THE DAYTIME RUNNING LIGHT RELAY (MAIN), TURNING ON THE DIMMER RELAY (DAYTIME RUNNING LIGHT RELAY NO. 2). CURRENT ALSO FLOWS FROM THE **MAIN** FUSE TO THE DIMMER RELAY (DAYTIME RUNNING LIGHT RELAY NO. 2) (POINT SIDE) → **HEAD (LH-UPR)** FUSE → HEADLIGHT HI LH → HEADLIGHT HI RH → **TERMINAL (A)5** OF THE DAYTIME RUNNING LIGHT RELAY NO. 3 → **TERMINAL (A)3** → **GROUND**, CAUSING THE HEADLIGHTS TO LIGHT UP AT APPROX. **20%** OF THEIR NORMAL BRIGHTNESS.

ONCE THE DAYTIME RUNNING LIGHT RELAY (MAIN) HAS BEEN ACTIVATED AND THE HEADLIGHTS LIGHT UP, THE HEADLIGHTS REMAIN ON EVEN IF THE PARKING BRAKE LEVER IS ENGAGED AGAIN (PARKING BRAKE SW ON).

### 2. HEADLIGHT OPERATION

WHEN THE LIGHT CONTROL SW IS AT **HEAD** POSITION AND THE DIMMER SW AT **LOW** POSITION, CURRENT FLOWS FROM THE HEADLIGHT RELAY (COIL SIDE) TO **TERMINAL 3** OF THE INTEGRATION RELAY → **TERMINAL 4** → **TERMINAL 13** OF THE LIGHT CONTROL SW → **TERMINAL 11** → **GROUND**, ACTIVATING THE HEADLIGHT RELAY. THIS CAUSES THE CURRENT TO FLOW FROM THE HEADLIGHT RELAY (POINT SIDE) TO THE **HEAD LWR** FUSE → HEADLIGHT LO → **GROUND**, CAUSING THE HEADLIGHTS TO LIGHT UP AT NORMAL BRIGHTNESS. SIMULTANEOUSLY, CURRENT FLOWS FROM THE **DRL** FUSE → DAYTIME RUNNING LIGHT RELAY NO. 3 (COIL SIDE) → **GROUND**, ACTIVATING RELAY NO. 3.

WHEN THE DIMMER SW IS AT **HIGH** POSITION, **TERMINAL 12** OF THE DIMMER SW OUTPUTS A SIGNAL TO **TERMINAL 16** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN) TO ACTIVATE IT. THIS TURNS ON DIMMER RELAY (DAYTIME RUNNING LIGHT RELAY NO. 2). SO CURRENT FLOWS FROM THE DIMMER RELAY (DAYTIME RUNNING LIGHT RELAY NO. 2) (POINT SIDE) TO THE **HEAD (LH-UPR)** FUSE → HEADLIGHT HI LH → DAYTIME RUNNING LIGHT NO. 3 (POINT SIDE) → **GROUND**, AND FROM THE **HEAD (RH-UPR)** FUSE → DAYTIME RUNNING LIGHT RELAY NO. 3 (POINT SIDE) → HEADLIGHT HI RH → DAYTIME RUNNING LIGHT RELAY NO. 3 (POINT SIDE) → **GROUND**, CAUSING THE HEADLIGHTS TO OPERATE AT HI.

WHEN THE DIMMER SW IS AT **FLASH** POSITION, CURRENT FROM THE HEADLIGHT RELAY (COIL SIDE) FLOWS TO **TERMINAL 14** OF THE DIMMER SW → **TERMINAL 9** → **GROUND**, ACTIVATING THE RELAY. SIMULTANEOUSLY, CURRENT FROM THE HEADLIGHT RELAY (POINT SIDE) FLOWS TO HEADLIGHT LO, LIGHTING UP HEADLIGHT LO AND ACTIVATING DAYTIME RUNNING LIGHT RELAY NO. 3. THEN **TERMINAL 12** OF THE DIMMER SW OUTPUTS A SIGNAL TO **TERMINAL 16** OF THE DAYTIME RUNNING LIGHT RELAY (MAIN), ACTIVATING THE DAYTIME RUNNING LIGHT RELAY (MAIN) SO THAT CURRENT FLOWS TO HEADLIGHT HI LIKE IT DOES FOR **HIGH** POSITION. THIS CAUSES ALL HEADLIGHTS TO LIGHT UP.

## SERVICE HINTS

### D6 DAYTIME RUNNING LIGHT RELAY (MAIN)

15-GROUND : ALWAYS APPROX. **12** VOLTS

2-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

13-GROUND : ALWAYS CONTINUITY

5-GROUND : APPROX. **12** VOLTS WITH THE DAYTIME RUNNING LIGHT SYSTEM

DOES NOT OPERATE OR THE LIGHT CONTROL SW AT **OFF** OR **TAIL** POSITION  
(WHEN THE CONNECTOR IS DISCONNECTED, ALWAYS APPROX. **12** VOLTS)

8-GROUND : CONTINUITY WITH THE PARKING BRAKE LEVER RELEASED



# HEADLIGHT (CANADA)

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B2	24 (2JZ-GTE)	D6	28	H4	24 (2JZ-GTE)
C12	28	G2	24 (2JZ-GTE)	I20	29
C13	28	H1	24 (2JZ-GTE)	P5	29
D2	A 24	H2	24 (2JZ-GTE)		
D3	B 24	H3	24 (2JZ-GTE)		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO. 4 (LEFT KICK PANEL)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)
2B	22	ENGINE ROOM MAIN AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB2		
IB5	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
IE	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	I2	38	COWL WIRE
E7			I4		


B 2 GRAY




C12




C13 BLACK




D 2 (A) GRAY




D 3 (B) GRAY




D 6 GRAY




G 2 BLACK



H 1 BLACK



H 2 BLACK




H 3 BROWN



H 4 BROWN



I20




P 5








# TAILLIGHT



FROM POWER SOURCE SYSTEM (SEE PAGE 56)





# TAILLIGHT

## SYSTEM OUTLINE

WHEN THE LIGHT CONTROL SW IS TURNED TO **TAIL** OR **HEAD** POSITION. THE CURRENT FLOWS TO **TERMINAL 3** OF THE LIGHT FAILURE SENSOR THROUGH THE **TAIL** FUSE.

WHEN THE IGNITION SW IS TURNED ON, THE CURRENT FLOWS FROM THE **GAUGE** FUSE TO **TERMINAL 8** OF THE LIGHT FAILURE SENSOR, AND ALSO FLOWS THROUGH THE REAR LIGHT WARNING LIGHT TO **TERMINAL 4** OF THE LIGHT FAILURE SENSOR.

### TAILLIGHT DISCONNECTION WARNING

WITH THE IGNITION SW ON AND THE LIGHT CONTROL SW TURNED TO **TAIL** OR **HEAD** POSITION, IF THE TAILLIGHT CIRCUIT IS OPEN, THE LIGHT FAILURE SENSOR DETECTS THE FAILURE BY THE CHANGE IN CURRENT FLOWING FROM **TERMINAL 3** OF THE LIGHT FAILURE SENSOR TO **TERMINAL 9**, AND THE WARNING CIRCUIT OF THE LIGHT FAILURE SENSOR IS ACTIVATED.

AS A RESULT, THE CURRENT FLOWS FROM **TERMINAL 4** OF THE LIGHT FAILURE SENSOR → **TERMINAL 11** → **GROUND** AND TURNS THE REAR LIGHT WARNING LIGHT ON, WHICH REMAINS ON UNTIL THE LIGHT CONTROL SW IS TURNED OFF.

## SERVICE HINTS

### TAILLIGHT RELAY

5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

### L2 LIGHT FAILURE SENSOR

4,8-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

3-GROUND : APPROX. **12** VOLTS WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

11-GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	28	F8	26 (2JZ-GE)	R9	30
F5	24 (2JZ-GTE)	I20	29	R10	30
	26 (2JZ-GE)	L1	30	R11	30
F6	24 (2JZ-GTE)	L2	30	R12	30
	26 (2JZ-GE)	P13	24 (2JZ-GTE)	T6	29
F8	24 (2JZ-GTE)		26 (2JZ-GE)		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1B		
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1
1J	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)

**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER


**○ : SPLICE POINTS**

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	B5	40	FLOOR NO. 2 WIRE
E18	34		B6		
B3	40	FLOOR NO. 2 WIRE	B7		
B4			B8		





# FOG LIGHT



## SERVICE HINTS

### FOG LIGHT RELAY

(2)3-(2)5 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION, DIMMER SW AT **LOW** POSITION AND THE FOG LIGHT SW **ON** POSITION

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	28	F3	26 (2JZ-GE)	F4	26 (2JZ-GE)
F3	24 (2JZ-GTE)	F4	24 (2JZ-GTE)		

### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1J	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)

### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL




### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	E18	34	ENGINE ROOM MAIN WIRE

C13 BLACK


F3 GRAY

F4 GRAY





# LIGHT AUTO TURN OFF



## SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS TO **TERMINAL 7** OF THE INTEGRATION RELAY THROUGH **GAUGE FUSE**. VOLTAGE IS APPLIED AT ALL TIMES TO **TERMINAL (A) 2** OF THE INTEGRATION RELAY THROUGH THE TAILLIGHT RELAY COIL SIDE, AND TO **TERMINAL (A) 3** THROUGH THE HEADLIGHT RELAY COIL SIDE.

### 1. NORMAL LIGHTING OPERATION

<TURN TAILLIGHT ON>

WITH THE LIGHT CONTROL SW TURNED TO TAIL POSITION, A SIGNAL IS INPUT INTO **TERMINAL (A) 1** OF THE INTEGRATION RELAY. DUE TO THIS SIGNAL, THE CURRENT FLOWING TO **TERMINAL (A) 2** OF THE RELAY FLOWS TO **TERMINAL (A) 1** → **TERMINAL 2** OF THE LIGHT CONTROL SW → **TERMINAL 11** → TO **GROUND**, AND TAILLIGHT RELAY CAUSES TAILLIGHTS TO TURN ON.

<TURN HEADLIGHT ON>

WITH THE LIGHT CONTROL SW TURNED TO HEAD POSITION, A SIGNAL IS INPUT INTO **TERMINALS (A) 1** AND **(A) 4** OF THE INTEGRATION RELAY. DUE TO THIS SIGNAL, THE CURRENT FLOWING TO **TERMINAL (A) 3** OF THE RELAY FLOWS TO **TERMINAL (A) 4** → **TERMINAL 13** OF THE LIGHT CONTROL SW → **TERMINAL 11** → TO **GROUND** IN THE HEADLIGHT CIRCUIT, AND CAUSES TAILLIGHT AND HEADLIGHT RELAY TO TURN THE LIGHTS ON. THE TAILLIGHT CIRCUIT IS SAME AS ABOVE.

### 2. LIGHT AUTO TURN OFF OPERATION

WITH LIGHT ON AND IGNITION SW TURNED OFF (INPUT SIGNAL GOES TO **TERMINAL 7** OF THE RELAY), WHEN THE DRIVER'S DOOR IS OPENED (INPUT SIGNAL GOES TO **TERMINAL 6** OF THE RELAY), THE RELAY OPERATES AND THE CURRENT IS CUT OFF WHICH FLOWS FROM **TERMINAL (A) 2** OF THE RELAY TO **TERMINAL (A) 1** IN TAILLIGHT CIRCUIT AND FROM **TERMINAL (A) 3** TO **TERMINAL (A) 4** IN HEADLIGHT CIRCUIT. AS A RESULT, ALL LIGHTS ARE TURNED OFF AUTOMATICALLY.

## SERVICE HINTS

### HEADLIGHT RELAY

- 2-1 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR THE DIMMER SW AT **FLASH** POSITION (USA)
- : CLOSED WITH THE ENGINE RUNNING AND THE PARKING BRAKE LEVER RELEASED (CANADA)

### TAILLIGHT RELAY

- 3-5 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

### D10 DOOR COURTESY SW LH

- 3-2 : CLOSED WITH THE LH DOOR OPEN

### I20 (A) INTEGRATION RELAY

- 7-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 6-GROUND : CONTINUITY WITH THE LH DOOR OPEN
- 1-GROUND : ALWAYS APPROX. **12** VOLTS
- (A)2-GROUND : ALWAYS APPROX. **12** VOLTS
- (A)3-GROUND : ALWAYS APPROX. **12** VOLTS
- (A)4-GROUND : CONTINUITY WITH THE LIGHT CONTROL SW AT **HEAD** POSITION
- (A)1-GROUND : CONTINUITY WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	28	D10	30	I20 A	29

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)





# LIGHT AUTO TURN OFF

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)


## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
BI	40	LEFT QUARTER PILLAR


C13 BLACK



D10




I20 (A)




# TURN SIGNAL AND HAZARD WARNING LIGHT




C10 ⑧ BLUE



C12 ①




C13 BLACK




F 7 GRAY




F 8 GRAY



H10




J 1




(HINT:SEE PAGE 7)

R 9




R10





# TURN SIGNAL AND HAZARD WARNING LIGHT



## SERVICE HINTS

### TURN SIGNAL FLASHER

- (4) 1-GROUND : CHANGES FROM APPROX. 12 VOLTS TO 0 VOLTS WITH THE IGNITION SW ON AND THE TURN SIGNAL SW LEFT OR RIGHT, OR WITH THE HAZARD WARNING SW ON.  
 (4) 2-GROUND : 12 VOLTS WITH THE IGNITION SW ON OR THE HAZARD SW ON  
 (4) 3-GROUND : ALWAYS CONTINUITY

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C10	B 28	F 7	26 (2JZ-GE)	J 1	29
C12	A 28	F 8	26 (2JZ-GTE)	R 9	30
C13	28		26 (2JZ-GE)	R10	30
F 7	24 (2JZ-GTE)	H10	29		

### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO. 4 (LEFT KICK PANEL)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)

### ▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL
IH	36	RIGHT KICK PANEL
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER

### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 2	32	ENGINE ROOM WIRE	I 3	38	INSTRUMENT PANEL WIRE
E18	34		B 4	40	FLOOR NO. 2 WIRE
I 2	38	COWL WIRE			



# STOP LIGHT



## SYSTEM OUTLINE

CURRENT IS APPLIED AT ALL TIMES THROUGH THE **STOP FUSE** TO **TERMINAL 2** OF THE STOP LIGHT SW. WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS FROM THE **GAUGE FUSE** TO **TERMINAL 8** OF THE LIGHT FAILURE SENSOR, AND ALSO FLOWS THROUGH THE REAR LIGHT WARNING LIGHT TO **TERMINAL 4** OF THE LIGHT FAILURE SENSOR.

### STOP LIGHT DISCONNECTION WARNING

WHEN THE IGNITION SW IS TURNED ON AND THE BRAKE PEDAL IS PRESSED (STOP LIGHT SW ON), IF THE STOP LIGHT CIRCUIT IS OPEN, THE CURRENT FLOWING FROM **TERMINAL 7** OF THE LIGHT FAILURE SENSOR TO **TERMINAL 2** CHANGES, SO THE LIGHT FAILURE SENSOR DETECTS THE DISCONNECTION AND THE WARNING CIRCUIT OF THE LIGHT FAILURE SENSOR IS ACTIVATED.

AS A RESULT, THE CURRENT FLOWS FROM **TERMINAL 4** OF THE LIGHT FAILURE SENSOR → **TERMINAL 11** → **GROUND** AND TURNS THE REAR LIGHT WARNING LIGHT ON. BY PRESSING THE BRAKE PEDAL, THE CURRENT FLOWING TO **TERMINAL 8** OF THE LIGHT FAILURE SENSOR KEEPS THE WARNING CIRCUIT ON HOLDING AND THE WARNING LIGHT ON UNTIL THE IGNITION SW IS TURNED OFF.

## SERVICE HINTS

### S11 STOP LIGHT SW

2-1 :CLOSED WITH THE BRAKE PEDAL DEPRESSED

### L 2 LIGHT FAILURE SENSOR

2, 7 GROUND: APPROX. 12 VOLTS WITH THE STOP LIGHT SW ON

4, 8 GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

11 GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
H14	30	R 9	30	S11	29
L 2	30	R10	30	T 6	29

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
BM1	40	BACK DOOR NO. 1 WIRE AND FLOOR NO. 2 WIRE (LEFT SIDE OF PACKAGE TRAY TRIM)
BO1	40	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE (BACK DOOR UPPER LEFT)

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER
BK	40	RIGHT SIDE OF HIGH MOUNTED STOP LIGHT

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 4	40	FLOOR NO. 2 WIRE	B10	40	BACK DOOR NO. 2 WIRE
B 6					






# BACK-UP LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 56)

- B 1 (B), (C)
- BACK-UP LIGHT SW (M/T)
- P 2 (A)
- BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)



**SERVICE HINTS**

**B 1 (B), (C) BACK-UP LIGHT SW (M/T)**

**P 2 (A) BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)**

(B), (C) 2-1, (A) 4-8 : CLOSED WITH THE SHIFT LEVER IN R POSITION

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B 1	B 24 (2JZ-GTE)	P 2	A 25 (2JZ-GTE)	R 9	30
	C 26 (2JZ-GE)		A 27 (2JZ-GE)	R10	30

**□ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)


**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER


**○ : SPLICE POINTS**

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 4	40	FLOOR NO. 2 WIRE	B 6	40	FLOOR NO. 2 WIRE


B 1 (B) GRAY




B 1 (C) GRAY




P 2 (A) GRAY



R 9



R10









# INTERIOR LIGHT

FROM POWER SOURCE SYSTEM (SEE PAGE 56)







# INTERIOR LIGHT

## SERVICE HINTS

### INTERGRATION RELAY (J/B NO. 1)

1-GROUND : ALWAYS APPROX. 12 VOLTS

4-GROUND : CONTINUITY WITH THE RH DOOR OPEN OR THE LH DOOR OPEN

### D10, D11 DOOR COURTESY SW LH, RH

1-2 : CLOSED WITH THE DOOR OPEN

### L 5 LUGGAGE COMPARTMENT LIGHT SW

1-GROUND : CLOSED WITH THE LUGGAGE COMPARTMENT DOOR OPEN

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D 7	28	I18	29	P 6	30
D10	30	L 4	30	T 6	29
D11	30	L 5	30		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D	20	FRONT DOOR LH WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1F	20	ROOF WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL
BI	40	LEFT QUARTER PILLAR


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I11	38	COWL WIRE	B 6	40	FLOOR NO. 2 WIRE


D 7




D10




D11



I18 BLUE




L 4




L 5 GRAY



P 6




T 6






# ILLUMINATION

FROM POWER SOURCE SYSTEM (SEE PAGE 56)







# ILLUMINATION

## SERVICE HINTS

### TAILLIGHT RELAY

5-3 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

### C13 LIGHT CONTROL SW [COMB. SW]

2-1 1 : CLOSED WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A29	28	H10	29	R 6	29
C 7	28	H12	29	R 8	29
C10	28	I20	29	S 6	29
C13	28	J 1	29	T 6	29
E 8	29	O 5	29	T 8	29
G 3	29	R 4	A	29	
G 4	29	R 5	B	29	

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IH1	38	INSTRUMENT PANEL AND CONSOLE BOX WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)
IH2		


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
IH	36	RIGHT KICK PANEL


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 4	38	COWL WIRE	I14	38	INSTRUMENT PANEL WIRE
I10	38	COWL WIRE	I19		
I12	38	INSTRUMENT PANEL WIRE			


A29




C 7 BLACK




C10 BLUE




C13 BLACK




E 8




G 3 BLACK




G 4 BLACK




H10




H12 ORANGE



I20




J 1




(HINT : SEE PAGE 7)


O 5 BLUE




R 4 (A)




R 5 (B)




R 6




R 8




S 6 BLACK



T 6




T 8 BLACK







# FRONT WIPER AND WASHER



## SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS TO **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW, **TERMINAL 2** OF THE WASHER MOTOR AND **TERMINAL 6** OF THE FRONT WIPER MOTOR FROM THE **WIPER FUSE**.

### 1. LOW SPEED POSITION

WITH THE WIPER SW TURNED TO **LOW** POSITION, THE CURRENT FLOWS FROM **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW TO **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → **TERMINAL 1** → TO **GROUND** AND CAUSES THE WIPER MOTOR TO RUN AT LOW SPEED.

### 2. HIGH SPEED POSITION

WITH THE WIPER SW TURNED TO **HIGH** POSITION, THE CURRENT FLOWS FROM **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 13** → **TERMINAL 2** OF THE FRONT WIPER MOTOR → **TERMINAL 1** → TO **GROUND** AND CAUSES TO THE WIPER MOTOR TO RUN AT HIGH SPEED.

### 3. INT POSITION

WITH THE WIPER SW TURNED TO **INT** POSITION, THE RELAY OPERATES AND THE CURRENT WHICH IS CONNECTED BY RELAY FUNCTION FLOWS FROM THE **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 16** → TO **GROUND**. THIS FLOWS OF THE CURRENT OPERATES THE INTERMITTENT CIRCUIT AND THE CURRENT FLOWS FROM **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → **TERMINAL 1** → TO **GROUND** AND FUNCTIONS.

THE INTERMITTENT OPERATION IS CONTROLLED BY A CONDENSER'S CHARGED AND DISCHARGED FUNCTION INSTALLED IN RELAY AND INTERMITTENT TIME IS CONTROLLED BY A TIME CONTROL SW TO CHARGE THE CHARGING TIME OF THE CONDENSER.

### 4. MIST POSITION

WITH THE WIPER SW TURNED TO **MIST** POSITION, THE CURRENT FLOWS FROM **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → **TERMINAL 1** → TO **GROUND** AND CAUSES THE WIPER MOTOR TO RUN AT LOW SPEED.

### 5. WASHER CONTINUOUS OPERATION

WITH THE WASHER SW TURNED TO ON, THE CURRENT FLOWS THROUGH **TERMINAL 2** OF THE WASHER MOTOR → **TERMINAL 1** → **TERMINAL 8** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 16** → TO **GROUND** AND CAUSES TO THE WASHER MOTOR TO RUN, AND WINDOW WASHER IS JET. THIS CAUSES THE CURRENT TO FLOW WASHER CONTINUOUS OPERATION CIRCUIT IN **TERMINAL 18** OF THE FRONT WIPER AND WASHER SW → **TERMINAL 7** → **TERMINAL 3** OF THE FRONT WIPER MOTOR → **TERMINAL 1** → TO **GROUND** AND FUNCTION.

## SERVICE HINTS

### C14 FRONT WIPER AND WASHER SW [COMB. SW]

16-GROUND : ALWAYS CONTINUITY

18-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

7-GROUND : APPROX. 12 VOLTS WITH THE WIPER AND WASHER SW AT **LOW** POSITION

: APPROX. 12 VOLTS EVERY APPROX. 1 TO 10 SECONDS INTERMITTENTLY WITH THE WIPER SW AT **INT** POSITION

4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON UNLESS THE WIPER MOTOR AT **STOP** POSITION

13-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW ON AND THE WIPER AND WASHER SW AT **HIGH** POSITION

### F 9 FRONT WIPER MOTOR

5-6 : CLOSED UNLESS WIPER MOTOR AT **STOP** POSITION



### : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C14	28	F 9	26 (2JZ-GE)	W 2	27 (2JZ-GTE)
F 9	24 (2JZ-GTE)	W 1	25 (2JZ-GTE)		



### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		



### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)



# FRONT WIPER AND WASHER


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 9	32	ENGINE ROOM MAIN WIRE	E21	34	ENGINE ROOM MAIN WIRE


**C14 BLACK**



**F 9 BLACK**




**W 1 BLACK**





FROM POWER SOURCE SYSTEM (SEE PAGE 56)



## SERVICE HINTS

### HORN RELAY

(2) 2- (2) 3 : CLOSED WITH THE HORN SW ON

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	28	H 8	27 (2JZ-GE)	H 9	27 (2JZ-GE)
H 8	24 (2JZ-GTE)	H 9	24 (2JZ-GTE)		

### □ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)


### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 2	32	ENGINE ROOM MAIN WIRE	I 2	38	COWL WIRE
E 18	34				




# THEFT DETERRENT AND DOOR LOCK CONTROL







# THEFT DETERRENT AND DOOR LOCK CONTROL



## SYSTEM OUTLINE

CURRENT ALWAYS FLOWS TO **TERMINAL (A) 9** OF THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU THROUGH THE **DOOR FUSE**, AND TO **TERMINAL (B) 1** THROUGH THE **DOME FUSE**.

WHEN THE IGNITION SW TURNED ON, THE CURRENT FLOWING THROUGH THE **ECU-IG FUSE** " **TERMINAL (A) 7** OF THE ECU " **TERMINAL (A) 6** FLOWS THROUGH THE COIL SIDE OF THE POWER MAIN RELAY TO **GROUND**, CAUSING THE RELAY TO OPERATE. THE CURRENT FLOWING THROUGH THE **DOOR FUSE** FLOWS TO THE DOOR LOCK CONTROL SWITCHES, CAUSING THE INDICATOR LIGHT TO LIGHT UP.

### 1. MANUAL LOCK OPERATION

WHEN THE DOOR LOCK CONTROL SW OR KEY SW ARE PUSHED TO **LOCK** POSITION, A LOCK SIGNAL IS INPUT TO **TERMINAL (B) 5, (B) 22** (FOR KEY SW) OF THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU AND CAUSES THE ECU TO FUNCTION. CURRENT FLOWS FROM **TERMINAL (A) 9** OF THE ECU " **TERMINAL (A) 3** " **TERMINAL 2 (LH), TERMINAL 4 (RH)** OF THE DOOR LOCK MOTORS " **TERMINAL 4 (LH), TERMINAL 2 (RH)** " **TERMINAL (A) 2** OF THE ECU " **TERMINAL (A) 4** " **GROUND** AND THE DOOR LOCK MOTOR CAUSES THE DOOR TO LOCK.

### 2. MANUAL LOCK OPERATION

WHEN THE DOOR LOCK CONTROL SW OR KEY SW ARE PUSHED TO UNLOCK POSITION, AN UNLOCK SIGNAL IS INPUT TO **TERMINAL (B) 8, (B) 6** (FOR KEY SW LH) OR **(B) 16** (FOR KEY SW RH) OF THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU AND CAUSES TO FUNCTION.

CURRENT FLOWS FROM **TERMINAL (A) 9** OF THE ECU " **TERMINAL (A) 2** " **TERMINAL 4 (LH), TERMINAL 2 (RH)** OF THE DOOR LOCK MOTORS " **TERMINAL 2 (LH), TERMINAL 4 (RH)** " **TERMINAL (A) 3** OF THE ECU " **TERMINAL (A) 4** " **GROUND** AND THE DOOR LOCK MOTOR CAUSES THE DOOR TO UNLOCK.

WHEN UNLOCK OPERATION OCCURS USING THE LH DOOR KEY SW, DOING THE UNLOCK OPERATION ONCE UNLOCKS ONLY THE DRIVER'S DOOR. TO UNLOCK ALL OTHER DOORS TOGETHER, UNLOCK OPERATION MUST BE DONE AGAIN WITHIN 3 SECONDS OF THE FIRST OPERATION.

### 3. IGNITION KEY REMINDER OPERATION

#### • OPERATION OF DOOR LOCK BUTTON (OPERATION OF DOOR LOCK MOTORS)

WHEN THE IGNITION KEY IS IN THE CYLINDER (UNLOCK WARNING SW ON) AND THE DOOR IS OPENED AND LOCKED USING DOOR LOCK BUTTON (DOOR LOCK MOTOR). THE DOOR IS LOCKED ONCE BUT EACH DOOR IS UNLOCKED SOON BY THE OPERATION OF THE ECU. AS A RESULT OF ECU ACTIVATION, THE CURRENT FLOWS FROM **TERMINAL (A) 9** OF THE ECU " **TERMINAL (A) 2** " **TERMINAL 4 (LH), TERMINAL 2 (RH)** OF THE DOOR LOCK MOTORS " **TERMINAL 2 (LH), TERMINAL 4 (RH)** " **TERMINAL (A) 3** OF THE ECU " **TERMINAL (A) 4** " **GROUND** AND CAUSES ALL THE DOOR LOCK CONTROL SW AND DOOR LOCK KEY SW.

#### • KEY LESS LOCK OPERATION

WHEN THE IGNITION KEY IS STILL INSERTED IN THE CYLINDER (UNLOCK WARNING SW ON), THE DOOR IS OPEN AND UNLOCK OPERATION IS PREVENTED BY KEEPING THE DOOR LOCK BUTTON PRESSED TO THE LOCK SIDE, THE DOOR IS KEPT IN THE LOCK CONDITION. IF THE DOOR IS THEN CLOSED, A SIGNAL IS INPUT TO THE ECU FROM THE DOOR COURTESY SW. THIS ACTIVATES THE ECU AND EACH DOOR IS UNLOCKED.





# THEFT DETERRENT AND DOOR LOCK CONTROL

## SERVICE HINTS

### D10, D11 DOOR COURTESY SW LH, RH

3-2 : CLOSED WITH THE DOOR OPEN

### D12, D13 DOOR KEY LOCK AND UNLOCK SW LH, RH

1-3 : CLOSED WITH THE DOOR LOCK CYLINDER UNLOCKED WITH KEY

2-3 : CLOSED WITH THE DOOR LOCK CYLINDER LOCKED WITH KEY

### D15, D16 DOOR LOCK MOTOR AND DOOR UNLOCK DETECTION SW LH, RH

1-3 : CLOSED WITH **UNLOCK** POSITION.

### E 6 ENGINE HOOD COURTESY SW

1-2 : CLOSED WITH THE ENGINE HOOD OPEN

### U 1 UNLOCK WARNING SW

2-1 : CLOSED WITH THE IGNITION KEY IN CYLINDER

### L 3 LUGGAGE COMPARTMENT KEY UNLOCK SW

2-1 : CLOSED WITH THE DOOR LOCK CYLINDER UNLOCKED WITH KEY

### L 5 LUGGAGE COMPARTMENT LIGHT SW

1-GROUND : CLOSED WITH THE DOOR OPEN

### T 7 (A), T13 (B) THEFT DETERRENT AND DOOR LOCK CONTROL ECU

(B) 9-GROUND : CONTINUITY WITH THE LUGGAGE COMPARTMENT DOOR TO **UNLOCK** POSITION

(B) 14-GROUND : CONTINUITY WITH THE ENGINE HOOD OPEN

(B) 4-GROUND : CONTINUITY WITH THE LUGGAGE COMPARTMENT DOOR OPEN

(B) 8-GROUND : CONTINUITY WITH THE DOOR LOCK CONTROL SW TO **UNLOCK** POSITION

(B) 5-GROUND : CONTINUITY WITH THE DOOR LOCK CONTROL SW TO **LOCK** POSITION

(B) 25-GROUND : APPROX. **12** VOLTS WITH THE SHIFT LEVER IN **N** OR **P** POSITION AND THE IGNITION SW AT **ST** POSITION (A/T)

: APPROX. **12** VOLTS WITH THE CLUTCH PEDAL FULLY DEPRESSED (M/T)

(A) 7-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

(B) 20-GROUND : CONTINUITY WITH THE IGNITION KEY IN CYLINDER

(B) 15-GROUND : CONTINUITY WITH THE LH DOOR TO **UNLOCK** POSITION

(B) 21-GROUND : CONTINUITY WITH THE RH DOOR TO **UNLOCK** POSITION

(B) 6-GROUND : CONTINUITY WITH THE DOOR KEY LOCK AND UNLOCK SW LH TO **UNLOCK** POSITION

(B) 16-GROUND : CONTINUITY WITH THE DOOR KEY LOCK AND UNLOCK SW RH TO **UNLOCK** POSITION

(B) 22-GROUND : CONTINUITY WITH THE DOOR KEY LOCK AND UNLOCK SW TO **LOCK** POSITION

(A) 4-GROUND : ALWAYS CONTINUITY

(B) 1-GROUND : ALWAYS APPROX. **12** VOLTS

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 9	28	D16	30	P 8	30
D10	30	E 6	24 (2JZ-GTE)	T 1	25 (2JZ-GTE)
D11	30		26 (2JZ-GE)		27 (2JZ-GE)
D12	30	L 3	30	T 5	29
D13	30	L 5	30	T 7	A 29
D14	30	P 2	25 (2JZ-GTE)	T13	B 29
D15	30		27 (2JZ-GE)	U 1	29

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D	20	FRONT DOOR LH WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		
1K		
2A	22	BATTERY AND J/B NO.2 (ENGINE COMPARTMENT LEFT)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	32 (2JZ-GTE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
	34 (2JZ-GE)	
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB6	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	36	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL
IH		
BI	40	LEFT QUARTER PILLAR
BJ	40	LOWER BACK PANEL CENTER


**○ : SPLICE POINTS**


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 2	38	COWL WIRE	I21	38	INSTRUMENT PANEL WIRE
I 4			B 1	40	FRONT DOOR LH WIRE
I19	38	INSTRUMENT PANEL WIRE	B 2	40	FRONT DOOR RH WIRE





# POWER WINDOW







# POWER WINDOW

## SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS THROUGH THE **ECU-IG** FUSE TO → **TERMINAL (A)7** OF THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU → **TERMINAL (A)6** → **TERMINAL 1** OF THE POWER MAIN RELAY → **TERMINAL 2** → **GROUND**, THIS ACTIVATES THE RELAY AND THE CURRENT FLOWING TO **TERMINAL 5** OF THE RELAY FROM DOOR FUSE FLOWS TO **TERMINAL 3** OF THE RELAY → **TERMINAL 4** OF THE POWER WINDOW MASTER SW AND → **TERMINAL 4** OF THE POWER WINDOW CONTROL SW RH.

### 1. MANUAL OPERATION (DRIVER'S WINDOW)

WITH THE IGNITION SW TURNED ON AND WITH THE POWER WINDOW MASTER SW (DRIVER'S) AT **UP** POSITION, THE CURRENT FLOWING TO **TERMINAL 4** OF THE POWER WINDOW MASTER SW FLOWS TO **TERMINAL 10** OF THE MASTER SW → **TERMINAL 1** → OF THE POWER WINDOW MOTOR → **TERMINAL 2** → **TERMINAL 9** OF THE MASTER SW → **TERMINAL 8** → **GROUND** AND CAUSES THE POWER WINDOW MOTOR TO ROTATE IN THE UP DIRECTION. THE WINDOW ASCENDS ONLY WHILE THE SW IS BEING PUSHED.

IN DOWN OPERATION, THE FLOW OF CURRENT FROM **TERMINAL 4** OF THE POWER WINDOW MASTER SW TO **TERMINAL 9** OF THE MASTER SW CAUSES THE FLOW OF CURRENT FROM **TERMINAL 2** OF THE POWER WINDOW MOTOR → **TERMINAL 1** → **TERMINAL 10** OF THE MASTER SW → **TERMINAL 8** → **GROUND**, FLOWING IN THE OPPOSITE DIRECTION TO MANUAL UP OPERATION AND CAUSING THE MOTOR TO ROTATE IN REVERSE, LOWERING THE WINDOW.

### 2. DRIVER'S WINDOW AUTO DOWN OPERATION

WHEN THE DRIVER'S WINDOW SW IS PUSHED STRONGLY ON THE DOWN SIDE, THE CURRENT FLOWING TO **TERMINAL 4** OF THE POWER WINDOW MASTER SW FLOWS TO THE DOWN CONTACT POINT AND AUTO DOWN CONTACT POINT OF THE DRIVER'S SW.

THIS ACTIVATES THE RELAY (DOWN SIDE) INSIDE THE POWER WINDOW MASTER SW, AND THE HOLD CIRCUIT ALSO TURNS ON AT THE SAME TIME, SO THE RELAY (DOWN SIDE) REMAINS ACTIVATED EVEN WHEN THE SW IS RELEASED.

CURRENT FLOWS AT THIS TIME FROM **TERMINAL 4** OF THE POWER WINDOW MASTER SW → **TERMINAL 9** → **TERMINAL 2** OF POWER WINDOW MOTOR → **TERMINAL 1** → **TERMINAL 10** OF POWER WINDOW MASTER SW → **TERMINAL 8** → **GROUND**, SO THE MOTOR CONTINUES TO OPERATE UNTIL THE DRIVER'S WINDOW IS FULLY DOWN.

WHEN THE DRIVER'S WINDOW FINISHES DOWN OPERATION THE HOLD CIRCUIT GOES OFF, SO THE RELAY (DOWN SIDE) ALSO TURNS OFF. THIS STOPS THE CURRENT FLOWING FROM FROM **TERMINAL 4** OF THE POWER WINDOW MASTER SW TO **TERMINAL 9**, SO THE POWER WINDOW MOTOR STOPS AND AUTO DOWN OPERATION STOPS.

WHEN THE DRIVER'S SW IS PULLED ON THE UP SIDE DURING AUTO DOWN OPERATION, THE HOLD CIRCUIT IS TURNED OFF SO CURRENT FLOWS FROM **TERMINAL 4** OF THE POWER WINDOW MASTER SW TO **TERMINAL 9** IS CUT OFF AND THE POWER WINDOW MOTOR STOPS. IF THE SW REMAINS PULLED UP, THE RELAY (UPSIDE) IS ACTIVATED, SO CURRENT FLOWS FROM **TERMINAL 4** OF THE POWER WINDOW MASTER SW → **TERMINAL 10** → **TERMINAL 1** OF THE POWER WINDOW MOTOR → **TERMINAL 2** → **TERMINAL 9** → **TERMINAL 8** → **GROUND**, THE POWER WINDOW MOTOR ROTATES IN THE UP DIRECTION AND MANUAL UP OPERATION OCCURS WHILE THE SW IS PULLED UP.

### 3. MANUAL OPERATION BY POWER WINDOW SW (FRONT RH WINDOW)

WITH POWER WINDOW SW (FRONT RH) PULLED TO THE UP SIDE, CURRENT FLOWING FROM **TERMINAL 4** OF THE POWER WINDOW CONTROL SW FLOWS TO **TERMINAL 1** OF THE POWER WINDOW SW → **TERMINAL 2** OF THE POWER WINDOW MOTOR → **TERMINAL 1** → **TERMINAL 3** OF THE POWER WINDOW SW → **TERMINAL 5** → **TERMINAL 7** OF THE MASTER SW → **TERMINAL 8** → **GROUND** AND CAUSES THE POWER WINDOW MOTOR (FRONT RH) TO ROTATE IN THE UP DIRECTION. UP OPERATION CONTINUES ONLY WHILE THE POWER WINDOW SW IS PULLED TO THE UP SIDE. WHEN THE POWER WINDOW SW (FRONT RH) IS PULLED TO THE DOWN SIDE, THE CURRENT FLOWING TO THE MOTOR FLOWS IN THE OPPOSITE DIRECTION, FROM **TERMINAL 1** TO **TERMINAL 2**, AND THE MOTOR ROTATES IN REVERSE. WHEN THE WINDOW LOCK SW IS PUSHED TO THE LOCK SIDE, THE GROUND CIRCUIT TO THE PASSENGER'S WINDOW BECOMES OPEN.

AS A RESULT, EVEN IF OPEN/CLOSE OPERATION OF THE PASSENGER'S WINDOW IS TRIED, THE CURRENT FROM **TERMINAL 8** OF THE POWER WINDOW MASTER SW IS NOT GROUNDING AND THE MOTOR DOES NOT ROTATE, SO THE PASSENGER'S WINDOW CANNOT BE OPERATED AND WINDOW LOCK OCCURS. FURTHERMORE, REAR LH, RH WINDOW OPERATE THE SAME AS THE ABOVE CIRCUIT.

### 4. KEY OFF POWER WINDOW OPERATION

WITH THE IGNITION SW TURNED FROM ON TO OFF, THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU AND CURRENT FLOWS FROM DOOR FUSE **TERMINAL (A) 9** OF THE ECU OR DOME FUSE TO **TERMINAL (B)1** OF THE ECU → **TERMINAL (A) 6** → **TERMINAL 1** OF THE POWER RELAY → **TERMINAL 2** → **GROUND** FOR ABOUT **60** SECONDS. THE SAME AS NORMAL OPERATION, THE CURRENT FLOWS FROM DOOR FUSE → **TERMINAL 5** OF THE POWER MAIN RELAY → **TERMINAL 3** → **TERMINAL 4** OF THE POWER WINDOW MASTER SW, AND **TERMINAL 4** OF THE POWER WINDOW CONTROL SW RH. AS A RESULT, FOR ABOUT **60** SECONDS AFTER THE IGNITION SW IS TURNED. THE FUNCTIONING OF THIS RELAY MAKES IT POSSIBLE TO RAISE AND LOWER THE POWER WINDOW ALSO, BY OPENING THE FRONT DOOR (DOOR OPEN DETECTION SW ON ED) WITHIN ABOUT **60** SECONDS AFTER TURNING THE IGNITION SW TO OFF, A SIGNAL IS INPUT TO **TERMINAL (B) 19**, **(B) 7** OF THE THEFT DETERRENT AND DOOR LOCK CONTROL ECU. AS A RESULT, THE ECU TURNED OFF AND UP AND DOWN MOVEMENT OF THE POWER WINDOW STOPS.

## SERVICE HINTS

### P 8 POWER WINDOW MASTER SW

4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

8-GROUND : ALWAYS CONTINUITY

10-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW **ON** AND MASTER SW (DRIVER'S WINDOW) AT **UP** POSITION

9-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW **ON** AND MASTER SW (DRIVER'S WINDOW) AT **DOWN OR AUTO DOWN** POSITION

### WINDOW LOCK SW

OPEN WITH THE WINDOW LOCK SW AT **LOCK** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D10	30	P 8	25	T 7	A 29
D11	30	P 9	27	T13	B 29
P 7	30	P10	27		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D	20	FRONT DOOR LH WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	36	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

## ▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL
IH		
BI	40	LEFT QUARTER PILLAR




FROM POWER SOURCE SYSTEM (SEE PAGE 56)




# AND A/T INDICATOR (2JZ-GTE)








# AND A/T INDICATOR (2JZ-GTE)





# AND A/T INDICATOR (2JZ-GTE)

## SYSTEM OUTLINE

THIS SYSTEM ELECTRICALLY CONTROLS THE LINE PRESSURE, THROTTLE PRESSURE, LOCK-UP PRESSURE AND ACCUMULATOR PRESSURE ETC. THROUGH THE SOLENOID VALVE. THE ELECTRONICALLY CONTROLLED TRANSMISSION IS A SYSTEM WHICH PRECISELY CONTROLS GEAR SHIFT TIMING AND LOCK-UP TIMING IN RESPONSE TO THE VEHICLE'S DRIVING CONDITIONS AND THE ENGINE OPERATING CONDITIONS DETECTED BY VARIOUS SENSORS, MAKING SMOOTH DRIVING POSSIBLE BY SHIFT SELECTION FOR EACH GEAR WHICH IS THE MOST APPROPRIATE TO THE DRIVING CONDITIONS AT THAT TIME, AND CONTROLS THE ENGINE TORQUE DURING SHIFTING TO ACHIEVE OPTIMUM SHIFT FEELING.

### 1. GEAR SHIFT OPERATION

WHEN DRIVING, THE ENGINE WARM UP CONDITION IS INPUT AS A SIGNAL TO **TERMINAL (B) 44** OF THE ENGINE CONTROL MODULE FROM THE ENGINE COOLANT TEMP. SENSOR AND THE VEHICLE SPEED SIGNAL FROM VEHICLE SPEED SENSOR NO. 2 IS INPUT TO **TERMINAL (B) 23** OF THE ENGINE CONTROL MODULE. AT THE SAME TIME, THE THROTTLE VALVE OPENING SIGNAL FROM THE THROTTLE POSITION SENSOR (MAIN) IS INPUT TO **TERMINAL (B) 43** OF THE ENGINE CONTROL MODULE AS THROTTLE ANGLE SIGNAL.

BASED ON THESE SIGNALS, THE ENGINE CONTROL SELECTS THE BEST SHIFT POSITION FOR DRIVING CONDITIONS AND SENDS CURRENT TO THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOIDS.

WHEN SHIFTING TO 1ST SPEED, THE CURRENT FLOWS FROM **TERMINAL (B) 10** OF THE ENGINE CONTROL MODULE → **TERMINAL 4** OF ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND** AND CONTINUITY TO NO. 1 SOLENOID CAUSES THE SHIFT (NO. 2 SOLENOID DOES NOT HAVE CONTINUITY AT THIS TIME.)

FOR 2ND SPEED, THE CURRENT FLOWS SIMULTANEOUSLY FROM **TERMINAL (B) 9** OF THE ENGINE CONTROL MODULE → **TERMINAL 8** OF ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND** AND FROM **TERMINAL (B) 10** OF THE ENGINE CONTROL MODULE → **TERMINAL 4** OF ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND CONTINUITY TO NO. 1 AND NO. 2 SOLENOIDS CAUSES THE SHIFT.

FOR 3RD SPEED, THERE IS NO CONTINUITY TO NO. 1 SOLENOID, ONLY TO NO. 2 SOLENOID, CAUSING THE SHIFT. SHIFTING INTO THE 4TH SPEED (OVERDRIVE) OCCURS WHEN NO CURRENT FLOWS TO NO. 1 AND NO. 2 SOLENOIDS. THE NO. 4 SOLENOID (FOR ACCUMULATOR BACK PRESSURE MODULATION) IS INSTALLED TO ADJUST THE BACK PRESSURE ON THE ACCUMULATOR AND CONTROLS THE HYDRAULIC PRESSURE DURING SHIFTING AND LOCK-UP IN ORDER TO PROVIDE SMOOTH SHIFTING WITH LITTLE SHIFT SHOCK.

### 2. LOCK-UP OPERATION

WHEN THE ENGINE CONTROL MODULE DECIDES BASED ON EACH SIGNAL THAT THE LOCK-UP CONDITION HAS BEEN MET, THE CURRENT THROUGH EFI NO. 1 FUSE FLOWS FROM THE EFI MAIN RELAY → **TERMINAL 3** OF ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **TERMINAL 7** → **TERMINAL (B) 14** OF THE ENGINE CONTROL MODULE → **GROUND**, SO CONTINUITY TO NO. 3 (FOR LOCK-UP) CAUSES LOCK-UP.

### 3. STOP LIGHT SW CIRCUIT

IF THE BRAKE PEDAL IS DEPRESSED (STOP LIGHT SW ON) WHEN DRIVING IN LOCK-UP CONDITION, A SIGNAL IS INPUT TO **TERMINAL(A) 4** OF THE ENGINE CONTROL MODULE. THE ENGINE CONTROL MODULE OPERATES AND CUTS THE CURRENT TO THE SOLENOID. TO RELEASE LOCK-UP.

### 4. OVERDRIVE CIRCUIT

#### \* O/D MAIN SW ON

WHEN THE O/D MAIN SW IS TURNED ON (SW POINT IS OPEN), A SIGNAL IS INPUT TO **TERMINAL (A) 28** OF THE ENGINE CONTROL MODULE, AND THE ELECTRONICALLY CONTROLLED TRANSMISSION CAUSES SHIFT TO OVERDRIVE WHEN THE CONDITIONS FOR OVERDRIVE ARE MET.

#### \* O/D MAIN SW OFF

WHEN THE O/D MAIN SW IS TURNED OFF (SW POINT IS CLOSED), THE CURRENT FLOWING THROUGH THE O/D OFF INDICATOR LIGHT FLOWS TO **GROUND** BY WAY OF THE O/D MAIN SW AND CAUSES THE O/D OFF INDICATOR LIGHT TO LIGHT UP. AT THE SAME TIME, A SIGNAL IS INPUT TO **TERMINAL (A) 28** OF THE ENGINE CONTROL MODULE AND THE ELECTRONICALLY CONTROLLED TRANSMISSION PREVENTS SHIFT INTO OVERDRIVE.

### 5. ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW CIRCUIT

WHEN THE ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW IS SWITCHED FROM NORMAL TO MANUAL, A SIGNAL IS INPUT TO **TERMINAL (A) 18** OF THE ENGINE CONTROL MODULE. INPUT OF THIS SIGNAL CAUSES CURRENT TO FLOW FROM THE **GAUGE FUSE** TO **TERMINAL (A) 1** OF THE COMBINATION METER → **TERMINAL (A) 12** → **TERMINAL (A) 25** OF THE ENGINE CONTROL MODULE → **GROUND**, LIGHTING UP THE INDICATOR LIGHT. IF THE A/T SHIFT LEVER IS THEN SHIFTED TO "2" POSITION, THE ENGINE CONTROL MODULE ENABLES THE VEHICLE TO START OFF WITH THE TRANSMISSION IS 2ND GEAR, THUS PERMITTING EASING STARTING OFF AND DRIVING ON SLIPPERY ROADS.

### 6. CRUISE CONTROL

WHEN CRUISE CONTROL OPERATION IS SELECTED A SIGNAL IS INPUT TO **TERMINAL (A) 12** OF THE ENGINE CONTROL MODULE FROM CRUISE CONTROL ECU. AS A RESULT, THE ENGINE CONTROL MODULE OPERATES AND CONTROLS OVERDRIVE, LOCK-UP AND SO ON FOR SMOOTH DRIVING.

## SERVICE HINTS

**E2 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID**

8-GROUND: APPROX. 13.2Ω:  
 4-GROUND: APPROX. 13.2Ω:  
     6.2: APPROX. 8.3Ω:  
     7.3: APPROX. 3.8Ω:  
     1.5: APPROX. 3.8Ω:

**E 3 ENGINE COOLANT TEMP. SENSOR**

1-2: 1- 10-20 KΩ @ 20°C - 4°F  
     4-7 KΩ @ 0°C - 32°F  
     2-3 KΩ @ 20°C - 68°F  
     0.9-1.3 KΩ @ 40°C - 104°F  
     0.4-0.7 KΩ @ 60°C - 140°F  
     0.2-0.4 KΩ @ 80°C - 176°F

**E 9 (B), E10 (A) ENGINE CONTROL MODULE**

BATT-E1: ALWAYS 9-14 VOLTS  
 IGSW-E1: 9-14 VOLTS WITH THE IGNITION SW ON  
     +B-E: 9-14 VOLTS WITH THE IGNITION SW ON  
 IDL1-E1: 0-1.5 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED  
     9-14 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN  
 VTA1-E1: 0.3-0.8 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED  
     3.2-4.9 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN  
 STA-E1: 6-14 VOLTS WITH THE ENGINE CRANKING  
 M-REL-E1: 9-14 VOLTS WITH THE IGNITION SW ON  
 VCC-E1: 4.5-5.5 VOLTS WITH THE IGNITION SW ON  
 L-E1: APPROX. 7.5-14 VOLTS WITH THE SHIFT LEVER AT "L" POSITION  
 2-E1: APPROX. 7.5-14 VOLTS WITH THE SHIFT LEVER AT "2" POSITION  
 R-E1: APPROX. 7.5-14 VOLTS WITH THE SHIFT LEVER AT "R" POSITION

**0 1 O/D DIRECT CLUTCH SPEED SENSOR**

1-2: APPROX. 620 Ω:

**V11 VEHICLE SPEED SENSOR NO. 2 (ELECTRONICALLY CONTROLLED TRANSMISSION)**

1-2: APPROX. 620 Ω:

**E 8 ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW**

4-3: CLOSED WITH ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW AT MANUAL POSITION

## : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 5	24(2JZ-GTE)	E 3	24(2JZ-GTE)	0 5	29
C 3	24(2JZ-GTE)	E 8	29	P 2	25(2JZ-GTE)
C10	B 28	E 9	B 29	S 5	25
C11	A 28	E10	A 29	S11	29
C12	C 28	I19	29	T 2	25(2JZ-GTE)
C16	28	J 1	29	T 6	29
D 1	24(2JZ-GTE)	J 2	29	T14	25
D 5	28	K 4	29	V10	25(2JZ-GTE)
E 1	24(2JZ-GTE)	M 1	25	V11	25(2JZ-GTE)
E 2	24(2JZ-GTE)	0 1	25		

## : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
IE	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

# AND A/T INDICATOR (2JZ-GTE)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	<a href="#">32(2JZ-GTE)</a>	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA2	<a href="#">32</a>	
IB1	<a href="#">36</a>	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IF3	<a href="#">36</a>	INSTRUMENT PANEL AND COWL WIRE (RIGHT KICK PANEL)
II1	<a href="#">38</a>	ENGINE WIRE AND INSTRUMENT PANEL (RIGHT KICK PANEL)
IJ1	<a href="#">38</a>	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		


 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	<a href="#">32(2JZ-GTE)</a>	FRONT SIDE OF LEFT FENDER
ED	<a href="#">32(2JZ-GTE)</a>	REAR SIDE OF INTAKE MANIFOLD
IE	<a href="#">36</a>	LEFT KICK PANEL
IF		
IH	<a href="#">36</a>	RIGHT KICK PANEL


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 7	<a href="#">32</a>	ENGINE ROOM MAIN WIRE	E17	<a href="#">32</a>	ENGINE WIRE
E10	<a href="#">32</a>	ENGINE WIRE	I14	<a href="#">38</a>	INSTRUMENT PANEL WIRE
E13			I17	<a href="#">38</a>	ENGINE WIRE
E14			I18	<a href="#">38</a>	COWL WIRE
E16			I21	<a href="#">38</a>	INSTRUMENT PANEL WIRE


A 5 GRAY




C 3 DARK GRAY




C10 (B) BLUE




C11 (A) BROWN




C12 (C)




C16 GREEN



D 1 BLACK




D 5 DARK GRAY



E 1 DARK GRAY




E 2 GRAY




E 3 DARK GRAY




E 8




E9 DARK GRAY




E10 DARK GRAY



I19



J1




(HINT: SEE PAGE 7)

J2



(HINT: SEE PAGE 7)


K4 BLACK




M1 BLACK




O1 BLACK




O5 BLUE




P2 GRAY




S5 BLACK




S11 BLUE




T2 BLACK



T6




T14 BLACK



V10 BLACK




V11 BLACK









FROM POWER SOURCE SYSTEM (SEE PAGE 56)





# AND A/T INDICATOR (2JZ-GE)





# AND A/T INDICATOR (2JZ-GE)





# AND A/T INDICATOR (2JZ-GE)

## SYSTEM OUTLINE

THIS SYSTEM ELECTRICALLY CONTROLS THE LINE PRESSURE, THROTTLE PRESSURE, LOCK-UP PRESSURE AND ACCUMULATOR PRESSURE ETC. THROUGH THE SOLENOID VALVE. THE ELECTRONICALLY CONTROLLED TRANSMISSION IS A SYSTEM WHICH PRECISELY CONTROLS GEAR SHIFT TIMING AND LOCK-UP TIMING IN RESPONSE TO THE VEHICLE'S DRIVING CONDITIONS AND THE ENGINE OPERATING CONDITIONS DETECTED BY VARIOUS SENSORS, MAKING SMOOTH DRIVING POSSIBLE BY SHIFT SELECTION FOR EACH GEAR WHICH IS THE MOST APPROPRIATE TO THE DRIVING CONDITIONS AT THAT TIME, AND CONTROLS THE ENGINE TORQUE DURING SHIFTING TO ACHIEVE OPTIMUM SHIFT FEELING.

### 1. GEAR SHIFT OPERATION

WHEN DRIVING, THE ENGINE WARM UP CONDITION IS INPUT AS A SIGNAL TO **TERMINAL (B) 44** OF THE ENGINE CONTROL MODULE FROM THE ENGINE COOLANT TEMP. SENSOR AND THE VEHICLE SPEED SIGNAL FROM VEHICLE SPEED SENSOR NO. 2 IS INPUT **TERMINAL (B) 23** OF THE ENGINE CONTROL MODULE. AT THE SAME TIME, THE THROTTLE VALVE OPENING SIGNAL FROM THE THROTTLE POSITION SENSOR IS INPUT TO **TERMINAL (B) 43** OF THE ENGINE CONTROL MODULE AS THROTTLE ANGLE SIGNAL.

BASED ON THESE SIGNALS, THE ENGINE CONTROL MODULE SELECTS THE BEST SHIFT POSITION FOR DRIVING CONDITIONS AND SENDS CURRENT TO THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOIDS.

WHEN SHIFTING TO 1ST SPEED, THE CURRENT FLOWS FROM **TERMINAL (B) 10** OF THE ENGINE CONTROL MODULE → **TERMINAL 1** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID . → **GROUND** AND CONTINUITY TO NO. 1 SOLENOID CAUSES THE SHIFT (NO. 2 SOLENOID DOES NOT HAVE CONTINUITY AT THIS TIME.)

FOR 2ND SPEED, THE CURRENT FLOWS SIMULTANEOUSLY FROM **TERMINAL (B) 9** OF THE ENGINE CONTROL MODULE → **TERMINAL 2** OF ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND FROM **TERMINAL (B) 10** OF THE ENGINE CONTROL MODULE → **TERMINAL 1** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, AND CONTINUITY TO NO. 1 AND NO. 2 SOLENOIDS CAUSES THE SHIFT.

FOR 3RD SPEED, THERE IS NO CONTINUITY TO NO. 1 SOLENOID, ONLY TO NO. 2 SOLENOID, CAUSING THE SHIFT. SHIFTING INTO THE 4TH SPEED (OVERDRIVE) OCCURS WHEN NO CURRENT FLOWS TO NO. 1 AND NO. 2 SOLENOIDS.

### 2. LOCK-UP OPERATION

WHEN THE ENGINE CONTROL MODULE JUDGES FROM EACH SIGNAL THAT LOCK-UP OPERATION CONDITIONS HAVE BEEN MET, THE CURRENT FLOWS FROM **TERMINAL (B) 8** OF THE ENGINE CONTROL MODULE → **TERMINAL 3** OF THE ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID → **GROUND**, CAUSING CONTINUITY TO THE LOCK-UP SOLENOID AND CAUSING LOCK-UP OPERATION.

### 3. STOP LIGHT SW CIRCUIT

IF THE BRAKE PEDAL IS DEPRESSED (STOP LIGHT SW ON) WHEN DRIVING IN LOCK-UP CONDITION, A SIGNAL IS INPUT TO **TERMINAL(A) 4** OF THE ENGINE CONTROL MODULE. THE ENGINE CONTROL MODULE OPERATES AND CUTS THE CURRENT TO THE SOLENOID TO RELEASE LOCK-UP.

### 4. OVERDRIVE CIRCUIT

#### \* O/D MAIN SW ON

WHEN THE O/D MAIN SW IS TURNED ON (SW POINT IS OPEN), A SIGNAL IS INPUT TO **TERMINAL (A) 28** OF THE ENGINE CONTROL MODULE AND THE ELECTRONICALLY CONTROLLED TRANSMISSION CAUSES SHIFT TO OVERRIDE WHEN THE CONDITIONS FOR OVERDRIVE ARE MET.

#### \* O/D MAIN SW OFF

WHEN THE O/D MAIN SW IS TURNED OFF (SW POINT IS CLOSED). THE CURRENT FLOWING THROUGH THE O/D OFF INDICATOR LIGHT FLOWS TO **GROUND** BY WAY OF THE O/D MAIN SW AND CAUSES THE O/D OFF INDICATOR LIGHT TO LIGHT UP. AT THE SAME TIME, A SIGNAL IS INPUT TO **TERMINAL (A) 28** OF THE ENGINE CONTROL MODULE AND THE ELECTRONICALLY CONTROLLED TRANSMISSION PREVENTS SHIFT INTO OVERDRIVE.

### 5. ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW CIRCUIT

WHEN THE ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW IS SWITCHED FROM **NORMAL** TO **MANUAL**, A SIGNAL IS INPUT TO **TERMINAL (A) 18** OF THE ENGINE CONTROL MODULE. INPUT OF THIS SIGNAL CAUSES CURRENT TO FLOW FROM THE **GAUGE FUSE** TO **TERMINAL (A) 1** OF THE COMBINATION METER → **TERMINAL (A) 12** → **TERMINAL (A) 25** OF THE ENGINE CONTROL MODULE → **GROUND**, LIGHTING UP THE INDICATOR LIGHT. IF THE A/T SHIFT LEVER IS THEN SHIFTED TO "2" POSITION, THE ENGINE CONTROL MODULE ENABLES THE VEHICLE TO START OFF WITH THE TRANSMISSION IN 2ND GEAR, THUS PERMITTING EASING STARTING OFF AND DRIVING ON SLIPPERY ROADS.

### 6. CRUISE CONTROL

WHEN CRUISE CONTROL OPERATION IS SELECTED A SIGNAL IS INPUT TO **TERMINAL (A) 12** OF THE ENGINE CONTROL MODULE FROM CRUISE CONTROL ECU. AS A RESULT, THE ENGINE CONTROL MODULE OPERATES AND CONTROLS OVERDRIVE, LOCK-UP AND SO ON FOR SMOOTH DRIVING.

## SERVICE HINTS

**E2 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID**

1, 2, 3-GROUND : EACH 11-15 Ω

**E 3 ENGINE COOLANT TEMP. SENSOR**

4-7 K- μ0•C 32•F)

2-3 K- μ20•C 68•F)

0-9.3 K- μ40•C 104•F)

0-4.7 K- μ60•C 140•F)

0-2.4 K- μ80•C 176•F)

**E 9 (B), E10 (A) ENGINE CONTROL MODULE**

BATT-E1: ALWAYS 9-14 VOLTS

IGSW-E1: 9-14 VOLTS WITH THE IGNITION SW ON

+B-E1: 9-14 VOLTS WITH THE IGNITION SW ON

IDL1-E1: 0-1.5 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED

: 9-14 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN

VTA1-E1: 0.3-0.8 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED

3.2-4.9 VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN

STA-E1: 6-14 VOLTS WITH THE ENGINE CRANKING

M-REL-E1: 9-14 VOLTS WITH THE IGNITION SW ON

VCC-E1: 4.5-5.5 VOLTS WITH THE IGNITION SW ON

L-E1: 7.5-14 VOLTS WITH THE SHIFT LEVER AT "L" POSITION

2-E1: 7.5-14 VOLTS WITH THE SHIFT LEVER AT "2" POSITION

**V11 VEHICLE SPEED SENSOR NO. 2 (ELECTRONICALLY CONTROLLED TRANSMISSION)**

1-2: APPROX. 620-

**E 8 ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW**4-3 : CLOSED WITH THE ELECTRONICALLY CONTROLLED TRANSMISSION PATTERN SELECT SW AT **MANUAL** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A4	26(2JZ-GE)	E 3	26(2JZ-GE)	0 5	29
C10	28	E 8	29	P 2	27(2JZ-GE)
C11	28	E 9	29	P 3	27(2JZ-GE)
C12	28	E10	29	S11	29
C16	28	I19	29	T 2	27(2JZ-GE)
D 1	26(2JZ-GE)	J 1	29	T 6	29
D 4	26	J 2	29	V10	27(2JZ-GE)
E 1	26(2JZ-GE)	K 4	29	V11	27(2JZ-GE)
E 2	26(2JZ-GE)	M 1	29		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		
1K		
2A	22	BATTERY AND J/B NO. 2 (ENGINE COMPARTMENT LEFT)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	34(2JZ-GE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA3	34	
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		

# AND A/T INDICATOR (2JZ-GE)


 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	34(2JZ-GE)	FRONT SIDE OF LEFT FENDER
ED	34(2JZ-GE)	REAR SIDE OF INTAKE MANIFOLD
IE	36	LEFT KICK PANEL
IF		
IH	36	RIGHT KICK PANEL


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E20	34	ENGINE WIRE	I14	38	INSTRUMENT PANEL WIRE
E23			I17	38	ENGINE WIRE
E26			I21	38	INSTRUMENT PANEL WIRE
E28					


A 5 GRAY




C10  BLUE




C11  BROWN




C12 



C16 GREEN



D 1 BLACK




D 4 BLACK



E 1 DARK GRAY




E 2 BLACK



E 3 GREEN




E 8







E 9 **B** DARK GRAY




E10 **A** DARK GRAY



I19




J 1




(HINT : SEE PAGE 7)

J 2




(HINT : SEE PAGE 7)


K 4 BLACK




M 1 BLACK



O 5 BLUE




P 2 GRAY



P 3 DARK GRAY




S11 BLUE



T 2 BLACK




T 6




V10 BLACK



V11 BLACK



A 6 (A) BLACK




A 7 (B) GRAY



A 8 (A) GRAY




A 9 (B) GRAY




A10, A11 GRAY



A18 (B)



A19 (A)




A31 GRAY




A32 GRAY




D 1 BLACK




D 5 DARK GRAY



S11 BLUE





T 5



# ABS (W/O TRACTION CONTROL)

FROM POWER SOURCE SYSTEM (SEE PAGE 56)





# ABS (W/O TRACTION CONTROL)

## SYSTEM OUTLINE

THIS SYSTEM CONTROLS THE RESPECTIVE BRAKE FLUID PRESSURES ACTING ON THE DISC BRAKE CYLINDERS OF THE RIGHT FRONT WHEEL, LEFT FRONT WHEEL AND REAR WHEELS WHEN THE BRAKES ARE APPLIED IN A PANIC STOP SO THAT THE WHEELS DO NOT LOCK. THIS RESULTS IN IMPROVED DIRECTIONAL STABILITY AND STEERABILITY DURING PANIC BRAKING.

### 1. INPUT SIGNALS

#### (1) SPEED SENSOR SIGNAL

THE SPEED OF THE WHEELS IS DETECTED AND INPUT TO **TERMINALS FL+, FR+, RL+ AND RR+** OF THE ABS ECU.

#### (2) STOP LIGHT SW SIGNAL

A SIGNAL IS INPUT TO **TERMINAL STP** OF THE ABS ECU WHEN THE BRAKE PEDAL IS DEPRESSED.

### 2. SYSTEM OPERATION

DURING SUDDEN BRAKING, THE ABS ECU WHICH HAS SIGNALS INPUT FROM EACH SENSOR CONTROLS THE CURRENT FLOWING TO THE SOLENOID INSIDE THE ACTUATOR AND LETS THE HYDRAULIC PRESSURE ACTING ON EACH WHEEL CYLINDER ESCAPE TO THE RESERVOIR. THE PUMP INSIDE THE ACTUATOR IS ALSO OPERATING AT THIS TIME AND IT RETURNS THE BRAKE FLUID FROM THE RESERVOIR TO THE MASTER CYLINDER, THUS PREVENTING LOCKING OF THE VEHICLE WHEELS.

IF THE ECU JUDGES THAT THE HYDRAULIC PRESSURE ACTING ON THE WHEEL CYLINDER IS INSUFFICIENT, THE CURRENT ACTING ON SOLENOID IS CONTROLLED AND THE HYDRAULIC PRESSURE IS INCREASED.

HOLDING OF THE HYDRAULIC PRESSURE IS ALSO CONTROLLED BY THE ECU, BY THE SAME METHOD AS ABOVE, BY REPEATED PRESSURE REDUCTION, HOLDING AND INCREASE ARE REPEATED TO MAINTAIN VEHICLE STABILITY AND TO IMPROVE STEERABILITY DURING SUDDEN BRAKING.

## SERVICE HINTS

### A 6 (A), A 7 (B) ABS ACTUATOR

(A) 1-GROUND : ALWAYS CONTINUITY

(B) 5-(A) 4:33

(B) 1,(B) 2,(B) 4,(A) 4:APPROX. 8.8

(B) 5,(B) 6,(B) 8,(A) 4:APPROX. 4.3

### A10, A11 ABS SPEED SENSOR FRONT LH, RH

1-2:1.4-1.8 K (20•C, 68•F)

### A31, A32 ABS SPEED SENSOR REAR LH, RH

1-2:0.9-1.3 K (20•C, 68•F)

### A18, (B), A19(A) ABS ECU

(B) 2-GROUND :10-14 VOLTS WITH THE IGNITION SW ON

(B)12-GROUND :10-14 VOLTS WITH THE STOP LIGHT SW ON (BRAKE PEDAL DEPRESSED)

(A) 2, (A) 13-GROUND :ALWAYS CONTINUITY

(A) 1, (A) 4, (A) 10, (A) 11, (A) 21, (A) 22-GROUND:10-14 VOLTS WITH THE IGNITION SW ON

### S11 STOP LIGHT SW

1-2:CLOSED WITH THE BRAKE PEDAL DEPRESSED

## : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 6	A 26(2JZ-GE)	A11	26(2JZ-GE)	D 1	26(2JZ-GE)
A 7	B 26(2JZ-GE)	A18	B 28	D 5	28
A 8	A 26	A19	A 28	S11	29
A 9	B 26	A31	30	T 5	29
A10	26(2JZ-GE)	A32	30		

## : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	34(2JZ-GE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB5	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IB6		
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL))
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)

 : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
EA	34(2JZ-GE)	FRONT SIDE OF RIGHT FENDER
ED	34(2JZ-GE)	REAR SIDE OF INTAKE FENDER
IG	36	RIGHT KICK PANEL


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E18	34	ENGINE ROOM MAIN WIRE	I 4	38	COWL WIRE
I 2	38	COWL WIRE	I 9		

# ABS W/ TRACTION CONTROL

FROM POWER SOURCE SYSTEM (SEE PAGE 56)









# ABS (W/ TRACTION CONTROL)

## SYSTEM OUTLINE

THIS SYSTEM CONTROLS THE RESPECTIVE BRAKE FLUID PRESSURES ACTING ON THE DISC BRAKE CYLINDERS OF THE RIGHT FRONT WHEEL, LEFT FRONT WHEEL, RIGHT REAR WHEEL AND LEFT REAR WHEEL WHEN THE BRAKES ARE APPLIED IN A PANIC STOP SO THAT THE WHEELS DO NOT LOCK.

THIS RESULTS IN IMPROVED DIRECTIONALLY STABILITY AND STEERABILITY DURING PANIC BRAKING.

### 1. INPUT SIGNALS

#### (3) SPEED SENSOR SIGNAL

THE SPEED OF THE WHEELS IS DETECTED AND INPUT TO **TERMINALS FL+, FR+, RL+ AND RR+** OF THE ABS ECU.

#### (4) STOP LIGHT SW SIGNAL

A SIGNAL IS INPUT TO **TERMINAL STP** OF THE ABS ECU WHEN THE BRAKE PEDAL IS DEPRESSED.

#### (5) DECELERATION SENSOR SIGNAL

LONGITUDINAL AND LATERAL ACCELERATION IS DETECTED AND INPUT TO THE ABS ECU.

### 2. SYSTEM OPERATION

DURING SUDDEN BRAKING, THE ABS ECU WHICH HAS SIGNALS INPUT FROM EACH SENSOR CONTROLS THE CURRENT FLOWING TO THE SOLENOID INSIDE THE ACTUATOR AND LETS THE HYDRAULIC PRESSURE ACTING ON EACH WHEEL CYLINDER ESCAPE TO THE RESERVOIR. THE PUMP INSIDE THE ACTUATOR IS ALSO OPERATING AT THIS TIME AND IT RETURNS THE BRAKE FLUID FROM THE RESERVOIR TO THE MASTER CYLINDER, THUS PREVENTING LOCKING OF THE VEHICLE WHEELS.

IF THE ECU JUDGES THAT THE HYDRAULIC PRESSURE ACTING ON THE WHEEL CYLINDER IS INSUFFICIENT, THE CURRENT ACTING ON SOLENOID IS CONTROLLED AND THE HYDRAULIC PRESSURE IS INCREASED.

HOLDING OF THE HYDRAULIC PRESSURE IS ALSO CONTROLLED BY THE ECU, BY THE SAME METHOD AS ABOVE, BY REPEATED PRESSURE REDUCTION, HOLDING AND INCREASE ARE REPEATED TO MAINTAIN VEHICLE STABILITY AND TO IMPROVE STEERABILITY DURING SUDDEN BRAKING.

## SERVICE HINTS

### A20 (A), A21 (B) ABS ECU

(A) 13-GROUND: **10-14** VOLTS WITH THE IGNITION SW AT ON POSITION

(A) 5-GROUND: **10-14** VOLTS WITH THE STOP LIGHT SW ON

(A) 12, (A) 25-GROUND: ALWAYS CONTINUITY

### A 6 (A), A 7 (B) ABS ACTUATOR

(A) 1-GROUND: ALWAYS CONTINUITY

(A) 5-(A) **4.33**  $\Omega$

(B) 1, (B) 2, (B) 3, (B) 4- (A) 4,: APPROX. **8 8**  $\Omega$

(B) 5, (B) 6, (B) 7, (B) 8- (A) 4,: APPROX. **4.3**  $\Omega$

### S11 STOP LIGHT SW

2-1: CLOSED WITH THE BRAKE PEDAL DEPRESSED

### A10, A11 ABS SPEED SENSOR FRONT LH, RH

1-2: 0.4-1.8 K  $\Omega$  (**20°C, 68°F**)

### A31, A32 ABS SPEED SENSOR REAR LH, RH

1-2: 0.9-1.3 K  $\Omega$  (**20°C, 68°F**)

 : PARTS LOCATION

CODE		SEE PAGE	CODE		SEE PAGE	CODE	SEE PAGE
A 6	A	<a href="#">24(2JZ-GTE)</a>	A21	B	<a href="#">28</a>	D 5	<a href="#">28</a>
A 7	B	<a href="#">24(2JZ-GTE)</a>	A23		<a href="#">28</a>	E10	<a href="#">29</a>
A10		<a href="#">24(2JZ-GTE)</a>	A31		<a href="#">30</a>	S11	<a href="#">29</a>
A11		<a href="#">24(2JZ-GTE)</a>	A32		<a href="#">30</a>	T 5	<a href="#">29</a>
A20	A	<a href="#">28</a>	D 1		<a href="#">24(2JZ-GTE)</a>	T16	<a href="#">29</a>

 : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	<a href="#">22</a>	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
5	<a href="#">23</a>	R/B NO. 5 (ENGINE COMPARTMENT RIGHT)

 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	<a href="#">20</a>	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	<a href="#">20</a>	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	<a href="#">20</a>	COWL WIRE AND NO. 1 (LEFT KICK PANEL)
1K	<a href="#">20</a>	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	<a href="#">32(2JZ-GTE)</a>	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
IB2	<a href="#">36</a>	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB5	<a href="#">36</a>	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IB6		
IC2	<a href="#">36</a>	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IF1	<a href="#">36</a>	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
II1	<a href="#">38</a>	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	<a href="#">38</a>	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)


 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	<a href="#">36</a>	LEFT KICK PANEL
IG	<a href="#">36</a>	RIGHT KICK PANEL


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 2	<a href="#">38</a>	COWL WIRE	I 9	<a href="#">38</a>	COWL WIRE
I11			I18		

A 6 (A) BLACK



A 7 (B) GRAY




A10 GRAY




A11 GRAY




A20 (A)




A21 (B)



A23




A31 GRAY




A32 GRAY




D 1 BLACK




D 5 DARK GRAY




E10 DARK GRAY




S11 BLUE



T 5



T16



## SYSTEM OUTLINE

TRACTION CONTROL IS THE SYSTEM TO REALIZE A FAVORABLE ACCELERATOR CONTROLABILITY BY MAKING THE ENGINE OUTPUT MOST APPROPRIATE FOR THE ACCELERATION UNDER EACH DRIVING CONDITION PROVIDED BY THE THROTTLE ECU.

(TRACTION OFF SW)

THIS IS THE SWITCH TO STOP THE OPERATION OF SLIP CONTROL. AFTER STARTING THE ENGINE, PRESSING THE SWITCH ONE TIME UNDER THE CONDITION THAT THE SNOW INDICATOR DOES NOT LIGHT ON, MAKES IT IN THE OPERATION STOP CONDITION (OFF), AND PRESSING IT ONE MORE TIME MAKES IT IN THE OPERATION WAITING CONDITION. IN ADDITION, RESTARTING AFTER THE ENGINE STOP MAKES IT IN THE OPERATION WAITING CONDITION WITHOUT CONCERNING THE TRACTION OFF SW.

(SNOW MODE SW)

THIS IS THE SWITCH TO FIX LOW  $\mu$  LOADS CONTROL AT THE TIME OF DRIVING ON A SLIPPERY ROAD SUCH AS SNOWY ROAD. AFTER STARTING THE ENGINE, PRESSING THE SWITCH MAKES IT FIX AT LOW  $\mu$  LOAD CONTROL AND SNOW INDICATOR LIGHT COMES ON. IN ADDITION, RESTARTING AFTER THE ENGINE STOP MAKES IT ALWAYS IN NORMAL CONDITION (AUTO MODE) WITHOUT CONCERNING THE SNOW MODE SW CONDITION. PRESSING THE SNOW MODE SW UNDER OPERATION PROHIBITION CONDITION OF THE TRACITION (TRAC OFF INDICATOR LIGHTS ON.) CANCELS THE OPERATION PROHIBITION OF THE TRACTION AND ALSO FIXES IT AT LOW  $\mu$  LOAD CONTROL.

(TRAC OFF INDICATOR LIGHT)

THIS LIGHT COMES ON BY SELECTING THE OPERATION STOP CONDITION OF THE TRACTION CONTROL WITH TRACTION OFF SW AND ALERTS THE DRIVER TO BE IN OPERATION STOP CONDITION AND ALSO ALERTS THE DRIVER BY BLINKING IN CASE OF THE OCCURANCE OF THE SYSTEM MAULFUCTION.

## SERVICE HINTS

### T15 (A), T16 (B) THROTTLE ECU


- WT-E1: **0.3** VOLTS WITH THE IGNITION SW ON AND THE TRAC OFF INDICATOR LIGHT ON  
**9-14** VOLTS WITH THE IGNITION SW ON AND THE TRAC OFF INDICATOR LIGHT OFF
- IND-E1 : **0.3** VOLTS WITH THE IGNITION SW ON AND SLIP INDICATOR LIGHT ON  
: **9-14** VOLTS WITH THE IGNITION SW ON AND SLIP INDICATOR LIGHT OFF
- CSW-E1: **0.3** VOLTS WITH THE IGNITION SW ON AND THE TRAC OFF SW HELDED ON PUSHING  
: **9-14** VOLTS WITH THE IGNITION SW ON AND THE TRAC OFF SW RELEASED
- SIND-E1 **0.3** VOLTS WITH THE IGNITION SW ON AND THE SNOW INDICATOR LIGHT ON  
**9-14** VOLTS WITH THE IGNITION SW ON AND THE SNOW INDICATOR LIGHT OFF
- SNOW-E1: **0.3** VOLTS WITH THE IGNITION SW ON AND THE SNOW MODE SW HELD ON PUSHING  
: **9-14** VOLTS WITH THE IGNITION SW ON AND THE SNOW MODE SW RELEASED
- NE-E1: PULSE GENERATION (ENGINE IDLING)
- TC-E1: **4.5-5.5** VOLTS WITH THE IGNITION SW ON AND THE ENGINE NOT RUNNING
- WA-E1: **9-14** VOLTS WITH THE IGNITION SW ON AND THE ABS ECU NORMAL CONDITION  
**0.3** VOLTS WITH THE IGNITION SW ON AND THE ABS ECU ABNORMAL CONDITION
- EFIB-E1 **9-14** VOLTS WITH THE IGNITION SW ON AND THE ENGINE NOT RUNNING
- IDL2-E1: **9-14** VOLTS WITH THE ENGINE RUNNING AND THE SUB THROTTLE VALVE FULLY OPEN  
**0-3** VOLTS WITH THE ENGINE RUNNING AND THE SUB THROTTLE VALVE FULLY CLOSED
- VTA2-E1: **3.2-4.9** VOLTS WITH THE ENGINE RUNNING AND THE SUB THROTTLE VALVE FULLY OPEN  
**0.3-0.8** VOLTS WITH THE ENGINE RUNNING AND THE SUB THROTTLE VALVE FULLY CLOSED
- BATT-E1: ALWAYS **9-14** VOLTS
- +B-E1: **9-14** VOLTS WITH THE IGNITION SW ON AND ENGINE NOT RUNNING
- IDL1-E1: **9-14** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN  
**0-3** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED
- VTA1-E1: **3.2- 4.9** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY OPEN  
**0.3-0.8** VOLTS WITH THE IGNITION SW ON AND THE THROTTLE VALVE FULLY CLOSED
- RLY+-RLY :**9-14** VOLTS WITH THE IGNITION SW ON
- A,A-,B,B+-EO1: PULSE GENERATION (ENGINE RUNNING AND THE THROTTLE VALVE FULLY CLOSED)
- EFI+,EFI-, ETC+,ETC--E1: PULSE GENERATION (IGNITION SW ON)

### T 8 TRACTION CONTROL SW


- 4-6** :CLOSED WITH THE TRACTIOIN CONTROL SW AT **OFF** POSITION
- 8-6** :CLOSED WITH THE TRACTIOIN CONTROL SW AT **SNOW** POSITION

### S18 SUB THROTTLE VALVE MOTOR

- 4-6, 3-1**:APPROX. **0.44**  $\Omega$



FROM POWER SOURCE SYSTEM (SEE PAGE 56)



# TRAC TRACTION CONTROL

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A20	28	E 9	B 29	T 5	29
C10	A 28	E10	A 29	T 8	29
C12	B 28	S 5	25(2JZ-GTE)	T15	A 29
D 1	24(2JZ-GTE)	S18	25(2JZ-GTE)	T16	B 29
D 5	28	T 2	25(2JZ-GTE)		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
5	23	R/B NO. 5 (ENGINE COMPARTMENT RIGHT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS















CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	32(2J2-GTE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
EA2		
IB5	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
I11	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	32(2JZ-GTE)	FRONT SIDE OF LEFT FENDER
EC	32(2JZ-GTE)	FRONT SIDE OF INTAKE MANIFOLD
ED	32(2JZ-GTE)	REAR SIDE OF INTAKE MANIFOLD
IE	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E16	32	ENGINE WIRE	I14	38	INSTRUMENT PANEL WIRE
I 2	38	COWL WIRE	I17	38	ENGINE WIRE
I11					











## SYSTEM OUTLINE

CURRENT IS APPLIED AT ALL TIMES THROUGH **STOP FUSE** TO **TERMINAL 1** OF THE CRUISE CONTROL ECU, **TERMINAL 2** OF THE STOP LIGHT SW, AND ALSO THROUGH THE **ECU-B FUSE** TO **TERMINAL 15** OF THE CRUISE CONTROL ECU.

WITH THE IGNITION SW TURNED TO ON, THE CURRENT FLOWS THROUGH GAUGE FUSE TO **TERMINAL (A) 9** OF THE COMBINATION METER AND THE CURRENT THROUGH **ECU-IG FUSE** FLOWS TO **TERMINAL 14** OF THE CRUISE CONTROL ECU.

WHEN THE IGNITION SW IS ON AND THE CRUISE CONTROL MAIN SWITCH IS TURNED ON, A SIGNAL IS INPUT FROM **TERMINAL 15** OF CRUISE CONTROL MAIN SW TO **TERMINAL 19** OF THE CRUISE CONTROL ECU. AS A RESULT, THE CRUISE CONTROL ECU FUNCTIONS AND THE CURRENT FLOWS THROUGH **TERMINAL 14** OF THE CRUISE CONTROL ECU TO **TERMINAL 13** OF THE CRUISE CONTROL ECU → **GROUND**, AND THE CRUISE CONTROL SYSTEM IS IN A CONDITION READY FOR OPERATION.

AT THE SAME TIME, THE CURRENT THROUGH THE **GAUGE FUSE** FLOWS TO **TERMINAL (A) 9** OF THE CRUISE CONTROL INDICATOR LIGHT → **TERMINAL (B) 6** → **TERMINAL 7** OF THE CRUISE CONTROL ECU → **TERMINAL 13** → **GROUND**, CAUSING THE CRUISE CONTROL INDICATOR LIGHT TO LIGHT UP, INDICATING THAT THE CRUISE CONTROL IS READY FOR OPERATION.

### 1. SET OPERATION

WHEN THE CRUISE CONTROL MAIN SW IS TURNED ON AND THE SET SW IS PUSHED WITH THE VEHICLE SPEED WITHIN THE SET LIMIT (APPROX. **40 KM/H, 25 MPH** TO **200 KM/H, 124 MPH**), A SIGNAL IS INPUT TO **TERMINAL 18** OF THE CRUISE CONTROL ECU AND THE VEHICLE SPEED AT THE TIME THE SET SW IS RELEASED, WHICH IS MEMORIZED IN THE ECU AS THE SET SPEED.

### 2. SET SPEED CONTROL

DURING CRUISE CONTROL DRIVING, THE ECU COMPARES THE SET SPEED MEMORIZED IN THE ECU WITH THE ACTUAL VEHICLE SPEED INPUTS INTO **TERMINAL 20** OF THE CRUISE CONTROL ECU FROM THE SPEED SENSOR, AND CONTROLS THE CRUISE CONTROL ACTUATOR TO MAINTAIN THE SET SPEED.

WHEN THE ACTUAL SPEED IS LOWER THAN THE SET SPEED, THE ECU CAUSES THE CURRENT TO THE CRUISE CONTROL ACTUATOR TO FLOW FROM **TERMINAL 12** → **TERMINAL 1** OF THE CRUISE CONTROL ACTUATOR → **TERMINAL 2** → **TERMINAL 11** OF THE CRUISE CONTROL ECU. AS A RESULT, THE MOTOR IN THE CRUISE CONTROL ACTUATOR IS ROTATED TO OPEN THE THROTTLE VALVE AND THE THROTTLE CABLE IS PULLED TO INCREASE THE VEHICLE SPEED. WHEN THE ACTUAL DRIVING SPEED IS HIGHER THAN THE SET SPEED, THE CURRENT TO CRUISE CONTROL ACTUATOR FLOWS FROM **TERMINAL 11** OF THE ECU → **TERMINAL 2** OF THE CRUISE CONTROL ACTUATOR → **TERMINAL 1** → **TERMINAL 12** OF THE CRUISE CONTROL ECU.

THIS CAUSES THE MOTOR IN THE CRUISE CONTROL ACTUATOR TO ROTATE TO CLOSE THE THROTTLE VALVE AND RETURN THE THROTTLE CABLE TO DECREASE THE VEHICLE SPEED.

### 3. COAST CONTROL

DURING THE CRUISE CONTROL DRIVING, WHILE THE COAST SW IS ON, THE CRUISE CONTROL ACTUATOR RETURNS THE THROTTLE CABLE TO CLOSE THE THROTTLE VALVE AND DECREASE THE DRIVING SPEED. THE VEHICLE SPEED WHEN THE COAST SWITCH IS TURNED OFF IS MEMORIZED AND THE VEHICLE CONTINUES AT THE NEW SET SPEED.

### 4. ACCEL CONTROL

DURING CRUISE CONTROL DRIVING, WHILE THE ACCEL SW IS TURNED ON, THE CRUISE CONTROL ACTUATOR PULLS THE THROTTLE CABLE TO OPEN THE THROTTLE VALVE AND INCREASE THE DRIVING SPEED.

THE VEHICLE SPEED WHEN THE ACCEL SW IS TURNED OFF IS MEMORIZED AND THE VEHICLE CONTINUES AT THE NEW SET SPEED.

### 5. RESUME CONTROL

UNLESS THE VEHICLE SPEED FALLS BELOW THE MINIMUM SPEED LIMIT (APPROX. **40 KM/H, 25 MPH**) AFTER CANCELING THE SET SPEED BY THE CANCEL SW, PUSHING THE RESUME SW WILL CAUSE THE VEHICLE TO RESUME THE SPEED SET BEFORE THE CANCELLATION.

### 6. MANUAL CANCEL MECHANISM

IF ANY OF THE FOLLOWING OPERATIONS OCCUR DURING CRUISE CONTROL OPERATION, THE MAGNETIC CLUTCH OF THE ACTUATOR TURNS OFF AND THE MOTOR ROTATES TO CLOSE THE THROTTLE VALVE AND THE CRUISE CONTROL IS RELEASED.

- \* PLACING THE SHIFT LEVER IN EXCEPT "D" POSITION (PARK/NEUTRAL POSITION SW EXCEPT "D" POSITION). "SIGNAL IS NOT INPUT TO **TERMINAL 2** OF THE ECU" (A/T)
- \* DEPRESSING THE BRAKE PEDAL (STOP LIGHT SW ON). "SIGNAL IS INPUT TO **TERMINAL 16** OF THE ECU"
- \* PUSHING THE CANCEL SWITCH (CANCEL SW ON). "SIGNAL IS INPUT TO **TERMINAL 18** OF THE ECU"
- \* DEPRESSING THE CLUTCH PEDAL (CRUISE CONTROL CLUTCH SW OFF). "SIGNAL IS NOT INPUT TO **TERMINAL 2** OF THE ECU"

## 7. AUTO CANCEL FUNCTION

A) IF ANY OF THE FOLLOWING OPERATING CONDITIONS OCCUR DURING CRUISE CONTROL OPERATION, THE SET SPEED IS ERASED, CURRENT FLOW TO MAGNETIC CLUTCH IS STOPPED AND THE CRUISE CONTROL IS RELEASED. (MAIN SW TURNS OFF).

WHEN THIS OCCURS, THE IGNITION SW MUST BE TURNED OFF ONCE BEFORE THE MAIN SW WILL TURN ON.

- \* OVER CURRENT TO TRANSISTOR DRIVING MOTOR AND/OR MAGNETIC CLUTCH.
- \* WHEN CURRENT CONTINUED TO FLOW TO THE MOTOR INSIDE THE ACTUATOR IN THE THROTTLE VALVE "OPEN" DIRECTION.
- \* OPEN CIRCUIT IN MAGNETIC CLUTCH.
- \* MOMENTARY INTERRUPTION OF VEHICLE SPEED SIGNAL.
- \* SHORT CIRCUIT IN CRUISE CONTROL SW.
- \* MOTOR DOES NOT OPERATE DESPITE THE MOTOR DRIVE SIGNAL BEING OUTPUT.

B) IF ANY OF THE FOLLOWING CONDITIONS OCCUR DURING CRUISE CONTROL OPERATION, THE SET SPEED IS ERASED AND THE CRUISE CONTROL IS RELEASED. (THE POWER OF MAGNETIC CLUTCH IS CUT OFF UNTIL THE SET SW IS "ON" AGAIN.)

- \* WHEN THE VEHICLE SPEED FALLS BELOW THE MINIMUM SPEED LIMIT, APPROX. **40** KM/H (**25** MPH)
- \* WHEN THE VEHICLE SPEED FALLS MORE THAN **16** KM/H (**10** MPH) BELOW THE SET SPEED, E.G. ON AN UPWARD SLOPE.
- \* WHEN POWER TO THE CRUISE CONTROL SYSTEM IS MOMENTARILY CUT OFF.

## 8. AUTOMATIC TRANSMISSION CONTROL FUNCTION

- \* IN OVERDRIVE. IF THE VEHICLE SPEED BECOMES LOWER THAN THE OVERDRIVE CUT SPEED (SET SPEED MINUS APPROX. **4** KM/H, **2.5** MPH) DURING CRUISE CONTROL OPERATION, SUCH AS DRIVING UP A HILL, THE OVERDRIVE IS RELEASED AND THE POWER INCREASED TO PREVENT A REDUCTION IN VEHICLE SPEED.
- \* AFTER RELEASING THE OVERDRIVE, VEHICLE SPEED BECOMES HIGHER THAN THE OVERDRIVE RETURN SPEED (SET SPEED MINUS APPROX. **2** KM/H, **1.2** MPH) AND THE ECU JUDGES BY THE SIGNALS FROM POTENTIOMETER OF THE ACTUATOR THAT THE UPWARD SLOPE HAS FINISHED, OVERDRIVE IS RESUMED AFTER APPROXIMATELY **2** SECONDS.
- \* DURING CRUISE CONTROL DRIVING, THE CRUISE CONTROL OPERATION SIGNAL IS OUTPUT FROM THE CRUISE CONTROL ECU TO THE ENGINE CONTROL MODULE. UPON RECEIVING THIS SIGNAL, THE ENGINE CONTROL MODULE CHANGES THE SHIFT PATTERN TO NORMAL. TO MAINTAIN SMOOTH CRUISE CONTROL OPERATION (ON A DOWNWARD SLOPE ETC.), LOCK-UP RELEASE OF THE TRANSMISSION WHEN THE IDLING POINT OF THE THROTTLE POSITION IS "ON" IS FORBIDDEN.

## SERVICE HINTS

### C 4 CRUISE CONTROL ACTUATOR

3-4 : APPROX. **38.5**  $\Omega$

### C14 CRUISE CONTROL SW [COMB. SW]

15-17 : CONTINUITY WITH THE MAIN SW ON

5-17 : APPROX. **418**  $\Omega$  WITH THE CANCEL SW ON

APPROX. **68**  $\Omega$  WITH THE RESUME/ACCEL SW ON

APPROX. **198**  $\Omega$  WITH THE SET/COAST SW ON

### C16 CRUISE CONTROL ECU

14-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION

15-GROUND : ALWAYS APPROX. **12** VOLTS

20-GROUND : **4** PULSE WITH **1** ROTATION OF ROTOR SHAFT

18-GROUND : APPROX. **418**  $\Omega$  WITH THE CANCEL SW ON IN CONTROL SW

APPROX. **198**  $\Omega$  WITH THE SET/COAST SW ON IN CONTROL SW

APPROX. **68**  $\Omega$  WITH THE RESUME/ACCEL SW ON IN CONTROL SW

13-GROUND : ALWAYS CONTINUITY



# CRUISE CONTROL

## : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 4	24 (2JZ-GTE)	D 1	26 (2JZ-GE)	S11	29
	26 (2JZ-GE)	D 5	28	T 2	25 (2JZ-GTE)
C10	A 28	E 2	A 24 (2JZ-GTE)		T 6
C12	B 28		B 26 (2JZ-GE)		
C14	28	E 9	B 29	V10	25 (2JZ-GTE)
C15	28	E10	A 29		27 (2JZ-GE)
C16	28	P 2	25 (2JZ-GTE)		
D 1	24 (2JZ-GTE)		17 (2JZ-GE)		

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I		
1J		

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS















CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB6	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ1	38	ENGINE WIRE AND COWL WIRE (RIGHT KICK PANEL)
IJ2		

## : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
IF		

## : SPLICE POINTS


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E14	32	ENGINE WIRE	I4	38	COWL WIRE
E16			I8	38	INSTRUMENT PANEL WIRE
E28	34	I14			
I2	38	COWL WIRE	I17	38	ENGINE WIRE






# CRUISE CONTROL


(2JZ-GE) E10 (A) DARK GRAY




P 2 GRAY




S11 BLUE




(2JZ-GTE) T 2 BLACK




(2JZ-GE) T 2 BLACK




T 6




V10 BLACK




C10 (A) BLUE



C12 (B)




P 1 GRAY




P 4 BLUE




T 6



V10 BLACK







## SYSTEM OUTLINE

THE PPS (HYDRAULIC REACTION TYPE) CONTROLS THE HYDRAULIC PRESSURE APPLIED TO THE HYDRAULIC REACTION CHAMBER IN THE GEAR BOX CONTROL UNIT USING THE PPS ECU, TO CHANGE THE STEERING FORCE AND PROVIDE OPTIMUM STEERING FEELING AT ANY VEHICLE SPEEDS AND UNDER ANY STEERING CONDITIONS.

### (PPS OPERATION)

WHEN THE IGNITION SW IS TURNED ON THE STARTING CURRENT FLOWS FROM THE **ECU-IG** FUSE TO **TERMINAL 4** OF THE PPS ECU. THE PPS ECU MONITORS VEHICLE SPEED, INPUT SIGNAL TO **TERMINAL 5** OF THE ECU. WHEN THE VEHICLE SPEED IS LOW, THE PPS ECU SENDS A HIGHER-CURRENT FROM **TERMINAL 1** OF THE ECU → **TERMINAL 1** OF THE SOLENOID VALVE → **TERMINAL 2** → **TERMINAL 2** OF THE ECU → **TERMINAL 6** → **GROUND**, INCREASING THE SOLENOID VALVE OPENING ANGLE TO PROVIDE COMFORTABLE STEERING OPERATION. WHEN THE VEHICLE SPEED IS HIGH, THE PPS ECU DECREASES THE SOLENOID VALVE OPENING ANGLE BY REDUCING THE CURRENT TO THE VALVE TO PROVIDE RESPONSIVE STEERING FEELING.

## SERVICE HINTS

### P1 PPS SOLENOID

1-2 : APPROX. 7.7 Ω (25•C, 77•F)

### P4 PPS ECU

4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

6-GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE		SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C10	A	28	P1	27 (2JZ-GE)	V10	25 (2JZ-GTE)
C12	B	28	P4	29		27 (2JZ-GE)
	P1	25 (2JZ-GTE)	T6	29		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

## ▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
IF	36	LEFT KICK PANEL
IH	36	RIGHT KICK PANEL

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I8	38	INSTRUMENT PANEL WIRE	I14	38	INSTRUMENT PANEL WIRE



# SHIFT LOCK



## SYSTEM OUTLINE

WHEN THE IGNITION SW IS TURNED TO **ACC** POSITION THE CURRENT FROM THE **CIG** FUSE FLOWS TO **TERMINAL 5** OF THE SHIFT LOCK ECU, IN THE ON POSITION, THE CURRENT FROM THE **ECU-IG** FUSE FLOWS TO **TERMINAL 1** OF THE ECU.

### 1. SHIFT LOCK MECHANISM

WITH THE IGNITION SW ON, WHEN A SIGNAL THAT THE BRAKE PEDAL IS DEPRESSED (STOP LIGHT SW ON) AND A SIGNAL THAT THE SHIFT LEVER IS PUT IN “**P**” POSITION (CONTINUITY BETWEEN P1 AND P OF THE SHIFT LOCK CONTROL SW) IS INPUT TO THE ECU, THE ECU OPERATES AND CURRENT FLOWS FROM **TERMINAL 1** OF THE ECU → **TERMINAL ‘SLS+’** OF THE SHIFT LOCK SOLENOID → **TERMINAL ‘SLS-’** → **TERMINAL 4** OF THE ECU → **GROUND**. THIS CAUSES THE SHIFT LOCK SOLENOID TO TURN ON (PLATE STOPPER DISENGAGES) AND THE SHIFT LEVER CAN SHIFT INTO POSITION OTHER THAN THE “**P**”.

### 2. KEY INTERLOCK MECHANISM

WITH THE IGNITION SW **ON** OR **ACC** POSITION, WHEN THE SHIFT LEVER IS PUT IN “**P**” POSITION (NO CONTINUITY BETWEEN P2 AND P OF SHIFT LOCK CONTROL SW), THE CURRENT FLOWING FROM **TERMINAL 6** OF THE ECU → KEY INTERLOCK SOLENOID IS CUT OFF. THIS CAUSES THE KEY INTERLOCK SOLENOID TO TURN OFF (LOCK LEVER DISENGAGES FROM **LOCK** POSITION) AND THE IGNITION KEY CAN BE TURNED FROM **ACC** TO **LOCK** POSITION.

## SERVICE HINTS

### S7 SHIFT LOCK ECU

- 5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 4-GROUND : ALWAYS CONTINUITY
- 2-GROUND : APPROX. 12 VOLTS WITH THE BRAKE PEDAL DEPRESSED

### S11 STOP LIGHT SW

- 2-1 : CLOSED WITH THE BRAKE PEDAL DEPRESSED

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
S7	29	S11	29	U1	29


## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		


## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL


S 7



S11 BLUE




U 1





# CIGARETTE LIGHTER AND CLOCK



## SERVICE HINTS

### C6 CIGARETTE LIGHTER

- 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 1-GROUND : ALWAYS CONTINUITY

### C8 CLOCK

- 2-GROUND : ALWAYS 12 VOLTS (POWER FOR CLOCK)
- 5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION  
(POWER FOR INDICATION)
- 3-GROUND : ALWAYS CONTINUITY

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C6	28	C8	28	J1	29

### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)


### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IH	36	RIGHT KICK PANEL


### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I8	38	INSTRUMENT PANEL WIRE			


C 6



C 8 GRAY




J 1



(HINT : SEE PAGE 7)



# REMOTE CONTROL MIRROR



## SERVICE HINTS

### R7 REMOTE CONTROL MIRROR SW

- 8-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 5-2 : CONTINUITY WITH THE OPERATION SW AT **LEFT** OR **UP** POSITION
- 8-5 : CONTINUITY WITH THE OPERATION SW AT **RIGHT** OR **DOWN** POSITION
- 2-GROUND : ALWAYS CONTINUITY

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
R7	29	R16	30	R17	30

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	36	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)


### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL


### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I5	38	INSTRUMENT PANEL WIRE			


R 7



R 1 6



R 1 7








# POWER SEAT

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



**SERVICE HINTS**

**P11 POWER SEAT CONTROL SW (DRIVER'S SEAT)**

2-GROUND : ALWAYS APPROX. 12 VOLTS  
 1-GROUND : ALWAYS CONTINUITY

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
P11	31	P12	31		

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)


**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
BQ1	42	FLOOR NO. 2 WIRE AND SEAT WIRE (UNDER THE FRONT LH SEAT)


**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
B1	40	LEFT QUARTER PILLAR

P11




P12





# SEAT HEATER (CANADA)

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



**SERVICE HINTS**

**S6 SEAT HEATER SW**

4-GROUND ; APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION  
 1-GROUND : ALWAYS CONTINUITY

**○ : PARTS LOCATION**

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
S6	29	S13	31	S15	31
S12	31	S14	31		

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC1	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
BQ1	42	FLOOR NO. 2 WIRE AND SEAT WIRE (UNDER THE FRONT LH SEAT)


**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
IG	36	RIGHT KICK PANEL
BI	40	LEFT QUARTER PILLAR


**○ : SPLICE POINTS**

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I11	38	COWL WIRE	B9	42	SEAT WIRE
I24					


S 6 BLACK




S 12 BLUE




S 13 BLUE



S 14




S 15





# UNLOCK AND SEAT BELT WARNING



## SYSTEM OUTLINE

CURRENT ALWAYS FLOWS TO **TERMINAL 1** OF THE INTEGRATION RELAY THROUGH **DOME FUSE**.

### 1. SEAT BELT WARNING SYSTEM

WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS FROM THE GAUGE FUSE TO **TERMINAL 7** OF THE INTEGRATION RELAY. AT THE SAME TIME, CURRENT FLOWS TO **TERMINAL 9** OF THE RELAY FROM THE **GAUGE FUSE** THROUGH THE SEAT BELT WARNING LIGHT. THIS CURRENT ACTIVATES THE INTEGRATION RELAY AND CURRENT FLOWING THROUGH THE WARNING LIGHT FLOW FROM **TERMINAL 9** OF THE RELAY → **TERMINAL 10** → **GROUND**, CAUSING THE WARNING LIGHT TO LIGHT UP. A BUCKLE SW OFF SIGNAL IS INPUT TO **TERMINAL 8** OF THE RELAY, THE CURRENT FLOWING TO **TERMINAL 7** OF THE RELAY FLOWS THROUGH **TERMINAL 10** → **GROUND** AND THE SEAT BELT WARNING BUZZER SOUNDS FOR APPROX. **4-8 SECONDS**. HOWEVER, IF THE SEAT BELT IS PUT ON DURING THIS PERIOD (WHILE THE BUZZER IS SOUNDING), SIGNAL INPUT TO **TERMINAL 8** OF RELAY STOPS AND THE CURRENT FLOW FROM **TERMINAL 7** OF THE RELAY → **TERMINAL 10** → **GROUND** IS CUT, CAUSING THE BUZZER TO STOP.

### 2. UNLOCK WARNING SYSTEM

WITH THE IGNITION KEY INSERTED IN THE KEY CYLINDER (UNLOCK SW ON), THE IGNITION SW STILL OFF AND DRIVER'S DOOR OPENS (DOOR COURTESY SW ON), WHEN A SIGNAL IS INPUT TO **TERMINAL 6** OF THE RELAY, THE INTEGRATION RELAY OPERATES, CURRENT FLOWS FROM **TERMINAL 7** OF THE RELAY → **TERMINAL 10** → **GROUND** AND UNLOCK WARNING BUZZER SOUNDS.

## SERVICE HINTS

### B6 BUCKLE SW LH

1-2 : CLOSED WITH THE DRIVER'S SEAT BELT IN USE

### D10 DOOR COURTESY SW LH

3-2 : CLOSED WITH THE LH DOOR OPEN

### U1 UNLOCK WARNING SW

2-1 : CLOSED WITH THE IGNITION KEY IN CYLINDER

### INTEGRATION RELAY

10-GROUND : ALWAYS CONTINUITY

6-GROUND : CONTINUITY WITH THE DRIVER'S DOOR OPEN

5-GROUND : CONTINUITY WITH THE IGNITION KEY IN CYLINDER

8-GROUND : CONTINUITY WITH THE DRIVER'S SEAT BELT IN USE

9-GROUND : **0** VOLTS WITH THE IGNITION SW ON AND BUCKLE SW OFF

1-GROUND : ALWAYS APPROX. **12** VOLTS

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B6	28	T6	29		
D10	30	U1	29		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
BI	40	LEFT QUARTER PILLAR


## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I7	38	FLOOR NO. 2 WIRE			




# UNLOCK AND SEAT BELT WARNING


B 6




D10



T 6




U 1







C14 BLACK



R15



W 1 BLACK








# REAR WIPER AND WASHER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



## SYSTEM OUTLINE

WHEN THE IGNITION SW IS TURNED ON, CURRENT FLOWS TO **TERMINAL 2** OF THE WASHER MOTOR, **TERMINAL 1** OF THE REAR WIPER MOTOR AND RELAY THROUGH THE **WIPER FUSE**.

### 1. REAR WIPER NORMAL OPERATION

WITH THE IGNITION SW TURNED ON AND REAR WIPER AND WASHER SW TURNED ON, THE CURRENT FLOWING TO **TERMINAL 1** OF THE REAR WIPER RELAY FLOWS TO **TERMINAL 3** OF THE RELAY → **TERMINAL 1** OF THE REAR WIPER AND WASHER SW → **TERMINAL 16** → TO **GROUND**. THUS, THE RELAY COIL IS ACTIVATED AND THE CURRENT TO **TERMINAL 1** OF THE RELAY FLOWS TO → **TERMIANL LH** → **TERMINAL LH** OF THE REAR WIPER MOTOR → MOTOR → TO **GROUND** AND CAUSES THE MOTOR TO OPERATE THE WIPER.

### 2. REAR WIPER INTERMITTENT OPERATION

WHEN THE IGNITION SW IS ON AND THE REAR WIPER AND WASHER SW IS TURNED TO **INT** POSITION, CURRENT FLOWING TO **TERMINAL 1** OF THE REAR WIPER MOTOR AND RELAY FLOWS TO **TERMINAL 2** OF THE RELAY → **TERMINAL 10** OF THE REAR WIPER AND WASHER SW → **TERMINAL 16** → **GROUND**.

THIS CAUSES THE MOTOR TO OPERATE (THE POINT CHANGES) AND THE INTERMITTENT CIRCUIT OF THE RELAY OPERATES. INTERMITTENT OPERATION OF THE CIRCUIT IS CONTROLLED BY THE CHANGING AND DISCHARGING OF THE CONDENSER INSTALLED INSIDE THE RELAY.

### 3. WASHER OPERATION

WITH THE IGNITION SW TURNED ON AND THE REAR WIPER AND WASHER SW TURNED TO **ON** POSITION, WHEN THE WIPER SW IS TURNED FURTHER, THE CURRENT FLOWING TO **TERMINAL 2** OF THE WASHER MOTOR FLOWS TO **TERMINAL 3** OF THE MOTOR → **TERMINAL 2** OF THE REAR WIPER AND WASHER SW → **TERMINAL 16** → TO **GROUND**, SO THAT THE WASHER MOTOR ROTATES AND THE WINDOW WASHER EJECTS THE SPRAY, ONLY WHILE THE SWITCH IS FULLY TURNED.

WHEN THE WIPER SW IS OFF AND THEN TURNED TO WASHER ON (WIPER OFF SIDE), ONLY THE WASHER OPERATES.

## SERVICE HINTS

### W1 WASHER MOTOR

2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

3-GROUND : CONTINUITY WITH THE WASHER SW TURNED ON

### R15 REAR WIPER MOTOR AND RELAY

1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

2-GROUND : CONTINUITY WITH THE REAR WIPER SW AT **INT** POSITION

3-GROUND : CONTINUITY WITH THE REAR WIPER SW AT **ON** POSITION

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C14	28	W1	25 (2JZ-GTE)		
R15	30		27 (2JZ-GE)		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LET KICK PANEL)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
BM1	40	BACK DOOR NO. 1 WIRE AND FLOOR NO. 2 WIRE (LEFT SIDE OF PACKAGE TRAY TRIM)
BO1	40	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE (BACK DOOR UPPER LEFT)

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E9	32	ENGINE ROOM MAIN WIRE	E21	34	ENGINE ROOM MAIN WIRE

NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.


- Malfunction symptoms of the supplemental restraint system are difficult to confirm, so the diagnostic trouble codes become the most important source of information when troubleshooting.  
When troubleshooting the supplemental restraint system, always inspect the diagnostic trouble codes before disconnecting the battery.
- Work must be started after 90 seconds from the time the Ignition SW is set to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.  
(The supplemental restraint system is equipped with a back-up power source so that if work is started within 90 seconds of disconnecting the negative (-) terminal cable of the battery, the SRS may be activated.)  
When the negative (-) terminal cable is disconnected from the battery, memory of the clock and audio systems will be cancelled. So before starting work, make a record of the contents memorized by each memory system. When work is finished, reset the clock and audio system as before and adjust the clock.  
To avoid erasing the memory of each memory system, never use a back-up power supply from outside the vehicle.
- When removing the steering wheel pad or handling a new steering wheel pad, keep the pad upper surface facing upward. Also, lock the lock lever of the twin lock type connector at the rear of the pad and take care not to damage the connector.  
(Storing the pad with its metallic surface up may lead to a serious accident if the SRS inflates for some reason.)
- Always store a removed or new front passenger airbag assembly with the airbag door facing up. Storing the airbag assembly with the airbag door facing down could cause a serious accident if the airbag inflates.
- Store the steering wheel pad where the ambient temperature remains below 93°C (200°F), without high humidity and away from electrical noise.
- Never use SRS parts from another vehicle. When replacing SRS parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly, airbag sensor assembly.
- Before repairing the body, remove the airbag sensors if during repair shocks are likely to be applied to the sensors due to vibration of the body or direct tapping with tools or other parts.
- Do not reuse a steering wheel pad.  
After evaluating whether the airbag sensor assembly is damaged or not, decide whether or not to reuse it.  
(See the Repair Manual for the method for evaluating the airbag sensor assembly.)
- When troubleshooting the supplemental restraint system, use a high-impedance (Min. 10 kΩ/V) tester.
- The wire harness of the supplemental restraint system is integrated with the cowl wire harness assembly. The vehicle wiring harness exclusively for the airbag system is distinguished by corrugated yellow tubing, as are the connectors.
- Do not measure the resistance of the airbag squibs.  
(It is possible this will deploy the airbag and is very dangerous.)
- If the wire harness used in the supplemental restraint system is damaged, replace the whole wire harness assembly.
- INFORMATION LABELS (NOTICES) are attached to the periphery of the SRS components. Follow the instructions on the notices.



The SRS has connectors which possess the functions described below:


**1. SRS ACTIVATION PREVENTION MECHANISM**

Each connector contains a short spring plate. When the connector is disconnected, the short spring plate automatically connects the power source and grounding terminals of the squib to preclude a potential difference between the terminals.




**2. ELECTRICAL CONNECTION CHECK MECHANISM**


This mechanism is designed to electrically check if connectors are connected correctly and completely. The electrical connection check mechanism is designed so that the disconnection detection pin connects with the diagnosis terminals when the connector housing lock is in to locked condition.



### 3. CONNECTOR TWIN-LOCK MECHANISM

With this mechanism connectors (male and female connectors) are locked by two locking devices to increase connection reliability. If the primary lock is incomplete, ribs interfere and prevent the secondary lock.





## SYSTEM OUTLINE

THE SRS IS A DRIVER AND PASSENGER PROTECTION DEVICE WHICH HAS A SUPPLEMENTAL ROLE TO THE SEAT BELTS.

WHEN THE IGNITION SW IS TURNED TO ACC OR ON, THE CURRENT FROM THE **CIG** FUSE FLOWS TO **TERMINAL 16** OF THE AIRBAG SENSOR ASSEMBLY. ONLY WHEN THE IGNITION SW IS ON DOES THE CURRENT FROM THE **IGN** FUSE FLOW TO **TERMINAL 15** OF THE AIRBAG SENSOR ASSEMBLY.

IF AN ACCIDENT OCCURS WHILE DRIVING, DECELERATION CAUSED BY A FRONTAL IMPACT IS DETECTED BY THE SENSOR IN THE AIRBAG SENSOR ASSEMBLY, AND WHEN THE FRONTAL IMPACT EXCEEDS A SET LEVEL (WHEN THE SAFING SENSOR BUILT INTO THE AIRBAG SENSOR ASSEMBLY IS ON, THE FLOOR SENSOR BUILT INTO THE AIRBAG SENSOR ASSEMBLY IS ON AND THE AIRBAG SENSOR ASSEMBLY IS ON), THE CURRENT FROM THE **CIG** OR THE **IGN** FUSE FLOWS THROUGH THE AIRBAG SENSOR ASSEMBLY TO **TERMINALS 7** AND **3** OF THE AIRBAG SENSOR ASSEMBLY TO **TERMINAL 1** OF THE AIRBAG SQUIB → **TERMINAL 2** → **TERMINALS 6** AND **2** OF THE AIRBAG SENSOR ASSEMBLY → THE FLOOR SENSOR BUILT INTO THE AIRBAG SENSOR ASSEMBLY → **TERMINAL 9**, **TERMINAL 10** OR **BODY GROUND** → **GROUND**. WHEN THE SAFING SENSOR BUILT INTO THE AIRBAG SENSOR ASSEMBLY IS ON, AND FLOOR SENSOR BUILT INTO THE AIRBAG SENSOR ASSEMBLY IS ON, ONE OF THE ABOVE-MENTIONED CIRCUITS IS ACTIVATED SO THAT THE CURRENT FLOWS TO THE AIRBAG SQUIBS, CAUSING IT TO OPERATE.

THE AIRBAG STORED INSIDE THE STEERING WHEEL PAD IS INSTANTANEOUSLY EXPANDED TO SOFTEN THE SHOCK TO A DRIVER.

SIMULTANEOUSLY, THE AIRBAG STORED INSIDE THE PASSENGER'S INSTRUMENT PANEL IS INSTANTANEOUSLY EXPANDED TO SOFTEN THE SHOCK TO A PASSENGER.

### : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A27	28	D1	24 (2JZ-GTE)	T6	29
A28	28		26 (2JZ-GE)		
A34	28	D5	28		

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1G	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS







CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

### : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL

### : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I5	38	INSTRUMENT PANEL WIRE	I14	38	INSTRUMENT WIRE


**A27 YELLOW**

**A28 YELLOW**

**C 5 YELLOW**

**D 1 BLACK**

**D 5 DARK GRAY**

**T 6**






# ELECTRIC TENSION REDUCER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



**SERVICE HINTS**

**B6 BUCKLE SW LH**

1-2 : CLOSED WITH THE DRIVER'S SEAT BELT IN USE

**B7 BUCKLE SW RH**

1-2 : CLOSED WITH THE FRONT PASSENGER'S SEAT BELT IN USE

**T11, T12 TENSION REDUCER SOLENOID LH, RH**

1-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

 : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
B6	28	T11	30		
B7	28	T12	30		


 : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1I	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		


 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IG	36	RIGHT KICK PANEL
BI	40	LEFT QUARTER PILLAR


B 6




B 7



T 11




T 12





# REAR WINDOW DEFOGGER AND MIRROR HEATER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



## SERVICE HINTS

### REAR WINDOW DEFOGGER RELAY

(4) 3- (4) 5 : CLOSED WITH THE IGNITION SW AT **ON** POSITION AND THE REAR WINDOW SW [HEATER CONTROL SW] **ON**

#### ○ : PARTS LOCATION

CODE		SEE PAGE	CODE		SEE PAGE	CODE		SEE PAGE
A13	B	28	N 2		29	R18	B	30
A14	A	28	N 3	A	30	R19	C	30
H13		29	R16		30			
J 1		29	R17		30			

#### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
4	23	R/B NO. 4 (LEFT KICK PANEL)

#### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1C	20	FLOOR NO. 2 WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D	20	FRONT DOOR LH WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1J		
1K		

#### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IC2	36	FLOOR NO. 2 WIRE AND COWL WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
BM1	40	BACK DOOR NO. 1 WIRE AND FLOOR NO. 2 WIRE (LEFT SIDE OF PACKAGE TRAY TRIM)
BO1	40	BACK DOOR NO. 2 WIRE AND BACK DOOR NO. 1 WIRE (BACK DOOR UPPER LEFT)


#### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	36	LEFT KICK PANEL
IH	36	RIGHT KICK PANEL


#### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 4	38	COWL WIRE	I14	38	INSTRUMENT PANEL WIRE
I 6	38	FLOOR NO. 2 WIRE			


A13 (B) ORANGE




A14 (A) ORANGE



H13 ORANGE




J 1




(HINT : SEE PAGE 7)

N 2, N 3 (A)



R16, R17





R18 (B) GREEN



R19 (C)







# AUTO ANTENNA

## SERVICE HINTS

### A30 AUTO ANTENNA CONTROL RELAY

- 1-GROUND : ALWAYS APPROX. 12 VOLTS
- 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 5-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 6-GROUND : ALWAYS CONTINUITY

### : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A30	28	R 4	B 29	S 9	B 29
A33	30	R 6	A 29		
J 1	29	S 8	A 29		

### : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (LEFT KICK PANEL)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IH1	38	INSTRUMENT PANEL WIRE AND CONSOLE BOX WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)


### : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IF	36	LEFT KICK PANEL
IH	36	RIGHT KICK PANEL


### : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 2	38	COWL WIRE	I16	38	CONSOLE BOX WIRE
I15	38	INSTRUMENT PANEL WIRE			


A30 GRAY



A33




J 1




(HINT : SEE PAGE 7)


R 4 (B)




R 6 (A)




S 8 (A)



(W/ WOOFER) S 9 (B) BLACK



(W/O WOOFER) S 9 (B)











# RADIO AND PLAYER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



# (w/STEREO POWER AMPLIFIER)

\* 1 : W/ WOOFER (SPEAKER)  
 \* 2 : W/O WOOFER (SPEAKER)





# RADIO AND PLAYER

## SERVICE HINTS

### S8 (A) STEREO POWER AMPLIFIER

- (A) 6, (A) 2-GROUND : ALWAYS APPROX. 12 VOLTS
- (A) 3-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** OR **ACC** POSITION
- (A) 4-GROUND : ALWAYS CONTINUITY

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A30	28	R6	29	S10	C 29
F10	29	R13	30		D 29
F11	29	R14	30	W2	30
F12	30	S8	A 29		
F13	30	S9	B 29		

### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	36	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IH1	38	INSTRUMENT PANEL WIRE AND CONSOLE BOX WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)
IH2		
IH3		
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IF	36	LEFT KICK PANEL


### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I5	38	INSTRUMENT PANEL WIRE	I19	38	INSTRUMENT PANEL WIRE
I16	38	CONSOLE BOX WIRE			


# (w/STEREO POWER AMPLIFIER)

\*1 : W WOOFER (SPEAKER)  
 \*2 : WO WOOFER (SPEAKER)


A30 GRAY




F10



F11




F12




F13



R 6




R13




R14




S 8 (A)




(\*1) S 9 (B) BLACK




(\*2) S 9 (B)



(\*1) S10 (C) BLACK



(\*2) S10 (D)




W 2





# RADIO AND PLAYER

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



# (w/o STEREO POWER AMPLIFIER)

## SERVICE HINTS

### R4(A) RADIO AND PLAYER

- (A) 4-GROUND : ALWAYS APPROX. 12 VOLTS
- (A) 3-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** OR **ACC** POSITION
- (A) 7-GROUND : ALWAYS CONTINUITY

### ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A30	28	F12	30	R5	B 29
F10	29	F13	30	R13	30
F11	29	R4	A 29	R14	30

### ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
ID1	36	FRONT DOOR LH WIRE AND INSTRUMENT PANEL WIRE (LEFT KICK PANEL)
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IL1	38	FRONT DOOR RH WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)

### ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IF	36	LEFT KICK PANEL


### ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I5	38	INSTRUMENT PANEL WIRE	I19	38	INSTRUMENT PANEL WIRE





# COMBINATION METER











# COMBINATION METER







# COMBINATION METER

## SERVICE HINTS

### B2 BRAKE FLUID LEVEL WARNING SW

1-2 : CLOSED WITH THE FLOAT DOWN

### P5 PARKING BRAKE SW

1-GROUND : CLOSED WITH THE PARKING BRAKE LEVER PULLED UP

### O2 OIL PRESSURE SW

1-GROUND : CLOSED WITH THE OIL PRESSURE ABOVE APPROX. 20 KPA (2.8 PSI, 0.2 KG/CM<sup>2</sup>)

### E4 ENGINE COOLANT TEMP. SENDER

1-GROUND : APPROX. 160-240 Ω (50°C, 122°F)  
APPROX. 17.1-20.4 Ω (120°C, 288°F)

### E7 ENGINE OIL LEVEL SENSOR

1-2 : CLOSED WITH THE FLOAT UP AND THE ENGINE OIL TEMP. AT BELOW APPROX. 55°C (131°F)  
OPEN WITH THE FLOAT DOWN AND THE ENGINE OIL TEMP. AT BELOW APPROX. 60°C (140°F)

### F14 FUEL SENDER

1-2 : APPROX. 3 Ω AT FUEL FULL  
APPROX. 110 Ω AT FUEL EMPTY

### C10 (B), C12 (A) COMBINATION METER

(B) 9-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

(A) 16-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT ST POSITION AND THE SHIFT LEVER AT P OR N POSITION (A/T)  
12 VOLTS WITH THE IGNITION SW AT ST POSITION AND THE CLUTCH PEDAL DEPRESSED (M/T)

(A) 8-GROUND : ALWAYS CONTINUITY

(A) 11-GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A13	28	E7	24 (2JZ-GTE)	O2	27 (2JZ-GE)
B2	24 (2JZ-GTE)		26 (2JZ-GE)	P2	25 (2JZ-GTE)
	26 (2JZ-GE)	E10	29		27 (2JZ-GE)
C9	28	F14	30	P4	29
C10	B 28	G2	24 (2JZ-GTE)	P5	29
C11	C 28		26 (2JZ-GE)	T5	29
C12	A 28	I4	27	T6	29
D6	28	J1	29	T13	29
E4	24 (2JZ-GTE)	L2	30	V10	25 (2JZ-GTE)
	26 (2JZ-GE)	O2	25 (2JZ-GTE)		27 (2JZ-GE)

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO. 4 (LEFT KICK PANEL)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1G	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H		
1I		
1J		
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IB1	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB2		
IE1	36	INSTRUMENT PANEL WIRE AND FLOOR NO. 2 WIRE (LEFT KICK PANEL)
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF2		
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IJ2	38	ENGINE WIRE COWL WIRE (RIGHT KICK PANEL)
BP1	40	FUEL GAUGE WIRE AND FLOOR NO. 2 WIRE (LUGGAGE ROOM FRONT LH)

**▽ : GROUND POINTS**

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
EC	32 (2JZ-GTE)	FRONT SIDE OF INTAKE MANIFOLD
	34 (2JZ-GE)	
IE	36	LEFT KICK PANEL
IF		
IH	36	RIGHT KICK PANEL

**○ : SPLICE POINTS**


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I2	38	COWL WIRE	I8	38	INSTRUMENT PANEL WIRE
I3	38	INSTRUMENT PANEL WIRE	I14		
I4	38	COWL WIRE	I21		






# COMBINATION METER


(2JZ-GTE) T 5




(2JZ-GE) T 5




T 6



T13 ORANGE



V10 BLACK







# RADIATOR FAN AND AUTOMATIC

## SYSTEM OUTLINE

### 1. HEATER BLOWER OPERATION

#### MANUAL BLOWER OPERATION

WHEN THE BLOWER CONTROL SW IS SET TO ANY BLOWER SPEEDS, THE A/C AMPLIFIER OPERATES AND THE CURRENT TO DRIVE THE BLOWER MOTOR FLOWS FROM **TERMINAL BLW** OF THE A/C AMPLIFIER TO **TERMINAL SI** OF THE BLOWER MOTOR CONTROL RELAY. THE CURRENT ACTIVATES THE RELAY AND THE VOLTAGE APPLIED TO **TERMINAL +B** OF THE BLOWER MOTOR CONTROL RELAY IS OUTPUT AT **TERMINAL M+** AS THE VOLTAGE FOR THE SELECTED BLOWER SPEED. THE CURRENT THEN FLOWS FROM **TERMINAL M+** OF THE BLOWER MOTOR CONTROL RELAY TO **TERMINAL 2** → **TERMINAL 1** → **TERMINAL M-** OF THE BLOWER MOTOR CONTROL RELAY → **TERMINAL GND** → **GROUND**, AND THE BLOWER MOTOR OPERATES AT THE BLOWER SPEED SELECTED.

#### AUTO FUNCTION

WHEN THE AUTO SW IS TURNED ON, THE A/C AMPLIFIER CALCULATES THE REQUIRED VENT TEMPERATURE BASE ON THE SET TEMPERATURE AND INPUT FROM EACH SENSOR. THEN **TERMINAL BLW** OF THE A/C AMPLIFIER INPUTS CURRENT TO **TERMINAL SI** OF THE BLOWER MOTOR CONTROL RELAY IN CONFORMITY WITH THE REQUIRED VENT OUTPUT. THIS CURRENT ACTIVATES THE BLOWER MOTOR CONTROL RELAY SO THAT CURRENT FLOWS FROM **TERMINAL M+** OF THE BLOWER MOTOR CONTROL RELAY → **TERMINAL 2** OF THE BLOWER MOTOR → **TERMINAL 1** → **TERMINAL M-** OF THE BLOWER MOTOR CONTROL RELAY → **TERMINAL GND** → **GROUND**, ACTIVATING THE BLOWER MOTOR. THE BLOWER MOTOR THEN OPERATES AT DIFFERENT STEPS IN CONFORMITY WITH VARIABLE CURRENT FLOW OUTPUT FROM **TERMINAL BLW** OF THE A/C AMPLIFIER TO **TERMINAL SI** OF THE BLOWER MOTOR CONTROL RELAY.

### 2. OPERATION OF AIR INLET CONTROL SERVO MOTOR

(SWITCHING FROM FRESH TO RECIRC)

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS FROM **HTR** FUSE TO **TERMINAL 2** OF THE AIR INLET CONTROL SERVO MOTOR → **TERMINAL 5** → **TERMINAL AIR** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND**, THE MOTOR ROTATES AND THE DAMPER STOPS AT **RECIRC** POSITION.

(SWITCHING FROM RECIRC TO FRESH)

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS FROM **HTR** FUSE TO **TERMINAL 2** OF THE AIR INLET CONTROL SERVO MOTOR → **TERMINAL 3** → **TERMINAL AIF** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND**, THE MOTOR ROTATES AND THE DAMPER STOPS AT **FRESH** POSITION.

### 3. OPERATION OF AIR VENT MODE CONTROL SERVO MOTOR

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS FROM **HTR** FUSE TO **TERMINAL IG** OF THE A/C AMPLIFIER

(SWITCHING FROM DEF TO FACE)

THE CURRENT FROM **TERMINAL AOF** OF THE A/C AMPLIFIER → **TERMINAL 1** OF THE AIR VENT MODE CONTROL SERVO MOTOR → **TERMINAL 2** → **TERMINAL AOD** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND**. THE MOTOR ROTATES AND THE DAMPER MOVES TO FACE SIDE. WHEN THE DAMPER OPERATES WITH THE A/C SW AT **FACE** POSITION, THE DAMPER POSITION SIGNAL IS INPUT FROM **TERMINAL 3** OF THE SERVO MOTOR TO THE **TERMINAL TP0** OF THE A/C AMPLIFIER. AS A RESULT, CURRENT TO THE SERVO MOTOR CIRCUIT IS CUT OFF BY THE AMPLIFIER, SO THE DAMPER STOPS AT THAT POSITION.

(SWITCHING FROM FACE TO DEF)

THE CURRENT FLOWS FROM **TERMINAL AOD** OF THE A/C AMPLIFIER → **TERMINAL 2** OF THE AIR VENT MODE CONTROL SERVO MOTOR → **TERMINAL 1** → **TERMINAL AOF** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND**, THE MOTOR ROTATES AND THE DAMPER STOPS AT THAT POSITION.

### 4. OPERATION OF AIR MIX CONTROL SERVO MOTOR

WHEN THE TEMPERATURE SW IS TURNED TO THE "COOL" SIDE, THE CURRENT FLOWS FROM **TERMINAL AMC** OF THE A/C AMPLIFIER → **TERMINAL 1** OF THE AIR MIX CONTROL SERVO MOTOR → MOTOR → **TERMINAL 2** → **TERMINAL AMH** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND** AND THE MOTOR ROTATES. THE DAMPER OPENING ANGLE AT THIS TIME IS INPUT FROM **TERMINAL 3** OF SERVO MOTOR TO **TERMINAL TP** OF THE A/C CONTROL ASSEMBLY, THIS IS USED TO DETERMINE THE DAMPER STOP POSITION AND MAINTAIN THE SET TEMPERATURE.

WHEN THE TEMPERATURE CONTROL SW IS TURNED TO THE "WARM" SIDE, THE CURRENT FLOWS FROM **TERMINAL AMH** OF THE A/C AMPLIFIER → **TERMINAL 2** OF THE AIR MIX CONTROL SERVO MOTOR → MOTOR → **TERMINAL 1** → **TERMINAL AMC** OF THE A/C AMPLIFIER, ROTATING THE MOTOR IN REVERSE AND SWITCHING THE DAMPER FROM COOL TO WARM SIDE.

## AIR CONDITIONING

---

### 5. AIR CONDITIONING OPERATION

THE A/C AMPLIFIER RECEIVES VARIOUS SIGNALS, I.E., THE ENGINE RPM FROM THE IGNITER, OUTLET TEMPERATURE SIGNAL FROM THE A/C THERMISTOR, COOLANT TEMPERATURE FROM THE ENGINE COOLANT TEMP. SENSOR AND THE LOCK SIGNAL FROM THE A/C COMPRESSOR, ETC.

WHEN THE ENGINE IS STARTED AND THE A/C SW (HEATER CONTROL SW) IS ON, A SIGNAL IS INPUT TO THE A/C AMPLIFIER. AS A RESULT, THE GROUND CIRCUIT IN A/C AMPLIFIER IS CLOSED AND CURRENT FLOWS FROM **HTR** FUSE TO **TERMINAL 1** OF THE A/C MAGNETIC CLUTCH RELAY → **TERMINAL 2** → **TERMINAL ACMG** OF THE ENGINE CONTROL MODULE → **TERMINAL A/C** → **TERMINAL MGC** OF THE A/C AMPLIFIER → **TERMINAL GND** → **GROUND**, TURNING THE RELAY ON, SO THAT THE A/C MAGNETIC CLUTCH IS ON AND THE A/C AMPLIFIER OPERATES.

AT THE SAME TIME, THE ENGINE CONTROL MODULE DETECTS THE MAGNETIC CLUTCH IS ON AND THE A/C AMPLIFIER IS OPERATING AND OPENS DIRECTION TO AVOID LOWERING THE ENGINE RPM DURING A/C OPERATING.


WHEN ANY OF THE FOLLOWING SIGNALS ARE INPUT TO THE A/C AMPLIFIER, THE A/C AMPLIFIER OPERATES TO TURN OFF THE AIR CONDITIONING.


- \* ENGINE RPM SIGNAL IS HIGH.
- \* COOLANT TEMP. SIGNAL IS HIGH.
- \* A SIGNAL THAT THE TEMPERATURE AT THE AIR OUTLET IS LOW.
- \* A SIGNAL THAT THERE IS A LARGE DIFFERENCE BETWEEN ENGINE SPEED AND COMPRESSOR SPEED.
- \* A SIGNAL THAT THE REFRIGERANT PRESSURE IS ABNORMALLY HIGH OR LOW.






# RADIATOR FAN AND AUTOMATIC









# RADIATOR FAN AND AUTOMATIC








# RADIATOR FAN AND AUTOMATIC







# RADIATOR FAN AND AUTOMATIC

## SERVICE HINTS

### A4 A/C MAGNETIC CLUTCH

4-GROUND : APPROX. 3.7 Ω

### A3 (A) A/C DUAL PRESSURE SW [A/C TRIPLE PRESSURE SW] (2JZ-GTE)

(A)1 -(A) 4 : OPEN ABOVE APPROX. 225 KPA (33 PSI, 2.3 KG/CM<sup>2</sup>) OR 3140 KPA (458 PSI, 32 KG/CM<sup>2</sup>)

### A3 (B) A/C DUAL PRESSURE SW (2JZ-GE)

(B)1- (B)2 : OPEN ABOVE APPROX. 225 KPA (33 PSI, 2.3 KG/CM<sup>2</sup>) OR 3140 KPA (458 PSI, 32 KG/CM<sup>2</sup>)

### A12 (C), A13 (A), A14 (B) A/C AMPLIFIER

+B-GROUND : ALWAYS APPROX. 10-14 VOLTS

IG-GROUND : APPROX. 10-14 VOLTS WITH THE IGNITION SW AT **ON** POSITION

HR-GROUND : APPROX. 10-14 VOLTS WITH THE IGNITION SW AT **ON** POSITION AND DO NOT TURN THE BLOWER MOTOR BELOW 1 VOLT WITH THE IGNITION SW AT **ON** POSITION AND TURN THE BLOWER MOTOR

ACC-GROUND : APPROX. 10-14 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION

TW-GROUND : 10-14 VOLTS AT START THE ENGINE AND MAX. COLD POSITION OF THE A/C TEMP. CONTROL SW BELOW 1 VOLT AT START THE ENGINE AND MAX. WARM POSITION OF THE A/C TEMP. CONTROL SW

MGC-GROUND : BELOW 1 VOLT AT START THE ENGINE, PUSH THE A/C AUTO SW AND THE A/C SW **ON** POSITION

BLW-GROUND : 10-14 VOLTS AT START THE ENGINE, PUSH THE A/C AUTO SW AND THE A/C SW **OFF** POSITION

S5-GROUND : 4-6 VOLTS WITH THE IGNITION SW ON

SG-GROUND : ALWAYS CONTINUITY

AMH-AMC : ALWAYS CONTINUITY

AMH-AMC : 13-19 VOLTS WITH THE IGNITION SW OFF

AOF-GROUND : APPROX. 12 VOLTS WITH THE FACE SW ON

AOD-GROUND : APPROX. 12 VOLTS WITH THE DEF SW ON

GND-GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A1	24 (2JZ-GTE)	A17	28	H12	A 29
	26 (2JZ-GE)	A24	28	H13	B 29
A2	24	A25	28	I4	27
A3	A 24 (2JZ-GTE)	A26	28	J1	29
	B 26 (2JZ-GE)	B3	28	R1	25
A4	24 (2JZ-GTE)	B4	A 28	R2	25
	26 (2JZ-GE)	B5	B 28	R3	25
A12	C 28	C10	A 28	R20	25
A13	A 28	C12	B 28	T6	29
A14	B 28	E5	24	V10	25 (2JZ-GTE)
A15	28	E10	29		27 (2JZ-GE)
A16	28	E11	29		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	22	R/B NO. 2 (ENGINE COMPARTMENT LEFT)
4	23	R/B NO. 4 (LEFT KICK PANEL)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	ENGINE ROOM MAIN WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E	20	INSTRUMENT PANEL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1H	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1K		

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	32 (2JZ-GTE)	ENGINE WIRE AND ENGINE ROOM MAIN WIRE (NEAR THE R/B NO. 2)
	34 (2JZ-GE)	
IB2	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)
IB4	36	ENGINE ROOM MAIN WIRE AND COWL WIRE (RIGHT KICK PANEL)
IB6		
IF1	36	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL REINFORCEMENT LH)
IF3	36	INSTRUMENT PANEL WIRE AND COWL WIRE (RIGHT KICK PANEL)
IG1	38	INSTRUMENT PANEL WIRE AND COWL NO. 3 WIRE (BEHIND HEATER CONTROL SW)
II1	38	ENGINE WIRE AND INSTRUMENT PANEL WIRE (RIGHT KICK PANEL)
IK1	38	COWL NO. 4 WIRE AND COWL WIRE (RIGHT KICK PANEL)


# AIR CONDITIONING

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32 (2JZ-GTE)	FRONT SIDE OF RIGHT FENDER
	34 (2JZ-GE)	
EB	32 (2JZ-GTE)	FRONT SIDE OF LEFT FENDER
	34 (2JZ-GE)	
IF	36	LEFT KICK PANEL
IG	36	RIGHT KICK PANEL
IH		

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E2	32	ENGINE ROOM MAIN WIRE	I12	38	INSTRUMENT PANEL WIRE
E5			I13	38	COWL NO. 3 WIRE
E9			I14	38	INSTRUMENT PANEL WIRE
E11	I19				
E21	I25				
E26	34	ENGINE WIRE			








# RADIATOR FAN AND AUTOMATIC AIR CONDITIONING


(2JZ-GE) E10 DARK GRAY




E11




H12 (A) ORANGE




H13 (B) ORANGE



I 4 BLACK



J 1



(HINT : SEE PAGE 7)


R 1 BLACK



R 2 BLACK




R 3 GRAY




R20 BLACK



T 6



V10 BLACK






# K OVERALL ELECTRICAL WIRING DIAGRAM


\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.

HOW TO READ THIS SECTION




- A**: System Title
- B**: Indicates the wiring color.  
Wire colors are indicated by an alphabetical code.  
B = Black L = Blue R = Red  
BR = Brown LG = Light Green V = Violet  
G = Green O = Orange W = White  
GR = Gray P = Pink Y = Yellow

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.




- C**: Indicates the connector to be connected to a part (the numeral indicates the pin No.)
- D**: The position of the parts is the same as shown in the wiring diagram and wire routing.
- E**: Indicates the pin number of the connector.  
The numbering system is different for female and male connectors.




The numbering system for the overall wiring diagram is the same as above.

- F**: Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.  
Example: **1** Indicates Relay Block No. 1.

- G**: Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts (different junction blocks are shaded differently for further clarification).



- H**: Indicates related system.
- I**: Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↘). Outside numerals are pin numbers.



- J**: ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- K**: Indicates a shielded cable.



- L**: Indicates and located on ground point.
- M**: The same code occurring on the next page indicates that the wire harness is continuous.


# K OVERALL ELECTRICAL WIRING DIAGRAM

1997 Model (Location No. 1 to 27)

## SYSTEM INDEX


SYSTEMS	LOCATION	SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	19-3 (w/ Traction Control) 18-3 (w/o Traction Control)	Horn	9-4	Seat Heater (Canada)	22-4
Auto Antenna	25-4	Ignition	2-4 (2JZ-GE) 2-2 (2JZ-GTE)	Shift Lock	22-2
Back-Up Light	16-8 (2JZ-GE) 15-8 (2JZ-GTE)	Illumination	8-3	SRS	13-3
Charging	1-4	Interior Light	10-3	Starting	1-2
Cigarette Lighter	22-1	Light Auto Turn Off	11-2	Stop Light	7-4
Clock	21-3	Power Seat	12-4	Taillight	7-2
Combination Meter	26-3	Power Source	1~27-1	Theft Deterrent and Door Lock Control	14-3
Cruise Control	17-3	Power Window	12-2	Traction Control	20-3
Electric Tension Reducer	21-4	PPS	21-3	Turn Signal and Hazard Warning Light	9-2
Electronically Controlled Transmission and A/T Indicator	16-3 (2JZ-GE) 15-3 (2JZ-GTE)	Radiator Fan and Automatic Air Conditioning	27-3	Unlock and Seat Belt Warning	10-2
Engine Control	4-3 (2JZ-GE) 3-3 (2JZ-GTE)	Radio and Player	24-3 (w/ Stereo Power Amplifier) 25-2 (w/o Stereo Power Amplifier)		
Fog Light	5-4	Rear Window Defogger and Mirror Heater	21-2		
Front Wiper and Washer	23-4	Rear Wiper and Washer	23-2		
Headlight	6-3 (Canada) 5-3 (USA)	Remote Control Mirror	11-4		

1 SUPRA ELECTRICAL WIRING DIAGRAM



# K OVERALL ELECTRICAL WIRING DIAGRAM

2 SUPRA







# K OVERALL ELECTRICAL WIRING DIAGRAM

3 SUPRA

(Cont. next page)




Power Source



Engine Control(2JZ-GTE)


For the connectors of the parts listed below, see the next page.  
 \* Engine Control Module





Engine Control(2JZ-GTE)

For the connectors of the parts listed below, see the next page.  
- Engine Control Module



# K OVERALL ELECTRICAL WIRING DIAGRAM

3 SUPRA(Cont' d)



Engine Control(2JZ- GTE)

9


10

11


12

ENGINE CONTROL MODULE

E 9 (B) DARK GRAY





E 10 (A) DARK GRAY






# K OVERALL ELECTRICAL WIRING DIAGRAM






# K OVERALL ELECTRICAL WIRING DIAGRAM

5 SUPRA




6 SUPRA






# K OVERALL ELECTRICAL WIRING DIAGRAM

7 SUPRA




8 SUPRA




# K OVERALL ELECTRICAL WIRING DIAGRAM

9 SUPRA




10 SUPRA




# K OVERALL ELECTRICAL WIRING DIAGRAM

11 SUPRA




12 SUPRA




# K OVERALL ELECTRICAL WIRING DIAGRAM

13 SUPRA



14 SUPRA






# K OVERALL ELECTRICAL WIRING DIAGRAM

15 SUPRA




















(Cont. next page)



Electronically Controlled Transmission and A/T Indicator(2JZ-GTE)

Power Source

1 2 3 4 B-Y




15 SUPRA(Cont' d)



Electronically Controlled Transmission and A/T Indicator




Back-Up Light(2JZ-GTE)



# K OVERALL ELECTRICAL WIRING DIAGRAM

(Cont. next page)



16 SUPRA


16 SUPRA (Cont' d)



Electronically Controlled Transmission and A/T Indicator




Back-Up Light(2JZ-GE)



# K OVERALL ELECTRICAL WIRING DIAGRAM


17 SUPRA



18 SUPRA


Power Source


ABS(w/o Traction Control)



# K OVERALL ELECTRICAL WIRING DIAGRAM

19 SUPRA









# K OVERALL ELECTRICAL WIRING DIAGRAM

21 SUPRA




22 SUPRA




# K OVERALL ELECTRICAL WIRING DIAGRAM

23 SUPRA




24 SUPRA



# K OVERALL ELECTRICAL WIRING DIAGRAM

25 SUPRA



1 : w/ Stereo Power Amplifier  
2 : w/o Stereo Power Amplifier







# K OVERALL ELECTRICAL WIRING DIAGRAM

26 SUPRA

(Cont. next page)




26 SUPRA(Cont' d)





# K OVERALL ELECTRICAL WIRING DIAGRAM



Radiator Fan and Automatic Air Conditioning

\*1 : 2JZ-GTE  
\*2 : 2JZ-GE

